



MERIDIAN
Information Manual

WARNING

This Information Manual may be used for general information purposes only.

This Information Manual is not kept current. It must not be used as a substitute for the official FAA approved Pilot's Operating Handbook required for operation of the airplane.




MERIDIAN

PA-46-500TP


SN 4697002, 4697340 AND UP
With Garmin G1000 and GFC700 System

INFORMATION

MANUAL



MANUAL PART NUMBER 767-070



Published by
TECHNICAL PUBLICATIONS
Issued: November 12, 2008
© 2008-2009 PIPER AIRCRAFT, INC.
All Rights Reserved



APPLICABILITY

Application of this handbook is limited to the specific Piper PA-46-500TP model airplane designated by serial number and registration number on the face of the title page of this handbook.


This handbook cannot be used for operational purposes unless kept in a current status.

WARNING

EXTREME CARE MUST BE EXERCISED TO LIMIT THE USE OF THIS HANDBOOK TO APPLICABLE AIRCRAFT. THIS HANDBOOK IS VALID FOR USE WITH THE AIRPLANE IDENTIFIED ON THE FACE OF THE TITLE PAGE. SUBSEQUENT REVISIONS SUPPLIED BY PIPER MUST BE PROPERLY INSERTED.

WARNING

INSPECTION, MAINTENANCE AND PARTS REQUIREMENTS FOR ALL NON-PIPER APPROVED STC INSTALLATIONS ARE NOT INCLUDED IN THIS HANDBOOK. WHEN A NON-PIPER APPROVED STC INSTALLATION IS INCORPORATED ON THE AIRPLANE, THOSE PORTIONS OF THE AIRPLANE AFFECTED BY THE INSTALLATION MUST BE INSPECTED IN ACCORDANCE WITH THE INSPECTION PROGRAM PUBLISHED BY THE OWNER OF THE STC. SINCE NON-PIPER APPROVED STC INSTALLATIONS MAY CHANGE SYSTEMS INTERFACE, OPERATING CHARACTERISTICS AND COMPONENT LOADS OR STRESSES ON ADJACENT STRUCTURES, PIPER PROVIDED INSPECTION CRITERIA MAY NOT BE VALID FOR AIRPLANES WITH NON-PIPER APPROVED STC INSTALLATIONS.



REVISIONS

The information compiled in the Pilot's Operating Handbook, with the exception of the equipment list, will be kept current by revisions distributed to the airplane owners. The equipment list was current at the time the airplane was licensed by the manufacturer and thereafter must be maintained by the owner.

Revision material will consist of information necessary to update the text of the present handbook and/or to add information to cover added airplane equipment.

I. Revisions

Revisions will be distributed whenever necessary as complete page replacements or additions and shall be inserted into the handbook in accordance with the instructions given below:

1. Revision pages will replace only pages with the same page number.
2. Insert all additional pages in proper numerical order within each section.
3. Insert page numbers followed by a small letter in direct sequence with the same common numbered page.

II. Identification of Revised Material


Each handbook page is dated at the bottom of the page showing the date of original issue and the date of the latest revision. Revised text and illustrations are indicated by a black vertical line located along the outside margin of each revised page opposite the revised, added, or deleted information. A vertical line next to the page number indicates that an entire page has been changed or added.

Vertical black lines indicate current revisions only. Correction of typographical or grammatical errors or the physical relocation of information on a page will not be indicated by a symbol.

ORIGINAL PAGES ISSUED


The original pages issued for this handbook prior to revision are given below:

Title, ii through viii, 1-1 through 1-16, 2-1 through 2-40, 3-1 through 3-72, 4-1 through 4-54, 5-1 through 5-144, 6-1 through 6-60, 7-1 through 7-74, 8-1 through 8-30, 9-1 through 9-56, and 10-1 through 10-2.



PILOT'S OPERATING HANDBOOK LOG OF REVISIONS

Current Revisions to the PA-46-500TP Meridian Pilot's Operating Handbook,
Report VB-1993 issued November 12, 2008.

Revision Number and Code	Revised Pages	Description of Revisions	FAA Approved Signature and Date
Rev. 1 (PR090616)	i	Added EASA approval	
		Updated Serial Number.	
	ii	Updated copyright.	
	v	Added Rev. 1 to L of R.	
	3-iii	Added 3.36 to TOC.	
	3-iv	Revised page numbers.	
	3-58	Added para. 3.36s.	
	3-59	Relocated to 3-60.	
	3-60	Relocated to 3-61.	
	3-61	Relocated to 3-62.	
	3-62	Relocated to 3-63.	
	3-63	Relocated to 3-64.	
	3-64	Relocated to 3-65.	
	3-65	Relocated to 3-66.	
	3-66	Relocated to 3-67.	
	3-67	Relocated to 3-68.	
	3-68	Relocated to 3-69.	
	3-69	Relocated to 3-70.	
	3-70	Relocated to 3-71.	
	3-71	Relocated to 3-72.	
3-72	Relocated to 3-73.		
3-73	Added page.		
3-74	Added blank page.		
7-40	Added GTS33 Mode S Transponder para.		
8-i	Added 8.38 to TOC.	 Albert J. Mill June 16, 2009	
8-31	Added page and para. 8.38.		
8-32	Added blank page.		
Rev. 2 (PR091106)	v	Added Rev. 2 to L of R.	
	thru vi		



PILOT'S OPERATING HANDBOOK LOG OF REVISIONS


Current Revisions to the PA-46-500TP Meridian Pilot's Operating Handbook, Report VB-1993 issued November 12, 2008.

Revision Number and Code	Revised Pages	Description of Revisions	FAA Approved Signature and Date
Rev. 2 (Cont.)	vi-a thru vi-b 2-11 2-17 3-2 3-3 4-iii 4-18 4-19 4-42 4-43 4-44 7-8 7-14 thru 7-15 7-16 7-19 7-22 7-23 7-34 thru 7-35	Added pages Revised text in Para. 2.29. Revised Equipment List in Para. 2.35. Revised text in Para. 3.1. Revised text in Note. Revised Pg. No. Removed text from Para. 4.5i and added Note. Deleted text from Para. 4.5i. Added text to Para. 4.5j. removed text from Para. 4.25a and 4.25b. Added text from Para. 4.25b pg. 4-42 to Para. 4.27a. Moved Para. 4.31 to pg. 4-44. Added Para. 4.31 from pg. 4-43. Revised text in Note. Revised text in Para. 7.8. Revised text in Note. Revised text in Para. 7.8. Revised text in Para. 7.8. Moved text to pg. 7-23. Added text from pg. 7-22. Revised text in Para. 7.8.	



PILOT'S OPERATING HANDBOOK LOG OF REVISIONS


Current Revisions to the PA-46-500TP Meridian Pilot's Operating Handbook, Report VB-1993 issued November 12, 2008.

Revision Number and Code	Revised Pages	Description of Revisions	FAA Approved Signature and Date
Rev. 2 (Cont.)	7-38 thru 7-40 8-3 9-i 9-57 thru 9-74	Revised text in Para. 7.8. Revised text in Para. 8.1. Added Supplement 5 to Section 9 TOC. Added Supplement 5 to Section 9.	 Albert J. Mill November 6, 2009
Rev. 3 (PR100927)	vi-a 2-21 3-5 3-71 4-14 4-17 4-18 4-19 4-41 4-42 4-43 5-2 5-3 5-4 5-5 5-6	Added Rev. 3 to L of R. Revised Para. 2.35. Revised Para. 3.1. Revised Note in Para. 3.43f. Revised Para. 4.5e. Revised Para. 4.5h. Revised Para. 4.5i. Revised Para.'s 4.5i and 4.5j. Revised Para. 4.23. Revised Para. 4.25a and 4.25b. Revised Para. 4.27a. Added text from page 5-3. Relocated text to page 5-2. Revised Para. 5.5(a). Revised Para. 5.5(b). Relocated text to page 5-6. Revised Para. 5.5(c). Added text from page 5-5. Relocated text to page 5-7. Revised Para. 5.5(c) and 5.5(d).	



PILOT'S OPERATING HANDBOOK LOG OF REVISIONS

Current Revisions to the PA-46-500TP Meridian Pilot's Operating Handbook, Report VB-1993 issued November 12, 2008.


Revision Number and	Revised	Description of Revisions	FAA Approved Signature
Rev. 3 (Continued)	5-7	Added text from page 5-6. Relocated text to page 5-8. Revised Para. 5.5(d) and 5.5(e).	 Albert J. Mill September 27, 2010
	5-8	Added text from page 5-7. Relocated text to page 5-8a.	
	5-8a	Added Page.	
	5-8b	Added Page.	
	7-i	Added Para. 7.33 to T of C.	
	7-74	Added Para. 7.33.	
	7-75	Added Page.	
	7-76	Added Page.	
	8-14	Revised Para. 8.21.	
	9-11	Revised Supplement 1, Section 3.	
	9-14	Revised Supplement 1, Section 3.	
	9-33	Revised Supplement 1, Section 7.	
	9-40	Revised Supplement 2, Section 4.	
Rev. 4 (PR101123)	vi-b	Added Rev. 4 to L of R.	
	vi-c	Added page.	
	vi-d	Added page.	
	4-11	Added Note to Para. 4.5c. Relocated text to page 4-11a.	
	4-11a	Added page.	
	4-11b	Added page.	
	4-12	Relocated text to page 4-11a and page 4-11b.	



PILOT'S OPERATING HANDBOOK LOG OF REVISIONS

Current Revisions to the PA-46-500TP Meridian Pilot's Operating Handbook,
Report VB-1993 issued November 12, 2008.

Revision Number and	Revised	Description of Revisions	FAA Approved Signature
Rev. 4 (Continued)	4-12	Added text from page 4-13.	
	(Cont.)	Added Note to Para. 4.5c.	
	4-13	Relocated text to page 4-12.	
	4-17	Added Note to Para. 4.5h.	
		Relocated text to page 4-19.	
	4-18	Added text from page 4-17.	
	4-22	Added Note to Para. 4.5n.	
	4-34	Added Note to Para. 4.13a.	
		Relocated text to page 4-35.	
	4-35	Added text from page 4-34..	
		Relocated text to page 4-35a.	
	4-35a	Added page.	
	4-35b	Added page.	
	4-36	Relocated text to page 4-35a.	
		Added Note to Para. 1.13c.	
	4-41	Added Note to Para. 4.23.	
		Relocated text to page 4-42.	
4-42	Added text from page 4-41.		
4-44	Added Note to Para. 4.31.		
7-43	Added Note to Para. 7.10.		
9-4	Revised Section 1.		
9-19	Added Note to Section 4.		
9-34	Revised Caution in Section 4.		
	Added Note to Section 4.		


Albert J. Mill
 November 23, 2010



PILOT'S OPERATING HANDBOOK LOG OF REVISIONS


Current Revisions to the PA-46-500TP Meridian Pilot's Operating Handbook,
Report VB-1993 issued November 12, 2008.

Revision Number and	Revised	Description of Revisions	FAA Approved Signature



TABLE OF CONTENTS

SECTION 1	GENERAL
SECTION 2	LIMITATIONS
SECTION 3	EMERGENCY PROCEDURES
SECTION 4	NORMAL PROCEDURES
SECTION 5	PERFORMANCE
SECTION 6	WEIGHT AND BALANCE
SECTION 7	DESCRIPTION AND OPERATION OF THE AIRPLANE AND ITS SYSTEMS
SECTION 8	AIRPLANE HANDLING, SERVICING AND MAINTENANCE
SECTION 9	SUPPLEMENTS
SECTION 10	OPERATING TIPS



THIS PAGE INTENTIONALLY LEFT BLANK





TABLE OF CONTENTS

SECTION 1

GENERAL

Paragraph No.		Page No.
1.1	Introduction	1-1
1.2	Notations	1-3
1.3	Engine	1-4
1.5	Propeller	1-4
1.7	Fuel	1-5
1.9	Oil	1-5
1.11	Maximum Weights	1-5
1.13	Reserved	1-6
1.15	Cabin and Entry Dimensions	1-6
1.17	Baggage Space Aft Cabin	1-6
1.19	Specific Loading	1-6
1.21	Symbols, Abbreviations and Terminology	1-7



THIS PAGE INTENTIONALLY LEFT BLANK

SECTION 1**GENERAL****1.1 INTRODUCTION**

This Pilot's Operating Handbook is designed for maximum utilization as an operating guide for the pilot. It includes the material required to be furnished to the pilot by the Federal Aviation Regulations and additional information provided by the manufacturer and constitutes the FAA Approved Airplane Flight Manual.

This handbook is not designed as a substitute for adequate and competent flight instruction, knowledge of current Airworthiness Directives, applicable Federal Aviation Regulations or Advisory Circulars. It is not intended to be a guide for basic flight instruction or a training manual and should not be used for operational purposes unless kept in a current status. The pilot should study the entire handbook to familiarize himself with the limitations, performance, procedures and operational handling characteristics of the airplane before flight.

Assurance that the airplane is in an airworthy condition is the responsibility of the owner. The pilot in command is responsible for determining that the airplane is safe for flight. The pilot is also responsible for remaining within the operating limitations as outlined by instrument markings, placards, and this handbook.



The handbook has been divided into numbered (arabic) sections each provided with a finger-tip tab divider for quick reference. Provisions for expansion of the handbook have been made by the deliberate omission of certain paragraph numbers, figure numbers, item numbers and pages noted as being intentionally left blank.

NOTE

In countries other than the United States of America, FAA operating rules may not apply. Operators must ensure that the aircraft is operated in accordance with national operating rules.

SECTION I
GENERAL

PA-46-500TP



THREE VIEW
Figure I-1

1.2 NOTATIONS

WARNING

Operating procedures or techniques which may result in personal injury or loss of life if not carefully followed.

CAUTION

Operating procedures or techniques which may result in damage to equipment if not carefully followed.

NOTE

Supplemental information or highlights considered of sufficient significance to require emphasizing.

THIS SPACE INTENTIONALLY LEFT BLANK

**1.3 ENGINE**

Number of Engines	1
Engine Manufacturer	Pratt & Whitney Canada
Engine Model Number	PT6A-42A

Engine Type

This airplane incorporates a free shaft turboprop engine with 3 axial and 1 centrifugal compressor stages, an annular combustion chamber, and a 3 stage turbine where one stage drives the compressor and a dual stage powers the propeller.

Horsepower Rating and Engine Speed

Takeoff Power	500 shp
Maximum Continuous	500 shp
Compressor Turbine Speed (Ng)	38,100 rpm (101.7%)
Propeller Speed (Np)	2,000 rpm

1.5 PROPELLER

Number of Propellers	1
Propeller Manufacturer	Hartzell
Blade Model	E8501B-3.5
Number of Blades	4
Hub Model	HC-E4N-3Q
Propeller Diameter	Maximum 82.5 in. (209.5 cm) Minimum 81.5 in. (207 cm)

Propeller Type

The propeller assembly consists of a hub unit and four metal blades, and is a hydraulically actuated, constant speed, full feathering and reversible type.

1.7 FUEL**JET FUEL ONLY**

Fuel Capacity	1160 lb/173 U.S. gal. (526.1 kg/654.8 liter)
Unusable Fuel	20 lb/3 U.S. gal. (9.0 kg/11.3 liter)

Fuel

Fuel, Aviation	Jet A, Jet A-1
----------------	----------------

Anti-Icing Additive

Refer to latest revision of
Pratt & Whitney Service Bulletin 3044
for anti-icing additive conforming
to MIL-I-27686

1.9 OIL

Oil Capacity	12 qt (11.35 liter)
Oil Specification	Refer to Section 8 for Oil Specifications

1.11 MAXIMUM WEIGHTS

Maximum Ramp Weight	5134 lb (2328.7 kg)
Maximum Takeoff Weight	5092 lb (2309.7 kg)
Maximum Landing Weight	4850 lb (2199.9 kg)
Maximum Weights in Baggage Compartment	100 lb (45.3 kg)
Maximum Zero Fuel Weight	4850 lb (2199.9 kg)



1.13 RESERVED

1.15 CABIN AND ENTRY DIMENSIONS

Cabin Width (max.)	49.5 in. (125.7 cm)
Cabin Length (Instrument panel to rear bulkhead)	148 in. (375.9 cm)
Cabin Height (max.)	47 in. (119.4 cm)
Entry Width	24 in. (60.9 cm)
Entry Height	46 in. (116.8 cm)

1.17 BAGGAGE SPACE AFT CABIN

Compartment Volume	20 cu. ft. (0.56 m ³)
Entry Dimensions	24 x 46 in. (60.9 x 116.8 cm)

1.19 SPECIFIC LOADING


Wing Loading at 5092 lb (2309.7 kg)	27.8 lb/ft ² (135.9 kg/m ²)
Power Loading @ MCP	10.2 lb/SHP (4.62 kg/SHP)

1.21 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY

The following definitions are of symbols, abbreviations and terminology used throughout the handbook and those which may be of added operational significance to the pilot.

(a) General Airspeed Terminology and Symbols

CAS	Calibrated Airspeed means the indicated speed of an aircraft, corrected for position and instrument error. Calibrated airspeed is equal to true airspeed in standard atmosphere at sea level.
KCAS	Calibrated Airspeed expressed in "Knots".
GS	Ground Speed is the speed of an airplane relative to the ground.
IAS	Indicated Airspeed is the speed of an aircraft as shown on the airspeed indicator when corrected for instrument error. IAS values published in this handbook assume zero instrument error.
KIAS	Indicated Airspeed expressed in "Knots".
M	Mach Number is the ratio of true airspeed to the speed of sound.
M_{MO}	Maximum Operating Limit Speed is the speed limit that may not be deliberately exceeded in normal flight operations. M is expressed in Mach number.
TAS	True Airspeed is the airspeed of an airplane relative to undisturbed air which is the CAS corrected for altitude, temperature and compressibility.
V_{FE}	Maximum Flap Extended Speed is the highest speed permissible with wing flaps in a prescribed extended position.



1.21 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY (Cont)

(a) General Airspeed Terminology and Symbols (Continued)

V_{LE}	Maximum Landing Gear Extended Speed is the maximum speed at which an aircraft can be safely flown with the landing gear extended.
V_{LO}	Maximum Landing Gear Operating Speed is the maximum speed at which the landing gear can be safely extended or retracted.
V_{MO}	Maximum Operating Speed is the the speed limit that may not be exceeded at any time. V is expressed in knots.
V_O	Maximum Operating Maneuvering Speed is the maximum speed at which application of full available aerodynamic control will not overstress the airplane.


NOTE

V_O is defined in accordance with FAR
23 Amendment 45

V_R	Rotation Speed used for takeoff.
V_S	Stalling Speed or the minimum steady flight speed at which the airplane is controllable.
V_{SO}	Stalling Speed or the minimum steady flight speed at which the airplane is controllable in the landing configuration at maximum gross weight.
V_{SI}	Speed or the minimum steady flight speed obtained in a specific configuration.
V_X	Best Angle-of-Climb Speed is the airspeed which delivers the greatest gain of altitude in the shortest possible horizontal distance.
V_Y	Best Rate-of-Climb Speed is the airspeed which delivers the greatest gain in altitude in the shortest possible time.

1.21 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY (Cont)**(b) Meteorological Terminology**

ISA	International Standard Atmosphere in which: (1) The air is a dry perfect gas; (2) The temperature at sea level is 15° Celsius (59° Fahrenheit); (3) The pressure at sea level is 29.92 in. Hg (1013.2 mb).
OAT	Outside Air Temperature is the free air static temperature obtained either from inflight temperature indications or ground meteorological sources, adjusted for instrument error and compressibility effects.
Indicated Pressure Altitude	The number actually read from an altimeter when the barometric subscale has been set to 29.92 in. Hg (1013.2 mb).
Pressure Altitude (P.A.)	Altitude measured from standard sea-level pressure of 29.92 in. Hg (1013.2 mb) by a pressure or barometric altimeter. It is the indicated pressure altitude corrected for position and instrument error. In this handbook, altimeter instrument errors are assumed to be zero.
Station Pressure	Actual atmospheric pressure at field elevation.
Wind	The wind velocities recorded as variables on the charts of this handbook are to be understood as the headwind or tailwind components of the reported winds.



1.21 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY (Cont)

(c) Power Terminology

Cruise Climb Power	The power recommended to operate the airplane in a cruise climb (a continuous, gradual climb) profile.
Flight Idle Power	The power required to run an engine, in flight, at the lowest speed that will ensure satisfactory engine and systems operation and airplane handling characteristics.
Maximum Continuous Power	The maximum power approved for continuous use.
Maximum Climb Power	The maximum power approved for climb.
Maximum Cruise Power	The maximum power approved for cruise.
Reverse Thrust	The thrust of the propeller directed opposite the usual direction, thereby producing a braking action.
Takeoff Power	The maximum power permissible for takeoff (limited to 5 minutes).
Zero Thrust	The absence of appreciable thrust.

1.21 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY (Cont)**(d) Engine Controls and Instruments**

Beta Range	On turbine powered aircraft using fully reversing propellers, this is the range of propeller blade angle movement not controlled by a governor and the propeller control lever. In this range, the blade pitch angle is scheduled by power lever movement and the constant propeller speed mechanism is blocked out.
Constant Speed Range	The engine operating range where the propeller is out of Beta range and operating at a constant rpm.
Gas Generator RPM (Ng)	Indicates the percent of gas generator rpm based on a figure of 101.7% at 38,100 rpm.
ITT Gauge	A temperature measuring system that senses gas temperature in the turbine section of the engine.
Manual Override (MOR)	The device that controls engine power in case of a pneumatic failure in the engine control systems. It can also control engine power in case of a power control linkage failure.
Propeller Feather	This is a propeller pitch condition which produces minimum drag in a flight condition.
Propeller Governor	The device that keeps propeller rpm constant by increasing or decreasing propeller pitch through a pitch change mechanism in the propeller hub.
Propeller RPM (Np)	Indicates propeller speed in rpm.
Py Pressure	P3 pressure (between the engine compressor and the combustor) This pressure is used as a reference for torque limiting and to provide smooth engine acceleration.



1.21 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY (Cont)

(d) Engine Controls and Instruments (Continued)

Tachometer	An instrument that indicates rotational speed. Gas generator tachometers measure speed as a percentage of the nominal maximum speed of the turbines (N_g), while propeller tachometers measure actual propeller rpm. (N_p)
Torquemeter	An indicating system that displays the output torque available on the propeller shaft. Torque is shown in foot-pounds.
Torque Limiter	A device which monitors torque pressure and adjusts the Py air pressure to the Fuel Control Unit to prevent an overtorque condition.

1.21 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY (Cont)**(e) Avionics System Abbreviations/Terminology**

1	Refers to pilot's side (AHRS1, ADC1, GPS1)
2	Refers to co-pilot's side (AHRS2, ADC2, GPS2)
ADC	Air Data Computer
AFCS	Automatic Flight Control System
AHRS	Attitude and Heading Reference System
EIS	Engine Indication System
FDE	Fault Detection and Exclusion
GCU	Garmin MFD/PFD Control Unit
GDL	Garmin Datalink
GDU	Garmin Display Unit
GEA	Garmin Engine/Airframe Processing Unit
GFC	Garmin Flight Control System
GIA	Garmin Integrated Avionics Unit
GMA	Garmin Audio Panel
GMC	Garmin AFCS Mode Controller
GMU	Garmin Magnetometer Unit
GPS	Global Positioning System
GSA	Garmin AFCS Servo Actuator
GSM	Garmin Servo Mount
GTP	Garmin Temperature Probe (OAT)
GTX	Garmin Transponder
GWX	Garmin Weather Radar
MFD	Multi-Function Display
PFD	Primary Flight Display
SBAS	Satellite-Based Augmentation System
TAWS	Terrain Awareness and Warning System
WAAS	Wide Area Augmentation System

1.21 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY (Cont)

(f) Airplane Performance and Flight Planning Terminology

Accelerate - Stop Distance	The distance required to accelerate an airplane to a specified speed and, experiencing failure of the engine at the instant that speed is attained, to bring the airplane to a stop.
Climb Gradient	The demonstrated ratio of the change in height during a portion of a climb, to the horizontal distance traversed in the same time interval.
Demonstrated Crosswind velocity	The demonstrated crosswind velocity is the velocity of the crosswind component for which adequate control of the airplane during takeoff and landing was actually demonstrated during certification tests.
MEA	Minimum Enroute IFR Altitude.
Route Segment	A part of a route. Each end of that part is identified by: (1) a geographical location; or (2) a point at which a definite radio fix can be established.

1.21 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY (Cont)**(g) Weight and Balance Terminology**

A.O.D.	Aft of Datum.
Arm	The horizontal distance from the reference datum to the center of gravity (C.G.) of an item.
Center of Gravity (C.G.)	The point at which an airplane would balance if suspended. The C.G.'s distance from the reference datum is found by dividing the total moment by the total weight of the airplane.
C.G. Arm	The arm obtained by adding the airplane's individual moments and dividing the sum by the total weight.
C.G. Limits	The extreme center of gravity locations within which the airplane must be operated at a given weight.
Datum	An imaginary vertical plane from which all horizontal distances are measured for balance purposes.
Basic Empty Weight	Standard empty weight plus optional equipment.
Maximum Landing Weight	Maximum weight approved for touchdown when landing.
Maximum Ramp Weight	Maximum weight approved for ground maneuver. (It includes the weight of fuel for start, taxi and run up.)
Maximum Takeoff Weight	Maximum Weight approved for the start of the takeoff run.
Maximum Zero Fuel Weight	Maximum weight exclusive of usable fuel.



1.21 SYMBOLS, ABBREVIATIONS AND TERMINOLOGY (Cont)

(g) Weight and Balance Terminology (Continued)

Moment	The product of the weight of an item multiplied by its arm. (Moment divided by a constant is used to simplify balance calculations by reducing the number of digits.)
Payload	Weight of occupants, cargo and baggage.
Standard Empty Weight	Weight of a standard airplane including unusable fuel, full operating fluids and full oil.
Station	A location along the airplane fuselage usually given in terms of distance from the reference datum.
Unusable Fuel	The quantity of fuel at which the first evidence of malfunctioning occurs under the most adverse fuel feed condition occurring under each intended operation and flight maneuver involving that tank.
Usable Fuel	Fuel available for flight planning.
Useful Load	Difference between takeoff weight, or ramp weight if applicable, and basic empty weight.

TABLE OF CONTENTS

SECTION 2

LIMITATIONS

Paragraph No.		Page No.
2.1	General	2-1
2.3	Airspeed Limitations	2-1
2.5	Airspeed Indicator Markings	2-2
2.7	Power Plant Limitations	2-3
	Engine	2-3
	Fuel	2-5
	Anti-Icing Additive	2-5
	Oil	2-6
	Propeller	2-6
2.9	Starter Limitations	2-7
2.11	Generator/Alternator Limitations	2-7
2.13	Power Control Lever Operation	2-8
2.15	Chip Detector	2-8
2.17	Power Plant Instrument Markings	2-8
2.19	Weight Limits	2-9
2.21	Center of Gravity Limits	2-9
2.23	Maneuver Limits	2-9
2.25	Flight Load Factor Limits	2-9
2.26	Runway Surface	2-10
2.27	Flight Crew Limits	2-10
2.28	Outside Air Temperature (OAT) Limits	2-10




TABLE OF CONTENTS (CONT'D)

**SECTION 2
LIMITATIONS**

Paragraph No.		Page No.
2.28a	Fuel Temperature Limits	2-10
2.29	Garmin G1000 Avionics System Limitations	2-11
2.31	Radar Limitations	2-16
2.32	Terrain Awareness and Warning System (TAWS)	2-16
2.33	Traffic Information	2-16
2.34	Jeppesen Chartview or Garmin Flight Charts Limitations	2-16
2.35	Kinds of Operation Equipment List	2-17
2.36	Operating Altitude Limitations	2-24
2.37	Oxygen	2-24
2.38	Cabin Pressurization Limits	2-24
2.39	Maximum Seating Configuration	2-24
2.40	Smoking	2-24
2.41	Icing	2-24
2.42	Vortex Generators	2-24
2.43	Placards	2-25

SECTION 2 LIMITATIONS

2.1 GENERAL

This section provides the FAA Approved operating limitations, instrument markings, color coding and basic placards necessary for operation of the PA-46-500TP Meridian and its systems.

Limitations associated with those optional systems and equipment which require handbook supplements can be found in Section 9 (Supplements).

2.3 AIRSPEED LIMITATIONS

SPEED	KIAS	KCAS
Maximum Operating Speed (V_{MO}) Do not exceed this speed in any operation.	188	187
Maximum Operating Maneuvering Speed - (V_O) Do not make full or abrupt control movements above this speed.	127	126
Maximum Flaps Extended Speed (V_{FE}) - Do not exceed this speed at the given flap setting.		
10°	168	167
20°	135	132
36°	118	115
Maximum Landing Gear Extended Speed (V_{LE}) Do not exceed this speed with the landing gear extended.	168	167
Maximum Landing Gear Operating Speed (V_{LO}) - Do not operate the landing gear above this speed.		
Extension	168	167
Retraction	129	128



2.5 AIRSPEED INDICATOR MARKINGS

(Garmin PFD)

MARKING	KIAS	SIGNIFICANCE
Red Line	188 KTS	Maximum Operating Limit (V_{MO}).
White Arc	69 to 118 KTS	Maximum Operating Speed with full flaps extended (V_{FE}).
Green Arc	79 to 188 KTS	Normal operating speed.
Red Line	69 KTS	Stalling speed with landing gear and flaps extended (V_{SO}) at maximum weight.

(Standby Airspeed Indicator)

Red Radial	188 KTS	Maximum Operating Limit (V_{MO})
White Arc	69 to 118 KTS	Maximum Operating Speed with full flaps extended (V_{FE}).
Green Arc	79 to 188 KTS	Normal Operating Speed

2.7 POWER PLANT LIMITATIONS**WARNING**

Positioning the power lever aft of the flight idle stop in flight is prohibited. Such positioning may cause loss of airplane control or may result in an engine overspeed condition and consequent loss of engine power.


Engine

Number of Engines	1
Engine Manufacturer	Pratt & Whitney Canada
Engine Model No.	PT6A-42A

The limits presented in the Table 2-1 shall be observed. The limitations presented do not necessarily occur simultaneously. Refer to the Pratt & Whitney Engine Maintenance Manual for specific action should any of the limits be exceeded.

Table 2-1							
OPERATING CONDITION (2)	SHP	TORQUE ft-lb (1)	MAX ITT °C	Ng %	Np RPM (11)	OIL PRESS PSI (7)	OIL TEMP °C
Take Off (3)	500	1313	800	101.7	2000	100 - 135	0 - 99
Max Continuous	500	1313	770	101.7	2000	100 - 135	0 - 99
Min. Idle			750 (8)	63 - 64		60 min.	-40 - 99
Starting			1000 (4)			0-200 (13)	-40 min(6)
Transient			850 (12) 880 (4)	104.1 (5)	2205 (9)	40 - 200	99 - 104 (10)
Max Reverse		310 - 360	770		1900	100 - 135	0 - 99

See Notes next page.



2.7 POWER PLANT LIMITATIONS (Continued)

NOTES:

- (1) Torque limit applies within range of 1600 to 2000 rpm prop shaft, below 1600 rpm torque is limited to 1100 ft. lb.
- (2) Engine inlet condition limit for engine operation: (a) temperature 46°C (115°F); (b) altitude: sea level to 30,000 ft. (temperature lapse rate of 2.0°C (3.7°F) per 1,000 ft. assumed).
- (3) This value is time limited to 5 minutes.
- (4) This value is time-limited to 5 seconds.
- (5) This value is time-limited to 10 seconds.
- (6) Limited by oil temperature.
- (7) Normal oil pressure with gas generator speed above 72% speed. With engine torque below 1313 ft. lb., minimum oil pressure is 85 psig at normal oil temperature (60 to 70°C). Under emergency conditions to complete a flight, a lower oil pressure limit of 60 psig is permissible at reduced power level, not exceeding 1100 ft. lb.
- (8) Applies over range 21000 to 23000 rpm.
- (9) May be employed in an emergency condition, at all ratings, to complete a flight.
- (10) Time limited to 10 minutes at any condition.
- (11) In flight in the absence of a minimum 40 psig oil pressure, continuous steady state propeller rotation must be prevented by propeller feathering. On the ground, with the engine shutdown, continuous propeller rotation must be prevented.
- (12) This value is time limited to 20 seconds.
- (13) During extremely cold starts (less than 0°F / -17.7°C), oil pressure may reach 200 psig.

2.7 POWER PLANT LIMITATIONS (Continued)**Fuel Limitations**

Approved Aviation Fuels JET A, JET A-1

Anti-Icing Additive

Anti-icing additive per MIL-I-27686 is required for use in the above fuels in the amount by volume of .15% maximum. See Section 8 for blending and handling procedures.

Total Capacity.....1160 lb/173 U.S. gal. (526.1 kg/654.8 liter)

Unusable Fuel.....20 lb/3 U.S. gal.(9.07 kg/11.3 liter)

The unusable fuel for this airplane has been determined as 10 lb/1.5 U.S. gal. (4.5 kg/5.6 liter) in each wing in critical flight attitudes.

Usable Fuel.....1140 lb/170 U.S. gal. (517.1 kg/643.5 liter)

The usable fuel in this airplane has been determined as 570 lb/85 U.S. gal. (258.5 kg/321.7 liter) in each wing.

Total usable fuel may be reduced by 13 lb/2 U.S.gal. (5.89 kg/7.5 liter) if the engine driven fuel boost pump fails.

Fuel quantity indication is not accurate in uncoordinated flight.

Fuel Imbalance

The maximum allowable fuel imbalance in this airplane is 125 lb (56.6 kg).

NOTE

To insure balanced fuel condition, minimize or avoid uncoordinated flight.



2.7 POWER PLANT LIMITATIONS (Continued)

Oil Limitations

Oil Grade or Specification

Refer to the latest revision of Pratt & Whitney Canada, Service Bulletin 3001 for approved oils. (Refer to Section 8 for Oil Specifications.)

CAUTION

Do not mix brands or types of oils.

Total Oil System Capacity 12 U.S. qt (11.35 liter)
Oil Tank Capacity9.2 U.S. qt (8.7 liter)

Propeller Limitations

Propeller Manufacturer	Hartzell
Propeller Model Number	HC-E4N-3Q
Number of Propellers	1
Number of Propeller Blades	4
Propeller Diameter	
Maximum	82.5 in. (209.5 cm)
Minimum	81.5 in. (207 cm)
Propeller Operating Limits	
Maximum Normal Operation	2000 RPM
Maximum Reverse	1900 RPM
Minimum Operation During Ground Operation	1200 RPM

NOTE

Propeller operation below 1200 RPM is prohibited.

**Blade Angles at Propeller Station 30
at Hydraulic Low Pitch Stop.**

Low Pitch Stop Min./Max.	18.9°/19.1°
Feather Min./Max.	84°/85°
Reverse Min./Max.	-9.5°/-10.5°

2.9 STARTER LIMITATIONS

Use of the starter is limited to 30 seconds ON, one minute OFF, 30 seconds ON, one minute OFF, 30 seconds ON, 30 minutes OFF before a fourth start may be attempted.

2.11 GENERATOR/ALTERNATOR LIMITATIONS

Generator/Alternator	Max. Continuous Load (amps)
Starter/Generator	170
Alternator Ground Operation	120
Alternator In Flight	130

THIS SPACE INTENTIONALLY LEFT BLANK



2.13 POWER CONTROL LEVER OPERATION

Power Lever Position operation aft of the flight idle detent is not permitted:

1. When the engine is shut down.
2. During flight.

WARNING

Positioning the power lever aft of the flight idle stop in flight is prohibited. Such positioning may cause loss of airplane control or may result in an engine overspeed condition and consequent loss of engine power.

2.15 CHIP DETECTOR

Takeoff is not approved with CHIP DETECT annunciator illuminated.

2.17 POWERPLANT INSTRUMENT MARKINGS

Table 2-2

Instrument	Red Line	Yellow Arc	Green Arc	Yellow Arc	Red Line
Propeller Speed (N _p)	2000		1200 - 2000		1200
Engine Speed (N _g)	101.7		0 - 101.7		
Fuel Flow - PPH			0 - 600		
Flow - KPH			0 - 272		
Oil Pressure - PSI	200	135 - 200	100 - 135	60 - 100 (1) 85 - 100 (2)	60 (1) 85 (2)
Oil Temp. °C	99		0 - 99	-40 - 0	-40
ITT - °C	800 1000 (3)	770 - 800	0 - 770		
Torque Ft - Lb	1313		0 - 1313		

(1) When torque is below 1100 ft. lb.

(2) When torque is above 1100 ft. lb.

(3) ITT red line while the engine is OFF and during engine START is 1000. Red line changes to 800 after engine START.

2.19 WEIGHT LIMITS

Maximum Ramp Weight	5134 lb (2328.7 kg)
Maximum Takeoff Weight	5092 lb (2309.7 kg)
Maximum Landing Weight	4850 lb (2199.9 kg)
Maximum Zero Fuel Weight	4850 lb (2199.9 kg)
Maximum Weight in Baggage Compartment	100 lb (45.3 kg)

NOTE

It is the responsibility of the airplane owner and the pilot to ensure that the airplane is properly loaded. See Section 6 (Weight and Balance) for proper loading instructions.

2.21 CENTER OF GRAVITY LIMITS

Weight	Forward Limit	Rearward Limit
	Distance Aft of Datum	Distance Aft of Datum
5134 lb (2328.7 kg)	141.13 in. (358.47 cm)	147.10 in. (373.63 cm)
5092 lb (2309.7 kg)	140.97 in. (358.06 cm)	147.10 in. (373.63 cm)
4100 lb (1859.7 kg)	137.23 in. (348.50 cm)	147.10 in. (373.63 cm)
3508 lb (1591.1 kg)	135.00 in. (342.90 cm)	143.67 in. (364.90 cm)
3000 lb (1360.7 kg)	135.00 in. (342.90 cm)	140.75 in. (357.49 cm)

NOTES

Straight line variation between points indicated.

The datum is located 100.0 in. (254 cm) ahead of the forward pressure bulkhead.

2.23 MANEUVER LIMITS


This is a Normal Category airplane. No acrobatic maneuvers including spins approved.

2.25 FLIGHT LOAD FACTOR LIMITS

Positive Load Factor (Maximum)	
Flaps Up	3.7 g
Flaps Down	2.0 g
Negative Load Factor (Maximum)	-1.48 g

NOTE

No inverted maneuvers approved.



2.26 RUNWAY SURFACE

Takeoff and landing operations must be conducted from paved, hard surfaces.

2.27 FLIGHT CREW LIMITS

The minimum required flight crew is one pilot in the left seat.

2.28 OUTSIDE AIR TEMPERATURE (OAT - Free Air Static Temperature) LIMITS

	Starting	In-flight
Minimum	-34°C	-54°C
Maximum	+46°C	+46°C

2.28a FUEL TEMPERATURE LIMITS

Minimum Limit

Fuel Type	Starting	In-flight
Jet A	-34°C	-34°C
Jet A-1	-34°C	-41°C

Maximum Limit

Fuel Type	Starting	In-flight
Jet A	+50°C	+50°C
Jet A-1	+50°C	+50°C

NOTE

When a mixture of Jet A and Jet A-1 is present in the fuel tanks, the Jet A minimum fuel temperature limit of -34°C must be observed.

2.29 GARMIN G1000 AVIONICS SYSTEM LIMITATIONS

1. The Garmin G1000 Cockpit Reference Guide for the Piper PA-46 Meridian, Garmin p/n 190-00764-XX, latest revision, must be immediately available to the flight crew.

NOTE

The Cockpit Reference Guide contains additional Warnings, Cautions and Advisories with which the pilot should become familiar.

2. The Garmin G1000 must utilize the following or later FAA approved software versions:

Sub-System	Software Version
PFD	8.20
MFD	8.20
GMA	3.05
AHRS	2.10
ADC	3.01
GIA	5.50
GEA	2.07
GPS	3.00

The database version is displayed on the MFD power-up page immediately after system power-up and must be acknowledged. The remaining system software versions can be verified on the AUX group sub-page 5, "AUX SYSTEM STATUS".

3. IFR enroute, oceanic and terminal navigation predicated upon the Garmin G1000 GPS Receiver is prohibited unless the pilot verifies the currency of the database or verifies each selected waypoint for accuracy by reference to current data.

2.29 GARMIN G1000 AVIONICS SYSTEM LIMITATIONS

(Continued)

4. Instrument approach navigation predicated upon the Garmin G1000 GPS Receiver must be accomplished in accordance with approved instrument approach procedures that are retrieved from the G1000 Navigation database. The G1000 Navigation database must incorporate the current update cycle or each waypoint must be verified for accuracy with current approach chart data.
5. When GPS WAAS corrections are unavailable or if operating outside of GPS WAAS coverage, instrument approaches utilizing the GPS receiver must be conducted in the approach mode and Fault Detection and Exclusion mode. Loss of Integrity annunciations must not be displayed at the Final Approach Fix. Vertical guidance from GPS will not be available if WAAS corrections are unavailable or if operating outside of WAAS coverage.
6. GPS WAAS SBAS corrections should be selected OFF when operating outside of WAAS system coverage.
7. Operation is prohibited north of 70° N and south of 70° S latitudes. In addition, operation is prohibited in the following two regions: 1) north of 65° N between 75° W and 120° W longitude and 2) south of 55° S between 120° E and 165° E longitude.
8. If the optional GDL 69 datalink is installed, weather information is limited to supplemental use only and may not be used in lieu of an official weather data source.
9. If FliteCharts or the optional Chartview function is enabled, the data is limited to supplemental use only. Current paper copies of navigation charts and data appropriate to the intended operation must be available to the pilot.

2.29 GARMIN G1000 AVIONICS SYSTEM LIMITATIONS
(Continued)

10. The TAWS / TERRAIN databases have an area of coverage as detailed below:
- The Terrain Database has an area of coverage from North 75° Latitude to South 60° Latitude in all longitudes.
 - The Airport Terrain Database has an area of coverage that includes the United States, Canada, Mexico, Latin America, and South America.
 - The Obstacle Database has an area of coverage that includes the United States.

NOTE

The area of coverage may be modified, as additional terrain data sources become available.

11. The AFCS preflight test must be successfully completed prior to use of the autopilot and flight director or manual electric trim. This is indicated by a white "PFT" annunciation during test, and upon successful conclusion a tone will be heard with the "PFT" annunciation clearing on the PFD.
12. A pilot with the seat belt fastened must occupy the left pilot's seat during all autopilot operations.
13. The autopilot and yaw damper must be off during takeoff and landing. The autopilot must be disengaged below 200 feet AGL during approach operations and minimum engagement height on takeoff is 400 feet AGL. Cruise engagement minimum altitude is 1000 feet AGL.
14. Autopilot operation with the G1000 in the reversionary (Display Backup) mode is limited to training operations and display failure operations.
15. Maximum fuel imbalance with autopilot engaged - 125 lbs.
16. Autopilot minimum approved operating speed - 90 KIAS.
Autopilot maximum approved operating speed - 175 KIAS
17. Minimum airspeed for autopilot coupled approaches - 100 KIAS



2.29 GARMIN G1000 AVIONICS SYSTEM LIMITATIONS

(Continued)

Approach Operation Limitations:


18. The GFC 700 autopilot is approved for Category 1 precision instrument approaches and non-precision approaches only.

CAUTION

CDI automatic source switching to the ILS on Nav 1 or 2 must be set to manual for instrument approaches conducted with the autopilot coupled. Upon selection of Nav 1 or 2, APR mode or NAV mode will have to be reselected for capture. If the CDI source is changed when the autopilot is engaged in NAV mode, the autopilot lateral mode will revert to roll attitude hold mode (ROL) and NAV mode must be manually reselected by the pilot.

19. To avoid giving unwanted audible alerts, TAWS should be inhibited when landing at an airport that is not included in the airport database.
20. All TAWS caution and warning aural alerts must be followed immediately upon receipt. Pilots are authorized to deviate from their current ATC clearance to the extent necessary to comply with terrain/obstacle warnings from the TAWS per FAR 91.223.
21. When operating single pilot - BARO SYNCH must be ON.
When operating two pilot - BARO SYNCH must be OFF.

THIS PAGE INTENTIONALLY LEFT BLANK



2.31 RADAR LIMITATIONS

Do not operate the radar during refueling operations or within 15 feet of trucks or containers accommodating flammables or explosives. Do not allow personnel within 15 feet of area being scanned by antenna when system is transmitting. Radar images beyond approximately 130nm should not be relied upon.

2.32 TERRAIN AWARENESS AND WARNING SYSTEM (TAWS)

Navigation must not be predicated upon the use of the Terrain Awareness Display. The Terrain Awareness Display is intended to serve as a situational awareness tool only, and may not provide the accuracy and/or fidelity on which to solely base terrain or obstacle avoidance maneuvering decisions.

2.33 TRAFFIC INFORMATION

The pilot should not maneuver the aircraft based on the traffic display only. The traffic display is intended to assist in visually locating traffic. The traffic display lacks the resolution necessary for use in evasive maneuvering. Maneuvers should be consistent with ATC instructions.

2.34 JEPPESEN CHARTVIEW OR GARMIN FLIGHT CHARTS LIMITATIONS

The geographic referenced aircraft symbol must not be used for navigation.

NOTE

The aircraft symbol displayed provides supplemental aircraft situational awareness information. It is not intended as a means for navigation or flight guidance. The airplane symbol is not to be used for conducting instrument approaches or departures. Position accuracy, orientation, and related guidance must be assumed by other means of required navigation.

Operators with the optional Jeppesen Chartview must have back-up charts available. Do not rely upon Jeppesen Chartview as your sole source of navigation information.

2.35 KINDS OF OPERATION EQUIPMENT LIST

This airplane may be operated in day or night VFR and day or night IFR when the appropriate equipment is installed and operable.

The following equipment list identifies the systems and equipment upon which type certification for each kind of operation was predicated and must be installed and operable for the particular kind of operation indicated.

NOTE

The following system and equipment list does not include specific flight instruments and communication/navigation equipment required by the FAR Part 91 operating requirements.

System	Number Required	Types of Operation and Remarks (DAY, NIGHT, VFR, IFR and ICING Conditions)
1. Garmin G1000 System Equipment		
GDU 1040 Primary Flight Display	1 (#1unit) 2	DAY, NIGHT, VFR IFR, ICING
GDU 1500 Multi-function Display	1	IFR, ICING
GCU 476 MFD/PFD Control Unit (Keypad)	1	IFR, ICING
GIA 63W Integrated Avionics Unit	2	DAY, NIGHT, VFR, IFR, ICING
GEA 71 Engine Airframe Interface	1	DAY, NIGHT, VFR, IFR, ICING
GRS 77 Attitude and Heading Reference System (AHRS)	1 2	DAY, NIGHT, VFR IFR, ICING
GDC 74A Air Data Computer (ADC)	1 2	DAY, NIGHT, VFR IFR, ICING
GMU 44 Magnetometer	2	DAY, NIGHT, VFR, IFR, ICING




2.35 KINDS OF OPERATION EQUIPMENT LIST (Continued)

System	Number Required	Types of Operation and Remarks (DAY, NIGHT, VFR, IFR and ICING Conditions)
1. Garmin G1000 System Equipment (continued) GMA 1347 Audio Panel	1 (pilot)	IFR, ICING
2. Flight Instrumentation Standby Attitude Indicator Standby Airspeed Indicator Standby Altimeter Magnetic Compass Outside Air Temperature (OAT) Indicator Clock	1 1 1 1 1 1	IFR, ICING IFR, ICING IFR, ICING DAY, NIGHT, VFR, IFR, ICING DAY, NIGHT, VFR, IFR, ICING IFR, ICING

2.35 KINDS OF OPERATION EQUIPMENT LIST (Continued)

System	Number Required	Types of Operation and Remarks (DAY, NIGHT, VFR, IFR and ICING Conditions)
3. Engine Instrumentation		
Torquemeter	1	DAY, NIGHT, VFR, IFR, ICING
Propeller Tachometer (Np)	1	DAY, NIGHT, VFR, IFR, ICING
Interstage Turbine Temperature (ITT)	1	DAY, NIGHT, VFR, IFR, ICING
Gas Generator Tachometer (Ng)	1	DAY, NIGHT, VFR, IFR, ICING
Oil Pressure	1	DAY, NIGHT, VFR, IFR, ICING
Oil Temperature	1	DAY, NIGHT, VFR, IFR, ICING
4. Miscellaneous Instrumentation		
Fuel Quantity Indicating System	2	DAY, NIGHT, VFR, IFR, ICING
Fuel Temperature Indicator	1	DAY, NIGHT, VFR, IFR, ICING
DC Voltmeter	1	DAY, NIGHT, VFR, IFR, ICING
DC Ammeter (Generator)	1	DAY, NIGHT, VFR, IFR, ICING
DC Ammeter (Alternator)	1	ICING
5. Equipment/ Furnishings		
Safety Restraint Each Occupant	AR	DAY, NIGHT, VFR, IFR, ICING



2.35 KINDS OF OPERATION EQUIPMENT LIST (Continued)

System	Number Required	Types of Operation and Remarks (DAY, NIGHT, VFR, IFR and ICING Conditions)
6. Engine		
Starter Generator	1	DAY, NIGHT, VFR, IFR, ICING
Alternator	1	ICING
FUEL PRESS LOW Annunciator**	1	DAY, NIGHT, VFR, IFR, ICING
L FUEL PUMP ON / R FUEL PUMP ON Annunciators*	2	DAY, NIGHT, VFR, IFR, ICING
Firewall Fuel Shutoff Valve	1	DAY, NIGHT, VFR, IFR, ICING
7. Flight Controls		
Flap Position Indicator	1	DAY, NIGHT, VFR, IFR, ICING
Elevator Trim Position Indicator	1	DAY, NIGHT, VFR, IFR, ICING
Rudder Trim Position Indicator	1	DAY, NIGHT, VFR, IFR, ICING
8. Ice Protection		
Pneumatic Deice System (Wing and Empennage Protection)*	1	ICING
Wing Ice Detection Light	1	ICING
Electrothermal Propeller Deice Boots*	1 per Blade	ICING

* Part of Crew Alerting System (CAS) and lighted switch in overhead switch panel.

** Part of Crew Alerting System (CAS)

2.35 KINDS OF OPERATION EQUIPMENT LIST (Continued)

System	Number Required	Types of Operation and Remarks (DAY, NIGHT, VFR, IFR and ICING Conditions)
8. Ice Protection (cont)		
Heated Windshield*	1	DAY, NIGHT, VFR, IFR, ICING
Heated Stall Warning Vane*	1	ICING
Heated Pitot Head*	1 (pilot) 2	DAY, NIGHT, VFR IFR, ICING
Alternate Static Source	1	ICING
WNSHLD OVRTEMP- Annunciator**	1	ICING
Vacuum Ejector	1	DAY, NIGHT, VFR, IFR, ICING
SURF DE-ICE System*	1	ICING
SURF DE-ICE FAIL Annunciator**	1	ICING
9. Landing Gear		
Hydraulic Pump	1	DAY, NIGHT, VFR, IFR, ICING
HYDR PUMP ON Annunciator**	1	DAY, NIGHT, VFR, IFR, ICING
Landing Gear Down Position Indicating Lights	3	DAY, NIGHT, VFR, IFR, ICING
Landing Gear Warning Horn	1	DAY, NIGHT, VFR, IFR, ICING
GEAR WARNING Annunciator (instrument panel red light)	1	DAY, NIGHT, VFR, IFR, ICING

* Part of Crew Alerting System (CAS) and lighted switch in overhead switch panel.

** Part of Crew Alerting System (CAS)



2.35 KINDS OF OPERATION EQUIPMENT LIST (Continued)

System	Number Required	Types of Operation and Remarks (DAY, NIGHT, VFR, IFR and ICING Conditions)
10. Pneumatic / Vacuum VACUUM LOW Annunciator**	1	IFR, ICING
11. Lights - External		
Landing Light	1	NIGHT
Position Lights		
a. Left Wing - Red and White	1 ca.	NIGHT
b. Right Wing - Green and White	1 ca.	NIGHT
Anti-Collision (Strobe) Lights	2	DAY, NIGHT, VFR, IFR, ICING
Taxi/Rec Lights	2	NIGHT
12. Lights - Cockpit		
Instrument Panel Switch Lights	AR	NIGHT
Instrument Lights	AR	NIGHT
Dome Lights	1 (pilot)	NIGHT

* Part of Crew Alerting System (CAS) and lighted switch in overhead switch panel.

** Part of Crew Alerting System (CAS)

2.35 KINDS OF OPERATION EQUIPMENT LIST (Continued)

System	Number Required	Types of Operation and Remarks (DAY, NIGHT, VFR, IFR and ICING Conditions)
13. Pressurization		
Cabin Altimeter	1	DAY, NIGHT, VFR, IFR, ICING
Cabin Differential Pressure Indicator	1	DAY, NIGHT, VFR, IFR, ICING
Cabin Vertical Speed Indicator	1	DAY, NIGHT, VFR, IFR, ICING
Pressure Control Valve	1	DAY, NIGHT, VFR, IFR, ICING
Pressure Relief Safety Valve	1	DAY, NIGHT, VFR, IFR, ICING
Pressurization Controller	1	DAY, NIGHT, VFR, IFR, ICING
CABIN ALT 10000 Annunciator (Amber)**	1	DAY, NIGHT, VFR, IFR, ICING
CABIN ALT 12000 Annunciator (Red)**	1	DAY, NIGHT, VFR, IFR, ICING
14. Miscellaneous System		
Stall Warning System	1	DAY, NIGHT, VFR, IFR, ICING
STALL WARN FAIL Annunciator**	1	DAY, NIGHT, VFR, IFR, ICING
LTS/GEAR ANN TEST System	1	DAY, NIGHT, VFR, IFR, ICING

* Part of Crew Alerting System (CAS) and lighted switch in overhead switch panel.

** Part of Crew Alerting System (CAS)



2.36 OPERATING ALTITUDE LIMITATIONS

Flight above 30,000 feet pressure altitude is not approved. Flight up to and including 30,000 feet is approved if equipped with avionics in accordance with FAR 91.

2.37 OXYGEN

A minimum of 800 psi is required for pressurized flight above 25,000 feet.

2.38 CABIN PRESSURIZATION LIMITS

- (a) Maximum cabin differential pressure of 5.5 psi.
- (b) Pressurized landing not approved.

2.39 MAXIMUM SEATING CONFIGURATION

The maximum seating capacity is 6 (six) persons.

2.40 SMOKING

Smoking is not permitted in the aircraft.

2.41 ICING (Reference Section 9, Supplements, for Meridian Aircraft Flight Into Known Icing (FIKI))

2.42 VORTEX GENERATORS

If a total of more than 5 (five) vortex generators are damaged or missing, the aircraft is not airworthy.

2.43 PLACARDS

On the pilot's left hand side panel:

THIS AIRCRAFT MUST BE OPERATED AS A NORMAL CATEGORY AIRPLANE IN COMPLIANCE WITH THE OPERATING LIMITATIONS STATED IN THE FORM OF PLACARDS, MARKINGS AND MANUALS. NO ACROBATIC MANEUVERS (INCLUDING SPINS) APPROVED. THIS AIRCRAFT APPROVED FOR V.F.R., I.F.R., DAY AND NIGHT ICING FLIGHT WHEN EQUIPPED IN ACCORDANCE WITH THE AIRPLANE FLIGHT MANUAL.

WARNING

TURN OFF STROBE LIGHTS WHEN IN CLOSE PROXIMITY TO GROUND OR DURING FLIGHT THROUGH CLOUD, FOG OR HAZE.

PRESSURIZED LANDING NOT APPROVED.

Above the pilot's PFD:

V₀ 127 KIAS
SEE AFM

V_{LO} 168 KIAS DN
V_{LO} 129 KIAS UP
V_{LE} 168 KIAS MAX

NO ACROBATIC MANEUVERS, INCLUDING SPINS, APPROVED.



2.43 PLACARDS (Continued)

Above the copilot's PFD (if equipped with Stormscope):

STORMSCOPE NOT TO BE USED FOR
THUNDERSTORM AREA PENETRATION

TOTAL USABLE FUEL CAPACITY 1140 LBS (517.1 KG)

FUEL TEMPERATURE LIMIT

JET A -34° C TO 50° C

JET A-1 -41° C TO 50° C

Adjacent to the parking brake knob:

PARK BRAKE
PULL ON

Below the cabin pressure dump switch:


DUMP

Adjacent to the bleed air knob:


BLEED AIR
PULL OFF

2.43 PLACARDS (Continued)

Around the ECS cabin comfort switch:




Around the landing gear handle:




Above the emergency gear extension handle:

EMERGENCY GEAR EXTENSION
PULL TO RELEASE. SEE A.F.M.
BEFORE RE-ENGAGEMENT.



2.43 PLACARDS (Continued)

On the power control console:



Near the elevator trim wheel:



2.43 PLACARDS (Continued)

On the fuel shutoff cover:

FUEL SHUTOFF
LIFT COVER - PULL OFF

Near the flap handle:

F L A P S		0° ▷
	<u>KIAS</u>	
	168	10° ▷
	135	20° ▷
	118	36° ▷


Near the defrost control:

DEFROST
PULL / ON



2.43 PLACARDS (Continued)

On the Environmental Control Unit switch panel:



Near the magnetic compass:

STANDBY COMPASS
FOR CORRECT READING CHECK:
AVIONICS ON
AIR CONDITIONING OFF
WINDSHLD HT OFF
PROP HEAT OFF
STALL HEAT OFF

THIS PAGE INTENTIONALLY LEFT BLANK



2.43 PLACARDS (Continued)

On the pilot's side panel directly below the window:

ALTERNATE STATIC SOURCE
(LOCATED PILOT'S SIDE BELOW PANEL)
UP - ALTERNATE
DOWN - PRIMARY
(SEE POH SECTION 5 FOR ALTERNATE
STATIC SYSTEM CORRECTION)

On the copilot's side panel:


EMERGENCY OXYGEN
IN DRAWER UNDER SEAT
(AISLE ACCESS)
PULL MASK OUT OF DRAWER FULLY
AT FULL EXTENSION GIVE CORD A TUG
MAXIMUM DURATION----- 15 MINS
SEE POH
NO SMOKING WHILE IN USE

On the pilot's side panel and below the right center window:


NO SMOKING


2.43 PLACARDS (Continued)

On the aft closeout panel:




On the handle of the upper cabin door (outside aircraft):






2.43 PLACARDS (Continued)

On the handle of the upper cabin door (inside aircraft):



On the upper edge of the cabin lower door:



Over the emergency exit handle:

EMERGENCY EXIT
REMOVE GLASS
PULL DOOR IN - LIFT UP

On inside of aft fuselage stowage door:

MAXIMUM WEIGHT THIS
COMPARTMENT 4 LBS (1.8 KG)

2.43 PLACARDS (Continued)

On the inside radar pod stowage door:

MAX WEIGHT 5 LBS (2.2 KG)

Near the wing fuel caps:



JET - A - FUEL

**ANTI-ICE ADDITIVE REQUIRED. SEE PILOT'S
OPERATING HANDBOOK FOR OTHER APPROVED
FUELS, QUANTITY AND TYPE OF ADDITIVE.**

**DURING FUELING AND DEFUELING OPERATIONS,
ATTACH GROUNDING CABLE TO GROUND
ATTACH PIN LOCATED ON MAIN STRUT.**




2.43 PLACARDS (Continued)

On the inboard section of the left flap:

NO
STEP

On the nose gear strut:



On the brake fluid reservoir:

BRAKE FLUID
RESERVOIR
SERVICE USING
MIL-H-5606

Inside the external power receptacle door:

STARTING PROCEDURE
FOR EXTERNAL POWER

MASTER SWITCH AND
RADIOS MUST BE OFF

SEE AIRPLANE FLIGHT
MANUAL FOR
DETAILED INSTRUCTIONS

Outside the external power receptacle door:

EXTERNAL POWER
28 VOLTS D.C.
TURN MASTER SWITCH
AND ALL EQUIP. OFF
BEFORE INSERTING
PLUG

2.43 PLACARDS (Continued)**Inside the main wheel well cavity:****STRUT AND TIRE
SERVICE INSTRUCTIONS**

PLACE AIRCRAFT ON JACKS AND EXTEND STRUT COMPLETELY. RELEASE AIR AND REMOVE AIR VALVE. SLOWLY COMPRESS THE STRUT. SLOWLY FILL COMPRESSED STRUT WITH MIL-H-5606 HYDRAULIC FLUID THROUGH THE FILLER OPENING UNTIL IT REACHES THE TOP OF THE FILLER PLUG HOLE. MANUALLY COMPRESS AND EXTEND STRUT SEVERAL TIMES TO REMOVE TRAPPED AIR. ADD FLUID EACH TIME IF REQUIRED. REPLACE VALVE AND, WITH MAIN GEAR STILL CLEAR OF GROUND, INFLATE STRUT TO 250 PSI AIR PRESSURE. INFLATE MAIN TIRE TO 55 PSI AIR PRESSURE. REMOVE JACKS FROM AIRCRAFT (NORMAL MAIN GEAR STRUT EXTENSION IS 3.14 INCHES / 7.98 CM WITH AIRCRAFT ON A LEVEL SURFACE AND AT EMPTY WEIGHT).

On the nose wheel strut:**STRUT AND TIRE
SERVICE INSTRUCTIONS**

PLACE AIRCRAFT ON JACKS AND EXTEND STRUT COMPLETELY. RELEASE AIR AND REMOVE AIR VALVE. SLOWLY COMPRESS THE STRUT. SLOWLY FILL COMPRESSED STRUT WITH MIL-H-5606 HYDRAULIC FLUID THROUGH THE FILLER OPENING UNTIL IT REACHES THE TOP OF THE FILLER PLUG HOLE. MANUALLY COMPRESS AND EXTEND STRUT SEVERAL TIMES TO REMOVE TRAPPED AIR. ADD FLUID EACH TIME IF REQUIRED. REPLACE VALVE AND, WITH NOSE GEAR STILL CLEAR OF GROUND, INFLATE STRUT TO A PRESSURE OF 160 PSI. INFLATE NOSE GEAR TIRE TO 70 PSI AIR PRESSURE. REMOVE JACKS FROM AIRCRAFT (NORMAL STRUT EXTENSION IS 2.70 INCHES / 6.86 CM WITH AIRCRAFT ON A LEVEL SURFACE AND AT EMPTY WEIGHT WITH FULL FUEL & OIL).



2.43 PLACARDS (Continued)

On the lower edge of the upper cabin door:


ENGINE OIL SPECIFICATION	DO NOT MIX DIFFERENT BRANDS OF OIL. OIL TANK CAPACITY: 9.2 QTS / 8.7 L. DO NOT OVERFILL.	100700-057
ENGINE LAST SERVICED WITH:	FILL WITH APPROVED OIL TO MAXIMUM MARK ON DIP STICK.	
DATE OF LAST SERVICE:	SEE LATEST REVISION OF PRATT & WHITNEY CANADA ENGINE SERVICE BULLETIN SB 3001 FOR LIST OF APPROVED LUBRICATING OILS.	

On the backside of the oil filler door:

ENGINE OIL SPECIFICATION	100700-058
DO NOT MIX DIFFERENT BRANDS OF OIL.	
OIL TANK CAPACITY: 9.2 QTS / 8.7 L. DO NOT OVERFILL.	
FILL WITH APPROVED OIL TO MAXIMUM MARK ON DIP STICK.	
SEE LATEST REVISION OF PRATT & WHITNEY CANADA ENGINE SERVICE BULLETIN SB 3001 FOR LIST OF APPROVED LUBRICATING OILS.	

2.43 PLACARDS (Continued)

On the pyramid cabinet behind the copilot's seat:





THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS
SECTION 3
EMERGENCY PROCEDURES

Paragraph No.		Page No.
3.1	General	3-1
	Crew Alerting System (CAS) Messages	3-2
	PFD Annunciations and Alerts	3-9
	Aural Alerts	3-12
	Overriding Considerations	3-13
	Terminology	3-13
3.3	Airspeeds for Emergency Operation	3-13
3.5	Rejected Takeoff	3-14
3.7	Engine Failure	3-14
	Engine Failure Before Rotation	3-14
	Engine Failure Immediately After Takeoff	3-15
	Engine Failure in Flight	3-15
	Air Start Envelope	3-16
	Air Start - Starter Assist	3-17
3.9	Engine System	3-19
3.9a	High Oil Temperature	3-19
3.9b	Oil Pressure	3-19
3.9c	Chip Detector	3-20
3.9d	Starter Engaged	3-20
3.9e	Fire Detect Fail	3-20
3.9f	Feather	3-21
3.9g	Beta	3-21
3.11	Fuel Control Unit Failure/Power Lever Control Loss (Manual Override Operation)	3-22
3.13	Propeller Speed	3-23
3.14	Engine Fire	3-24
	On Ground	3-24
	In Flight	3-24
3.15	Electrical Fire, Smoke or Fumes	3-25

TABLE OF CONTENTS (CONTINUED)

SECTION 3

EMERGENCY PROCEDURES

Paragraph No.		Page No.
3.16	Smoke Evacuation	3-26
	Cockpit/Cabin Fire	3-26
3.17	Emergency Descent - Maximum Rate	3-27
3.19	Emergency Descent - Maximum Range	3-27
3.21	Power Off Landing	3-28
3.23	Gear Up Landing	3-29
3.25	Landing Without Flaps	3-29
3.27	Landing With Primary Longitudinal Control Failed	3-30
3.29	Hydraulic System Malfunction	3-31
3.31	Emergency Landing Gear Extension	3-33
3.33	Flap System Malfunction	3-34
3.35	Electrical System Malfunctions	3-35
	Generator Failure	3-35
	Alternator Failure	3-35
	Dual Failure - Both Generator and Alternator Fail	3-36
	Complete Electrical Failure	3-43
3.36	Avionics System Failures	3-44
3.36a	Pilot's PFD Failure	3-44
3.36b	MFD Failure	3-45
3.36c	Copilot's PFD Failure	3-45
3.36d	Failure of Attitude and Heading Reference System (AHRS)	3-46
3.36e	Air Data Computer (ADC) Failure	3-49
3.36f	Erroneous or Loss of Engine and Fuel Displays	3-52
3.36g	Erroneous or Loss of Warning/Caution CAS Messages ...	3-52
3.36h	Autopilot Malfunction	3-53
3.36i	Automatic Autopilot Disconnect	3-53
3.36j	Electric Trim Failure	3-54
3.36k	Electric Pitch Trim Runaway	3-54

TABLE OF CONTENTS (CONTINUED)

SECTION 3

EMERGENCY PROCEDURES

Paragraph No.		Page No.
3.36l	Autopilot Overspeed Recovery	3-55
3.36m	Loss of Navigation Information	3-55
3.36n	Autopilot Out-Of-Trim	3-56
3.36o	Abnormal Flight Director Mode Transitions	3-57
3.36p	Failure of the Preflight Test	3-58
3.36p	Loss of Cabin Altitude Display	3-58
3.36r	Loss of Cabin Altitude Display and Cabin Differential Pressure Display	3-58
3-36s	Dual GPS Failure	3-58
3.37	Fuel System	3-60
3.39	Pressurization/Environmental System Malfunctions	3-63
	Fire/Smoke or Fumes in Cabin	3-63
	Cabin Altitude Above 10,000 Feet	3-64
	Cabin Altitude Above 12,000 Feet	3-64
	Emergency Pressurization	3-65
	Bleed Overtemperature	3-66
	Overpressurization	3-66
	Rapid or Explosive Decompression	3-67
3.40	Emergency Exit	3-67
3.41	Vacuum System Failure	3-68
3.43	Anti-ice/De-ice System Malfunctions	3-68
3.43a	Left Pitot Heat Failure	3-68
3.43b	Right Pitot Heat Failure	3-69
3.43c	Both Left and Right Pitot Heat Failure	3-69
3.43d	Pitot Heat Off	3-70
3.43e	Prop Heat Failure	3-70
3.43f	Windshield Over Temp	3-71
3.43g	Surface De-ice Failure	3-71
3.43h	Stall Warning Fail	3-72

TABLE OF CONTENTS (CONTINUED)

SECTION 3

EMERGENCY PROCEDURES

Paragraph No.		Page No.
3.45	Door Ajar	3-72
3.47	Standby Attitude Indicator Battery Heater Fail	3-72
3.49	Oxygen	3-73
3.51	Spin Recovery	3-73
3.53	Icing	3-73

SECTION 3

EMERGENCY PROCEDURES

3.1 GENERAL

This section provides the recommended procedures for handling various emergency or critical situations. All emergency procedures required by the FAA as well as those necessary for operation of the airplane, as determined by the operating and design features of the airplane, are presented.

Emergency procedures associated with optional systems and equipment which require handbook supplements are presented in Section 9, Supplements.

Pilots must familiarize themselves with the procedures in this section and must be prepared to take the appropriate action should an emergency situation arise. The procedures are offered as a course of action for handling the particular situation or condition described. They are not a substitute for sound judgement and common sense.

KNOW YOUR AIRCRAFT AND BE THOROUGHLY FAMILIAR WITH IMPORTANT EMERGENCY PROCEDURES.

Most basic emergency procedures are a normal part of pilot training. The information presented in this section is not intended to replace this training. This information is intended to provide a source of reference for the procedures which are applicable to this airplane. The pilot should review standard emergency procedures periodically to remain proficient in them.

3.1 GENERAL (Continued)

Crew Alerting System (CAS) Messages

The Crew Alerting System (CAS) consists of Master Warning and Master Caution Indicators operating in conjunction with CAS text messages. CAS text messages appear in the lower left area of the MFD during normal operations and in the right side area of the PFD's during reversionary mode operation. The Master Warning and Master Caution Indicators are illuminated push-button switches centered above the pilot's PFD. The severity of CAS messages are categorized as Warning, Caution and Advisory as follows:

Red Warning Messages

Warning messages consist of a flashing red Master Warning indicator, located above the pilot's PFD, and a flashing (inversely red on white) CAS Warning text message located in the lower left corner of the MFD. Warnings are accompanied by a continuous aural chime, which can be silenced by pressing (acknowledging) the MASTER WARN RESET switch. When acknowledged, the MASTER WARN RESET switch will extinguish, the CAS Warning text message will stop flashing and will revert to normal (red on black) video, and the aural chime will silence. CAS Warning text messages will persist until the initiating condition is removed. If the warning was initiated by an engine parameter, that parameter's indication will continue to flash until the condition is removed.

Amber Caution Messages

Caution messages consist of an amber Master Caution indicator, located above the pilot's PFD, and a (inversely black on amber) CAS Caution text message located in the lower left corner of the MFD. Cautions are accompanied by a single aural chime. Caution messages can be acknowledged by pressing the MASTER CAUTION RESET switch. When acknowledged, the MASTER CAUTION RESET switch will extinguish and the CAS Caution text message will revert to normal (amber on black) video. CAS Caution text messages will persist until the initiating condition is removed.

3.1 GENERAL (Continued)

Crew Alerting System (CAS) Messages (continued)

White Advisory Messages

CAS Advisory text messages appear in the CAS window in white text. Advisory messages do not require acknowledgment and are not accompanied by aural chimes. CAS Advisory Messages persist until the initiating condition is removed.

NOTE

The Garmin G1000 Cockpit Reference Guide for the Piper PA-46 Meridian, Garmin p/n 190-00764-XX, latest revision and the Garmin G1000 Pilot's Guide for the Piper PA-46-500TP, Garmin p/n 190-00763-XX, latest revision, contain detailed descriptions of the annunciator system (CAS and Non-CAS) and all warnings, cautions and advisories.

The following tables show the color and significance of the Warning, Caution and Advisory messages which may appear on the Garmin G1000 displays.

3.1 GENERAL (Continued)

Crew Alerting System (CAS) Messages (continued)

Warning Messages - Red - Repeating Aural Chime

Message	Cause
ALTERNATOR AMPS	Alternator producing 130 amperes or greater.
ALTERNATOR FAIL	Alternator switch selected ON and alternator control unit detects a failure of the alternator.
ALTERNATOR OFF	Alternator is selected OFF in flight.
BLEED OVERTEMP	Temperature in the bleed air ducts is 350°F or above.
CABIN ALT 12000	Cabin altitude is 12,000 feet or above.
CABIN DIFF PRESS	Cabin differential pressure is equal to or greater than 5.7 psi OR greater than 5.5 psi for more than 30 seconds.
DOOR AJAR	Cabin door is not properly closed and latched with engine running.
ENGINE FIRE	Overtemperature condition in the engine compartment due to fire.
FLAP FAIL	Wing flap system failure due to an overcurrent condition in the flap motor/actuator circuit
FUEL IMBALANCE	Fuel quantity imbalance greater than 125 pounds.
FUEL PRESS LOW	Fuel pressure is below 10 psig.
FUEL QTY LOW	Total FUEL QTY is equal to or less than 100 pound.
GENERATOR AMPS	Generator producing 170 amperes or greater.
GENERATOR FAIL	Generator selected ON and no output.
GENERATOR OFF	Generator is selected OFF in flight
HYDR PUMP ON	Landing gear hydraulic pump is operating while the aircraft is on the ground.
ITT	Inter-turbine temperature is equal to or greater than 800°C OR equal to or greater than 1000°C if in START mode OR equal to or greater than 750°C if Ng is between 63% and 64%.

3.1 GENERAL (Continued)**Crew Alerting System (CAS) Messages (continued)**

Message	Cause
NG OVERSPEED	Gas generator speed is equal to or greater than 101.7%.
OIL PRESSURE	For engine torque greater than or equal to 1100 foot-pounds and oil pressure that is either less than or equal to 85 psi or greater than 200 psi. OR For engine torque less than 1100 foot-pounds and oil pressure that is either less than or equal to 60 psi or greater than 200 psi.
OIL TEMPERATURE	Oil temperature is equal to or less than -40°C or equal to or greater than 99°C.
L PITOT HT FAIL R PITOT HT FAIL	Both left and right pitot heat have failed.
PROP HEAT FAIL	A fault has developed in the propeller heat system in flight.
PROP SPEED	Propeller speed is less than 1175 rpm or equal to or greater than 2040 rpm for more than 2 seconds.
SURF DE-ICE FAIL	Surface de-ice system has failed in flight.
TORQUE	Engine torque is 1330 foot-pounds or greater.
VOLTS	Generator is OFF, alternator is OFF and aircraft is on the ground and main bus voltage is less than 24V or equal to or greater than 32V OR generator is ON, alternator is ON or aircraft is in the air and main bus voltage is less than 25V or equal to or greater than 32V. Anytime when operating exclusively on the EMER bus and the voltage is less than 24 V.
WNSHLD OVRTEMP	Windshield temperature exceeds 170°F or the windshield temperature sensor has failed.

3.1 GENERAL (Continued)

Crew Alerting System (CAS) Messages (continued)

Caution Messages - Amber - Single Aural Chime

Message	Cause
BETA	Power lever is selected below flight idle position and propeller blade angle is below low pitch stop in flight.
CABIN ALT 10000	Cabin altitude is 10,000 feet or above.
CHIP DETECT	Existence of ferrous metal particles in the engine oil system.
FEATHER	With engine operating, indicates a failure in the propeller feathering electrical system. An uncommanded propeller feathering could occur if additional electrical failures occur in the system.
FIRE DETECT FAIL	Failure of the engine fire detection system.
FUEL FILTER	Fuel filter contamination level is approaching the bypass mode and requires maintenance.
FUEL IMBALANCE	Fuel quantity imbalance greater than 40 pounds.
FUEL QTY LOW	Total FUEL QTY is greater than 100 pounds and equal to or less than 180 pounds.
HYDR PUMP ON	Landing gear hydraulic pump has been operating for more than 15 seconds in flight.
OXYGEN	One or more of the passenger oxygen generators are activated while in flight.
L PITOT HT FAIL	Left pitot heat has failed.
R PITOT HT FAIL	Right pitot heat has failed.

3.1 GENERAL (Continued)
Crew Alerting System (CAS) Messages (continued)

Caution Messages - Amber - Single Aural Chime (continued)

Message	Cause
PITOT HEAT OFF	Pitot heat has not been selected ON (no chime accompanies this CAS message).
PROP HEAT FAIL	A fault has developed in the propeller heat system while the aircraft is on the ground.
STALL WARN FAIL	The lift computer and/or lift transducer has failed.
STARTER ENGAGED	The starter contactor is closed and power is being applied to the starter/generator. (Ng greater than 56% for 10 seconds.)
STBY BAT HT FAIL	Failure of the standby attitude indicator battery heater.
SURF DE-ICE FAIL	Surface de-ice system has failed while the aircraft is on the ground.
VACUUM LOW	Vacuum is below approximately 2.0 inches of mercury.

3.1 GENERAL (Continued)

Crew Alerting System (CAS) Messages (continued)

Advisory Messages - White - No Aural Chime

Message	Cause
ALTERNATOR OFF	Alternator is selected OFF while the aircraft is on the ground.
BETA	Propeller is in Beta range while the aircraft is on the ground.
DOOR AJAR	Cabin door is not properly closed and latched while the aircraft is on the ground with the engine not running.
EMER BLEED ON	Emergency bleed system has been activated either automatically at a cabin altitude in excess of 12,000 feet, or by the pilot.
FEATHER	Propeller is in feather position while the aircraft is on the ground.
L FUEL PUMP ON	Left fuel pump is operating and delivering 4.5 psig minimum.
R FUEL PUMP ON	Right fuel pump is operating and delivering 4.5 psig minimum.
FUEL TEMP	Fuel temperature is equal to or less than -34°C.
GENERATOR OFF	Generator is selected OFF while the aircraft is on the ground.
IGNITION ON	Ignition switch is selected to MAN and power is applied to the engine ignition unit, and when Auto mode is selected and engine torque is between 275 to 375 foot-pounds.
OXYGEN	One or more of the passenger oxygen generators are activated while the aircraft is on the ground.
STARTER ENGAGED	The starter is engaged normally.
STBY BAT TEST OK	Standby attitude indicator system test mode is successfully completed.

3.1 GENERAL (Continued)

PFD Annunciations and Alerts

The Garmin G1000 System produces a number of PFD annunciations and alerts outside of the Crew Alerting System (CAS). PFD annunciations and alerts are not accompanied by Master Warning or Master Caution Indications and are displayed in dedicated areas of the PFD or MFD. Various aural alerts (voice, horn or tone) may accompany PFD annunciations and alerts and no pilot action is required to acknowledge PFD annunciations and alerts.

3.1 GENERAL (Continued)

PFD Annunciations and Alerts (continued)

Comparator Annunciations

Comparator Window Text	Condition
ALT MISCOMP	Difference in altitude sensors is \geq 200 feet.
IAS MISCOMP	<p>If both airspeed sensors detect $<$ 35 knots, this is inhibited.</p> <p>If either airspeed sensor detects \geq 35 knots, and the difference in sensors is $>$ 10 knots.</p> <p>If either airspeed sensor detects \geq 80 knots, and the difference in sensors is $>$ 7 knots.</p>
HDG MISCOMP	Difference in heading sensors is $>$ 6 degrees.
PIT MISCOMP	Difference in pitch sensors is $>$ 5 degrees.
ROL MISCOMP	Difference in roll sensors is $>$ 6 degrees.
ALT NO COMP	No data from one or both altitude sensors.
IAS NO COMP	No data from one or both airspeed sensors.
HDG NO COMP	No data from one or both heading sensors.
PIT NO COMP	No data from one or both pitch sensors.
ROL NO COMP	No data from one or both roll sensors.

3.1 GENERAL (Continued)**PFD Annunciations and Alerts (continued)****Reversionary Sensor Annunciations**

Reversionary Sensor Window Text	Condition
BOTH ON ADC1	Both PFD's are displaying data from the number 1 Air Data Computer.
BOTH ON ADC2	Both PFD's are displaying data from the number 2 Air Data Computer.
BOTH ON AHRS1	Both PFD's are displaying data from the number 1 Attitude and Heading Reference System.
BOTH ON AHRS2	Both PFD's are displaying data from the number 2 Attitude and Heading Reference System.
BOTH ON GPS1	Both PFD's are displaying data from the number 1 GPS Receiver.
BOTH ON GPS2	Both PFD's are displaying data from the number 2 GPS Receiver.
XSIDE ADC	The PFD displaying this annunciation is displaying data from the cross-side Air Data Computer.
XSIDE AHRS	The PFD displaying this annunciation is displaying data from the cross-side Attitude and Heading Reference System.

3.1 GENERAL (Continued)

PFD Annunciations and Alerts (continued)

GEAR WARN Annunciator

The red GEAR WARN annunciator is located on the instrument panel above the landing gear selector. The GEAR WARN annunciator and gear warning horn will operate simultaneously under the following conditions:

- In flight when the throttle is reduced to low power settings and the landing gear are not in the DOWN position.
- In flight when the flaps are extended more than 10° and the landing gear are not in the DOWN position.
- On the ground when the landing gear selector is in the UP position. The landing gear squat switch activates to prevent operation of the retract side of the hydraulic pump on the ground.

Aural Alerts

Aural alerts are provided to alert:

- When an engine limitation is exceeded (repeating chime).
- When in a Vmo/Mmo overspeed condition (“Airspeed, Airspeed”).
- When approaching a stall (steady tone).
- When cabin altitude warning is exceeded (repeating chime).
- Autopilot disconnect (warble tone).
- Terrain caution/warnings.
- In flight when the throttle is reduced to low power settings and the landing gear are not in the DOWN position.
- In flight when the flaps are extended more than 10° and the landing gear are not in the DOWN position.
- On the ground when the landing gear selector is in the UP position.

3.1 GENERAL (Continued)

Overriding Considerations

In all emergencies, the overriding consideration must be to:

- Maintain Airplane Control.
- Analyze the situation.
- Take proper action.

NOTE

If after resetting a circuit breaker, it trips open again, do not attempt to reset it.

Terminology

Many emergencies require some urgency in landing the aircraft. The degree of urgency varies with the emergency; therefore the terms "land as soon as possible" and "land as soon as practical" are employed. These terms are defined as follows:

Land as soon as possible

A landing should be accomplished at the nearest suitable airfield considering the severity of the emergency, weather conditions, field facilities, and ambient lighting.

Land as soon as practical

Emergency conditions are less urgent, and although the mission is to be terminated, the emergency is such that an immediate landing at the nearest suitable airfield may not be necessary.

3.3 AIRSPEEDS FOR EMERGENCY OPERATIONS

STALL SPEEDS

5092 lbs (Gear UP, Flaps 0°)	79 KIAS
5092 lbs (Gear DOWN, Flaps 36°).....	69 KIAS

OPERATING MANEUVERING SPEED.....127 KIAS

BEST GLIDE (Propeller Feathered)

5092 lbs (Gear UP, Flaps 0°)	108 KIAS
------------------------------------	----------

3.5 REJECTED TAKEOFF

POWER LeverIDLE

BrakingAS REQUIRED

ReverseAS REQUIRED

If insufficient runway remains for a safe stop:

CONDITION LeverCUT-OFF/FEATHER

BATTERY SwitchOFF

Firewall FUEL SHUTOFF ValveLIFT COVER - PULL OFF

Maneuver as necessary to avoid obstacles.**After the aircraft has stopped - EVACUATE.****3.7 ENGINE FAILURE****Engine failure before rotation:**

POWER LeverIDLE

BrakingAS REQUIRED

STOP STRAIGHT AHEAD.**If insufficient runway remains for a safe stop:**

CONDITION LeverCUT-OFF/FEATHER

BATTERY SwitchOFF

Firewall FUEL SHUTOFF ValveLIFT COVER - PULL OFF

Maneuver as necessary to avoid obstacles.**After the aircraft has stopped - EVACUATE.**

3.7 ENGINE FAILURE (Continued)**Engine Failure Immediately After Takeoff**

If sufficient runway remains for a normal landing, land straight ahead. If area ahead is rough, or if it is necessary to clear obstructions, maintain a safe airspeed and make only a shallow turn if necessary to avoid obstructions.

Airspeed100 KIAS
 Landing GearDOWN
 POWER LeverIDLE
 CONDITION LeverCUT-OFF/FEATHER

When landing gear is down and time permits:

FlapsDOWN 36°
 Airspeed85 KIAS

BATTERY SwitchOFF
 Firewall FUEL SHUTOFF ValveLIFT COVER - PULL OFF
After the aircraft has stopped - EVACUATE.

Engine Failure in Flight

Oxygen.....AS REQUIRED
 MIC SEL SwitchMSK
 Airspeed108 KIAS
 POWER LeverIDLE
 CONDITION LeverCUT-OFF/FEATHER
 PropellerVERIFY FEATHERED

CAUTION

The battery switch must be ON to feather the propeller.


Remaining FuelCHECK
 Air StartRefer to Air Start procedure in this section

If above the airstart envelope (Figure 3-3), descend into the envelope and make an airstart per this section. Use oxygen as required. Perform a normal descent or emergency descent as appropriate.

If engine air start is not successful, proceed with the power off landing procedure per Section 3.21.

3.7 ENGINE FAILURE (Continued)

Air Start Envelope



Air Start Envelope

Figure 3-3

3.7 ENGINE FAILURE (Continued)**Air Start - Starter Assist****NOTE**

Items indented with “•” may be omitted if time is short.

Oxygen	AS REQUIRED
MIC SEL Switch	MSK
Autopilot	DISENGAGE
CONDITION Lever	CUT-OFF/FEATHER
Altitude & Airspeed	WITHIN THE AIR START ENVELOPE
POWER Lever	IDLE
GEN Switch	OFF
ALT Switch	OFF
• Electrical Load	REDUCE
• ECS CABIN COMFORT Switch	OFF
• BLEED AIR Lever	PULL OUT (closed)
FUEL PUMPS Switch	MAN
IGNITION Switch	MAN

CAUTION

To obtain an AUTO air start, the START MODE MAN/STOP switch must not be selected. If the switch is selected to MAN (switch light illuminated), the PUSH START switch must be held ON to keep the starter engaged during the start.

START MODE Switch	AUTO
PUSH START Switch	ENGAGE (Verify Start Annunciator Illuminated)
CONDITION Lever (Ng min. 13%)	RUN
ITT and Ng	MONITOR
After Engine Relight - Ng > 60%:	
GEN Switch	ON
ALT Switch	ON
FUEL PUMPS Switch	AUTO
IGNITION Switch	AUTO
BLEED AIR Lever	PUSH IN (open)
ECS CABIN COMFORT Switch	NORM



3.7 ENGINE FAILURE (Continued)

After Engine Relight - Ng > 60% (continued):

Electrical Equipment **AS REQUIRED**

3.9 ENGINE SYSTEM

3.9a High Oil Temperature

Indication: Master Warning Indication; Red OIL TEMP message;
Repeating aural chime; Red oil temperature indication.

POWER LeverREDUCE POWER

If temperature remains high, continue flight at reduced power and land as soon as possible.

3.9b Oil Pressure

Indication: Master Warning Indication; Red OIL PRESSURE message; Repeating aural chime; Red oil pressure indication.

Engine Torque at or above 1100 ft - lb:

Low Oil Pressure, Below 85 PSI

PowerREDUCE TO A MAX. OF
1100 FT - LB OF TORQUE

High Oil Pressure, Above 200 PSI

Land as soon as practical.

Engine Torque below 1100 ft - lb:

Low Oil Pressure, Below 60 PSI

PowerREDUCE TO MINIMUM TORQUE REQUIRED
TO COMPLETE FLIGHT

High Oil Pressure, Above 200 PSI

Land as soon as possible.

NOTE

If possible, always retain glide capability to the selected landing area in case of total engine failure.

3.9 ENGINE SYSTEM (Continued)**3.9c Chip Detector**

Indication: Master Caution Indication; Amber CHIP DETECT message; single aural chime.

After Engine Start:

Return to parking area and shutdown engine.

In Flight:

Oil TemperatureMONITOR

Oil Pressure.....MONITOR

Land as soon as practical.

Inspect Engine Before Next Flight

3.9d Starter Engaged

Indication: Master Caution Indication; Amber STARTER ENGAGED message remains illuminated after engine start; Single aural chime.

On the Ground:

MAN/STOP Switch.....PUSH

CONDITION Lever.....CUT-OFF/FEATHER

BATTERY Switch.....OFF

In Flight:

MAN/STOP Switch.....PUSH

GEN SwitchVERIFY ON

If generator is not on, land as soon as possible.

3.9e Fire Detect Fail

Indication: Master Caution Indication; Amber FIRE DETECT FAIL message; Single aural chime.

FIRE DETECT Circuit Breaker.....RESET

(Located on the pilot's forward circuit breaker panel, row D, position 6.)

Inspect and Repair Prior to Next Flight.

3.9 ENGINE SYSTEM (Continued)

3.9f Feather

Indication: Master Caution Indication; Amber FEATHER message;
Single aural chime.

On Ground After Engine Start:

Shut down and investigate cause.

In Flight:

Land as soon as practical and investigate cause.

3.9g Beta

In Flight:

Indication: Master Caution Indication; Amber BETA message;
Single aural chime.

POWER LeverVERIFY FLIGHT IDLE POSITION
OR FORWARD OF FLIGHT IDLE

3.11 FUEL CONTROL UNIT FAILURE OR POWER LEVER CONTROL LOSS (Manual Override Operation)

Indication: Power lever movement does not change Ng.

POWER Lever FLIGHT IDLE
 MANUAL OVRD Lever PULL UPWARDS AND MOVE
 FORWARD SLOWLY TO ACHIEVE
 REQUIRED ENGINE POWER

Land as soon as possible.

Perform landing without reverse.

After landing:

(If power cannot satisfactorily be controlled with MANUAL OVRD Lever)

CONDITION Lever CUT-OFF/FEATHER

CAUTION

Exercise extra care when using manual override, to avoid exceeding engine limitations. Engine response may be more rapid than when using the power lever. Avoid rapid movement.

If power control using manual override is excessive:

Reduce airspeed to below 168 KIAS by increasing pitch attitude.

Landing Gear EXTEND BELOW 168 KIAS

Flaps 10° BELOW 168 KIAS

Land as soon as possible.

When landing is assured:

CONDITION Lever CUT-OFF/FEATHER

3.13 PROPELLER SPEED

**Indication: Master Warning Indication; Red PROP SPEED message;
Repeating aural chime; Red propeller speed indication:**

For Prop RPM less than 1200:

POWER Lever INCREASE POWER

For Prop RPM greater than or equal to 2040 for more than 2 seconds:

POWER Lever REDUCE POWER

Airspeed REDUCE

Land as soon as practical.

For Prop RPM greater than or equal to 2080 continuously:

POWER Lever REDUCE AS NECESSARY

Airspeed REDUCE TO LOWEST PRACTICAL

Land as soon as possible.

NOTE

If possible, maintain altitude as necessary in order to retain glide capability to the selected airport in case of total engine failure.

Should heavy vibration or uncontrolled propeller speed runaway occur, be prepared to shut down the engine.

CONDITION Lever CUT-OFF/FEATHER

Conduct a Normal Descent, Section 4.5n, or Emergency Descent, Section 3.17, as appropriate and Power Off Landing, Section 3.21.

3.14 ENGINE FIRE**On Ground** (During engine start or taxi):**Indication: Master Warning Indication; Red Engine Fire message;
Repeating aural chime; Visual Verification.**

POWER Lever IDLE
 CONDITION Lever CUT-OFF/FEATHER
 Brakes AS REQUIRED
 Firewall FUEL SHUTOFF Valve LIFT COVER - PULL OFF
 BLEED AIR Lever PULL OUT (closed)
 ECS CABIN COMFORT Switch OFF
 FUEL PUMPS Switch OFF
 IGNITION Switch OFF
 Radio EMERGENCY CALL
 BATTERY Switch OFF
 Aircraft EVACUATE
 Fire EXTINGUISH

In Flight:**Indication: Master Warning Indication; Red Engine Fire message;
Repeating aural chime; Visual Verification.**

Engine Power REDUCE TO MINIMUM ACCEPTABLE
 ACCORDING TO FLIGHT SITUATION
 Oxygen AS REQUIRED (all aircraft occupants)
 MIC SEL Switch MSK

Confirm that fire exists then:

CONDITION Lever CUT-OFF/FEATHER
 Firewall FUEL SHUTOFF Valve LIFT COVER - PULL OFF
 ECS CABIN COMFORT Switch OFF
 BLEED AIR Lever PULL OUT (closed)

**Conduct a Normal Descent, Section 4.5n, or Emergency Descent,
Section 3.17, as appropriate and Power Off Landing, Section 3.21.****CAUTION**

If pressurized, this procedure will result in an immediate loss of pressurization and cabin altitude will rise at an uncontrolled rate.

3.15 ELECTRICAL FIRE, SMOKE OR FUMES

If source is known:

- OxygenCREW (100%) AND PASSENGERS
DON MASKS
- MIC SEL SwitchMSK
- Fire (if necessary)EXTINGUISH
- Faulty CircuitsISOLATE
- Smoke Evacuation (if necessary)EXECUTE CHECKLIST
(per para. 3.16)

Land as soon as possible.

If source is unknown:

- OxygenCREW (100%) AND PASSENGERS
DON MASKS
- MIC SEL SwitchMSK
- Fire (if necessary)EXTINGUISH
- Smoke Evacuation (if necessary)EXECUTE CHECKLIST
(per para. 3.16)
- GEN SwitchOFF
- ALT SwitchOFF
- AutopilotDISENGAGE
- Standby InstrumentsVERIFY ON and FLAG
IS PULLED ON GYRO
- (Transition to standby instruments and maintain attitude control using standby
altitude gyro)
- EMER SwitchON
- BATTERY SwitchOFF
- Cabin Altitude SelectSELECT 500 FEET ABOVE
FIELD ELEVATION
- Emergency DescentACCOMPLISH PER PARA. 3.17
TO A SAFE ALTITUDE
CONSISTENT WITH TERRAIN

Land as soon as possible.

(Perform Emergency Landing Gear Extension procedure and 0° Flap Landing)

3.15 ELECTRICAL FIRE, SMOKE OR FUMES (Continued)**If smoke or fire still persists:**

All Tie Bus BreakersPULL
Land as soon as possible.

(Perform Emergency Landing Gear Extension procedure and 0° Flap Landing)

CAUTION

The airplane may still be pressurized on the ground. Exercise extreme caution when operating cabin door.

3.16 SMOKE EVACUATION**Cockpit / Cabin Fire****CAUTION**

If pressurized, the following procedure will result in an immediate loss of pressurization and the cabin altitude will rise at an uncontrollable rate.

Oxygen MaskON (100%)
 MIC SEL SwitchMSK
 PassengersDON OXYGEN MASKS
 Cabin Pressure DUMP SwitchDUMP
 ECS CABIN COMFORT SwitchOFF
 BLEED AIR LeverPULL OUT (closed)
 EMERGENCY PRESSURE Circuit BreakerPULL
 (Located on the pilot's aft circuit breaker panel, row B, position 6.)
 AIR COND and Blower Fan SwitchesOFF
 VENT FAN SwitchON
 Emergency DescentAccomplish per Paragraph 3.17 to a
 Safe Altitude Consistent with Terrain

Land as soon as possible.

NOTE

If fumes/smoke dissipate, land as soon as possible to investigate problem. If fumes/smoke persist, refer to Fire in Flight procedure, Paragraph 3.14.

3.17 EMERGENCY DESCENT - MAXIMUM RATE

AutopilotOFF
 POWER LeverIDLE
 Landing GearBelow 168 KIAS, DOWN
 Windshield DEFROSTPULL OUT
 WINDSHLD HT SwitchDEFOG

NOTE

Windshield Heat ANTI ICE may be used for additional defrosting.

Smooth air

Airspeed after Landing Gear is Fully Extended168 KIAS

Rough air

Airspeed127 KIAS

3.19 DESCENT -MAXIMUM RANGE AFTER ENGINE FAILURE**NOTE**

Refer to Section 5, Performance, Figure 5-123 or Figure 5-257 (metric) for glide distance.

Oxygen MasksON
 MIC SEL SwitchMSK
 POWER LeverIDLE
 CONDITION LeverCUT-OFF/FEATHER
 PropellerVERIFY FEATHERED
 Landing Gear / FlapsUP

CAUTION

If landing gear and / or flaps are extended, glide distance will be severely reduced. Retracting the landing gear and flaps will reduce battery endurance significantly.

Airspeed108 KIAS
 Electrical LoadREDUCE (Monitor Battery Voltage)

CAUTION

If the propeller does not feather, the glide distance will be reduced.

NOTE

It may be required to adjust the rate of descent of the aircraft in order to achieve a cabin altitude of 12,500 feet before the oxygen supply is exhausted.

3.21 POWER OFF LANDING (ENGINE CUTOFF/FEATHER)

Best Gliding Airspeed is 108 KIAS

POWER Lever	IDLE
CONDITION Lever	CUT-OFF/FEATHER
Propeller	VERIFY FEATHERED
FUEL PUMPS Switch	OFF
IGNITION Switch	OFF
Firewall FUEL SHUTOFF Valve	LIFT COVER - PULL OFF
Electrical Load	REDUCE
ECS CABIN COMFORT Switch	OFF
Cabin Pressure DUMP Switch	DUMP
Seats and Seat Backs	UPRIGHT & LOCKED IN POSITION
Seat Belts and Harness	FASTEN / TIGHT
	CHECK INERTIA REEL
Passengers	BRIEF

Locate suitable field.

Establish spiral pattern. If sufficient altitude is available, maintain 108 KIAS with flaps 10° in the pattern.

Assure 1000 feet above field at downwind position for landing approach.

NOTE

For ditching or other off-airport landings, inhibit the Terrain Awareness and Warning System by selecting INHIBIT on the MFD Map-TAWS page.

When committed to landing:

Landing Gear	DOWN; 3 GREEN
Flaps	AS REQUIRED

If landing site is not suitable for gear down landing:

Landing Gear	MAINTAIN UP
--------------------	-------------

NOTE

Landing gear extension requires 8 seconds minimum.

Flaps	FULL DOWN
Final Approach Speed	85 KIAS

After Touchdown:

BATTERY Switch	OFF
After the aircraft has stopped	EVACUATE



3.27 LANDING WITH PRIMARY LONGITUDINAL CONTROL FAILED

PassengersBRIEF
Landing GearDOWN, 3 GREEN
Final Approach SpeedTRIM TO MAINTAIN 110 KIAS

- **Select the longest runway available and make a flat, no flap approach, minimizing the use of elevator trim.**
- **Set power (approximately 300 FT-LB torque) to maintain airspeed and 300 to 500 ft./min. rate of descent.**
- **Use elevator trim to adjust pitch.**
- **When positioned over the runway, flare the airplane with elevator trim and slowly reduce power to idle, reverse and brakes as required.**

3.29 HYDRAULIC SYSTEM MALFUNCTION

On Ground:

Indication: Master Warning Indication; Red HYDR PUMP ON message; Repeating aural chime.

LANDING GEAR Selector KnobVerify DOWN

The illumination of the HYDR PUMP ON annunciator while operating on the ground would require maintenance to investigate the cause prior to any flight operations.

In Flight:

Indication: Master Caution Indication; Amber HYDR PUMP ON message; Single aural chime.

HYDRAULIC PUMP POWER Circuit Breaker.....PULL
(Located on the pilot's forward circuit breaker panel, row C, position 4.)

Land as soon as practical and investigate the cause.

Prior to landing, the HYDRAULIC PUMP POWER circuit breaker must be reset to extend the landing gear. If the pump continues to run after the gear is locked down, pull the HYDRAULIC PUMP POWER circuit breaker. If the gear fails to extend, refer to the **Emergency Landing Gear Extension procedure 3.31.**

3.31 EMERGENCY LANDING GEAR EXTENSION

Indication: One or more of the green gear extension light(s) not illuminated and/or Red GEAR WARN annunciator illuminated.

NOTE

If emergency gear extension is required due to electrical power failure, the gear position indicator lights will not illuminate.

Prior to emergency extension procedure:

BATTERY Switch.....CHECK ON
 LANDING GEAR Circuit Breakers (2)RESET
 (Located on the pilot's forward circuit breaker panel, row C, positions 1, 2.)
 Day / Night Dimming SwitchDAY MODE

If landing gear does not check down and locked:

Airspeed100 KIAS
 HYDRAULIC PUMP POWER Circuit Breaker (25 amp)PULL
 (Located on the pilot's forward circuit breaker panel, row C, position 4.)
 Landing Gear HandleDOWN
 Emergency Gear Extension Control.....PULL

If 3 green lights are still not illuminated:

Yaw the aircraft left and right to lock the main landing gear.
 Reduce airspeed to minimum safe speed to improve nose gear locking.

If 3 green lights are illuminated:

Land.

If not successful, refer to Gear Up Landing (Section 3.23).



3.33 FLAP SYSTEM MALFUNCTION

**Indication: Master Warning Indication; Red FLAP FAIL message;
Repeating aural chime.**

FLAP WARN Circuit BreakerPULL AND RESET,
VERIFY NORMAL
FLAP OPERATION

(Located on the pilot's forward circuit breaker panel, row B, position 4.)

If Red FLAP FAIL message remains present:

FLAP MOTOR Circuit BreakerPULL
(Located on the pilot's forward circuit breaker panel, row B, position 3.)

Refer to Landing Without Flaps (Section 3.25).

3.35 ELECTRICAL SYSTEM MALFUNCTIONS**Generator Failure**

Indication: Master Warning Indication; Red GENERATOR FAIL message; Repeating aural chime; Zero generator amp indication.

Electrical LoadREDUCE UNTIL TOTAL LOAD IS
BELOW 130 AMPS & VOLTS
ANNUNCIATOR IS EXTINGUISHED

AIR COND SwitchOFF

GEN SwitchOFF then ON

If generator fails to reset:

GEN SwitchOFF

GENERATOR CONTROL Circuit BreakerRESET

(Located on the lower left instrument panel.)

GEN SwitchON

If circuit breaker opens again or annunciator stays illuminated with zero amps indicated:

GEN SwitchOFF

GENERATOR CONTROL Circuit BreakerPULL/DO NOT RESET

Land as soon as practical.

Alternator Failure

Indication: Master Warning Indication; Red ALTERNATOR FAIL message; Repeating aural chime; Zero alternator amp indication.

ALT SwitchOFF then ON

If alternator fails to reset:

ALT SwitchOFF

ALTERNATOR FIELD Circuit BreakerRESET

(Located on the pilot's forward circuit breaker panel, row D, position 7.)


ALT SwitchON

If circuit breaker opens again or annunciator stays illuminated with zero amps indicated:

ALT SwitchOFF

ALTERNATOR FIELD Circuit BreakerPULL/DO NOT RESET

If generator has assumed the load, limit load to under 200 amps and continue flight while avoiding icing conditions. Repair alternator as soon as possible.



3.35 ELECTRICAL SYSTEM MALFUNCTIONS (Continued)

Dual Failure - Both Generator and Alternator Fail

Indication: Red GENERATOR FAIL and Red ALTERNATOR FAIL messages; Repeating aural chime; Zero amp indication on both ammeters.

NOTE

Any time total tie bus voltage is below 25 Vdc while the aircraft is in the air, the VOLTS message will illuminate.

- GEN SwitchOFF
- ALT SwitchOFF
- GENERATOR CONTROL Circuit BreakerRESET
(Located on the lower left instrument panel.)
- ALTERNATOR FIELD Circuit Breaker.....RESET
(Located on the pilot's forward circuit breaker panel, row D, position 7.)
- GEN Switch (after OFF at least one second).....ON
- ALT Switch (after OFF at least one second).....ON

If only the generator resets:

- ALT SwitchOFF
- Continue flight while avoiding icing conditions.*

NOTE

The generator can supply sufficient amperage to run all the required electrical systems.

If only the alternator resets:

- GEN SwitchOFF
- Electrical LoadMAINTAIN LESS THAN
130 AMPS
- AmmeterMONITOR

Land as soon as practical.

3.35 ELECTRICAL SYSTEM MALFUNCTIONS (Continued)**If neither the generator nor alternator resets:**

GEN Switch.....	OFF
ALT Switch.....	OFF
EMER Switch.....	Verify OFF
BATTERY Switch.....	Verify ON
Electrical Load.....	REDUCE TO MINIMUM (per load-shed procedures shown)

NOTE

To have 30-minutes of battery power remaining after failure of the alternator and generator, the complete electrical system can be operated for 5-minutes and then load shedding per the procedure below must be executed. It is advised to start the load shedding procedure as soon as conditions permit. Items that are not shown, such as standby attitude indicator, are allowed to run continuously and still meet the 30-minute requirement.

Load-shed procedure (for 30-minutes of battery life):*VFR/DAY/NIGHT Conditions:***NOTE**

Turning off the AVIONICS switch removes power from all equipment on Avionics Bus 1 and Avionics Bus 2, some of which may be desired. Power must be removed as soon as conditions allow, and within 5-minutes of the alternator and generator failure, to have 30-minutes of battery life from the time of failure.

CAUTION

Common sense should be exercised when deactivating certain items. Any items that remain ON or are not activated as shown will reduce the battery life to less than 30-minutes.

3.35 ELECTRICAL SYSTEM MALFUNCTIONS (Continued)

VFR/DAY/NIGHT Conditions (continued):

AIR COND SwitchOFF
AVIONICS SwitchOFF
FUEL PUMPS SwitchAUTO
IGNITION SwitchAUTO
VENT FANOFF
WINDSHLD HT SwitchOFF
PITOT HEAT SwitchOFF (unless in rain)
PROP HEAT SwitchOFF
STALL HEAT SwitchOFF
SURF DE-ICE SwitchOFF
TAXI/REC LTOFF
LANDING LIGHTOFF
NAV LIGHTOFF
STROBE LIGHTOFF
ICE LIGHTOFF
COM 1 Transmit2-minutes in CRUISE 1-minute at LANDING

3.35 ELECTRICAL SYSTEM MALFUNCTIONS (Continued)**If desired equipment has been deactivated:****NOTE**

With the AVIONICS switch turned ON 30-minutes of battery life from the time of failure will not be available.

Circuit breakers of non-desired equipment.....PULL
 AVIONICS Switch.....ON

*ICING Conditions:***NOTE**

Exit and avoid icing conditions as soon as possible, as electrical equipment needed for flight in icing conditions, other than that shown below, will reduce the life of the battery to less than 30-minutes.

NOTE

Turning off the AVIONICS switch removes power from all equipment on Avionics Bus 1 and Avionics Bus 2, some of which may be desired. Power must be removed as soon as conditions allow, and within 5-minutes of the alternator and generator failure, to have 30-minutes of battery life from the time of failure.

CAUTION

Common sense should be exercised when deactivating certain items. Any items that remain ON or are not activated as shown will reduce the battery life to less than 30-minutes.

3.35 ELECTRICAL SYSTEM MALFUNCTIONS (Continued)

ICING Conditions (continued):

AIR COND SwitchOFF
AVIONICS SwitchOFF
FUEL PUMPS SwitchAUTO
IGNITION SwitchAUTO
VENT FANOFF
WINDSHLD HT SwitchOFF
PITOT HEAT SwitchON
PROP HEAT SwitchOFF
STALL HEAT SwitchOFF
SURF DE-ICE SwitchOFF (except 1 cycle in CRUISE, 1 cycle at LANDING)
TAXI/REC LTOFF
LANDING LIGHTOFF
NAV LIGHTOFF
STROBE LIGHTOFF
ICE LIGHTOFF (ON 1 minute in CRUISE, 1 minute at LANDING)
COM 1 Transmit2-minutes in CRUISE 1-minute at LANDING

3.35 ELECTRICAL SYSTEM MALFUNCTIONS (Continued)

If desired equipment has been deactivated:

NOTE

With the AVIONICS switch turned ON 30-minutes of battery life from the time of failure will not be available.

Circuit breakers of non-desired equipment.....PULL
 AVIONICS Switch.....ON

LANDING Conditions:

NOTE

If the landing is performed at a time that is approximately 30-minutes after the alternator and generator failure, activation of the following equipment may cause a complete electrical system failure. Be prepared to execute the appropriate emergency procedure.

FUEL PUMPS Switch.....5-Minutes Usage
 IGNITION Switch.....AS REQUIRED

LANDING LIGHT5-Minutes Usage

Prepare for landing with an inoperative landing light.

Flaps.....AS REQUIRED

Prepare to use FLAP SYSTEM MALFUNCTION checklist, Section 3.33 or LANDING WITHOUT FLAPS checklist, Section 3.25

LANDING GEAR.....AS REQUIRED

Prepare to use EMERGENCY LANDING GEAR EXTENSION checklist, Section 3.31.



THIS PAGE INTENTIONALLY LEFT BLANK

3.35 ELECTRICAL SYSTEM MALFUNCTIONS (Continued)

Complete Electrical Failure

Indication: PFDs, MFD and all equipment, less the Standby Attitude Gyro (if switch is ON), will be unpowered.

NOTE

If the EMER switch is not turned ON within one (1) second of the Complete Electrical Failure, the ADC 1 and AHRS 1 will require 45 seconds to realign.

STBY GYRO Switch.....VERIFY ON and FLAG IS PULLED ON GYRO

Maintain attitude control using standby instruments.

EMER Switch.....ON

BATTERY Switch.....OFF

GEN Switch.....OFF

ALT Switch.....OFF

AVIONICS Switch.....OFF

NOTE

Turning ON the EMER switch will activate the #1 PFD in Reversionary mode with AHRS 1 data, ADC 1 data, a subset of engine parameters, #1 Comm/Nav/GPS, Pilot's Audio Panel, Landing Gear Down Lights, internal lighting for the standby instruments and illumination of the magnetic compass.

Land as soon as possible.

NOTE

With a complete electrical failure, emergency landing gear extension and landing without flaps will be required. Refer to Emergency Landing Gear Extension (Section 3.31) and Landing Without Flaps (Section 3.25).

CAUTION

During operations on the emergency bus, BETA and REVERSE are not available.

3.36 AVIONICS SYSTEM FAILURES

NOTE

Images on the PFD and MFD displays may appear distorted when wearing polarized sunglasses.

3.36a Pilot's PFD Failure

Indication: PFD1 Display goes blank.

DISPLAY BACKUP button on pilot's audio panelPUSH
 XFR button on autopilotSELECT to PFD2
 XPDR2 SoftkeySELECT

Exit and avoid IFR and icing conditions as soon as practical.

NOTE

If the pilot's PFD fails, the MFD and the copilot's PFD will remain in normal mode. Pushing the DISPLAY BACKUP button on the pilot's audio panel allows the MFD to display AHRS and ADC information but lose certain map functions such as radar. The keypad must be used to perform typical PFD functions such as changing NAV and COM frequencies. The following features will become inoperative if there is a complete loss of PFD1/GIA1 functionality:

- Com 1/Nav 1
- Fuel Quantity
- #1 Transponder
- #1 GPS

3.36b MFD Failure

Indication: MFD Display goes blank.

DISPLAY BACKUP button on pilot's audio panelPUSH

Exit and avoid IFR and icing conditions as soon as practical.

NOTE

The pilot's PFD and co-pilot's PFD will revert to a reversionary mode display. The following features will become inoperative if there is a complete loss of MFD functionality:

- GDL 69 (Garmin Datalink - XM)
- GWX (Garmin Radar)

3.36c CoPilot's PFD Failure

Indication: PFD2 Display goes blank.

XFR button on autopilotSELECT to PFD1

XPDR1 SoftkeySELECT

Exit and avoid IFR and icing conditions as soon as practical.

NOTE

If the copilot's PFD fails, the MFD and pilot's PFD will remain in normal display format. The following features will become inoperative:

- | | |
|------------------|------------------|
| • Com 2/Nav 2 | • Traffic |
| • Stormscope | • ADF indication |
| • #2 Transponder | • DME indication |
| • #2 GPS | |

3.36 AVIONICS SYSTEM FAILURES (Continued)**3.36d Failure of the Attitude and Heading Reference System (AHRS)****AHRS 1 Total Failure****On Ground:**

Indication: HDG NO COMP, PIT NO COMP, ROL NO COMP white annunciations on PFD.

System Messages (MSG Softkey).....CONSIDER

AHRS 1 Circuit BreakerRESET

(Located on the pilot's aft circuit breaker panel, row C, position 6)

If AHRS 1 data still invalid:

AHRS 2 SENSOR Softkey.....SELECT

Avoid flight in IFR and icing conditions.

In Flight:

Indication: HDG NO COMP, PIT NO COMP, ROL NO COMP white annunciations and BOTH ON AHRS2 amber annunciation on PFD.

System Messages (MSG Softkey).....CONSIDER

AHRS 1 Circuit BreakerRESET

(Located on the pilot's aft circuit breaker panel, row C, position 6)

If AHRS 1 data still invalid:

AHRS 2 dataCROSSCHECK with STANDBY ATTITUDE
GYRO

Exit and avoid IFR and icing conditions as soon as practical.

NOTE

If AHRS 1 is still invalid, the autopilot will be inoperative.

NOTE

For partial AHRS failures, the system will not autorevert to the good AHRS but a red-x and amber text will appear over the affected parameter(s).

3.36 AVIONICS SYSTEM FAILURES (Continued)

**3.36d Failure of the Attitude and Heading Reference System (AHRS)
(continued)**

AHRS 2 Total Failure

On Ground:

**Indication: HDG NO COMP, PIT NO COMP, ROL NO COMP white
annunciations on PFD.**

System Messages (MSG Softkey).....CONSIDER
AHRS 2 Circuit BreakerRESET
(Located on the copilot's aft circuit breaker panel, row A, position 3)

If AHRS 2 data still invalid:

AHRS 1 SENSOR softkeySELECT
Avoid flight in IFR and icing conditions.

In Flight:

**Indication: HDG NO COMP, PIT NO COMP, ROL NO COMP white
annunciations and BOTH ON AHRS1 amber
annunciation on PFD.**

System Messages (MSG Softkey).....CONSIDER
AHRS 2 Circuit BreakerRESET
(Located on the copilot's aft circuit breaker panel, row A, position 3)

If AHRS 2 data still invalid:

AHRS 1 dataCROSSCHECK with STANDBY ATTITUDE
GYRO

Exit and avoid IFR and icing conditions as soon as practical.

NOTE

If AHRS 2 is still invalid, the autopilot will be inoperative.

NOTE

For partial AHRS failures, the system will not autorevert to the good AHRS but a red-x and amber text will appear over the affected parameter(s).



3.36 AVIONICS SYSTEM FAILURES (Continued)

3.36d Failure of the Attitude and Heading Reference System (AHRS) (continued)

AHRS 1 and AHRS 2 Total Failure

Indication (Ground and Flight): HDG NO COMP, PIT NO COMP, ROL NO COMP white annunciations and red-x's and amber failure text on all AHRS parameters.

Standby Attitude IndicatorVerify FLAG is pulled
Attitude.....Use standby attitude gyro
Heading.....Use magnetic compass
Course.....Set using digital window
System Messages (MSG Sofikey).....CONSIDER
If all AHRS data is still invalid
and time allows.....RESET both AHRS
Circuit Breakers

Land as soon as practical.

NOTE

For partial AHRS failures, a red-x and amber text will appear over the affected parameter(s).

3.36 AVIONICS SYSTEM FAILURES (Continued)**3.36e Air Data Computer (ADC) Failure****ADC 1 Total Failure****On Ground:**

Indication: ALT NO COMP, IAS NO COMP white annunciations on PFD.

System Messages (MSG Softkey).....CONSIDER

ADC 1 Circuit BreakerRESET

(Located on the pilot's aft circuit breaker panel, row C, position 5)

If ADC 1 data still invalid:

ADC 2 SENSOR softkey.....SELECT

Avoid flight in IFR and icing conditions.

In Flight:

Indication: ALT NO COMP, IAS NO COMP white annunciations and BOTH ON ADC 2 amber annunciation on PFD.

System Messages (MSG Softkey).....CONSIDER

ADC 1 Circuit BreakerRESET

(Located on the pilot's aft circuit breaker panel, row C, position 5)

If ADC 1 data still invalid:

ADC 2 data.....CROSSCHECK with STANDBY

AIRSPEED & ALTITUDE

Exit and avoid IFR and icing conditions as soon as practical.

NOTE

For partial ADC failures, the system will not autorevert to the good ADC but a red-x and amber text will appear over the affected parameter(s).

3.36 AVIONICS SYSTEM FAILURES (Continued)

3.36e Air Data Computer (ADC) Failure (continued)

ADC 2 Total FailureOn Ground:

Indication: ALT NO COMP, IAS NO COMP white annunciations on PFD.

System Messages (MSG Softkey)CONSIDER
 ADC 2 Circuit BreakerRESET
 (Located on the pilot's aft circuit breaker panel, row A, position 4)

If ADC 2 data still invalid:

ADC 1 SENSOR softkeySELECT
Avoid flight in IFR and icing conditions.

In Flight:

Indication: ALT NO COMP, IAS NO COMP white annunciations and BOTH ON ADC 1 amber annunciation on PFD.

System Messages (MSG Softkey)CONSIDER
 ADC 2 Circuit BreakerRESET
 (Located on the pilot's aft circuit breaker panel, row A, position 4)

If ADC 2 data still invalid:

ADC 1 dataCROSSCHECK with STANDBY
 AIRSPEED & ALTITUDE

Exit and avoid IFR and icing conditions as soon as practical.

NOTE

For partial ADC failures, the system will not autorevert to the good ADC but a red-x and amber text will appear over the affected parameter(s).

3.36 AVIONICS SYSTEM FAILURES (Continued)

3.36e Air Data Computer (ADC) Failure (continued)

ADC 1 and ADC 2 Failure

**Indication (Ground and Flight): ALT NO COMP, IAS NO COMP
white annunciations and red-x's and amber failure text on
all ADC parameters.**

System Messages (MSG Softkey).....CONSIDER
Airspeeduse Standby Airspeed Indicator
Altitudeuse Standby Altimeter
If all ADC data is still invalid
and time allowsRESET both AIR DATA
circuit breakers

Land as soon as practical.

NOTE

For partial ADC failures, the system will not autorevert to the good ADC but a red-x and amber text will appear over the affected parameter.

3.36 AVIONICS SYSTEM FAILURES (Continued)

3.36f Erroneous or Loss of Engine and Fuel Displays

Indication: Red-x over affected engine parameter or fuel display as erroneous indications.

NOTE

Erroneous information may be identified by indications which do not agree with other system information. Erroneous indications may be determined by comparing a display with other displays and other system information.

1. Set power based on throttle lever position, engine sound and speed.
2. Monitor other indications to determine the health of the engine.
3. Use known power settings and power setting tables for approximate fuel flow values.
4. Use other system information, such as annunciator messages, fuel totalizer quantity and flow, to safely complete the flight.

If ALL engine parameters are invalid and time allows:

GEA circuit breakerRESET
(Located on the pilot's aft circuit breaker panel, row C, position 1)

3.36g Erroneous or Loss of Warning/Caution CAS Messages

Indication: Displayed information shows an abnormal or emergency situation without the associated CAS message present.

NOTE

Loss of a CAS message may be indicated when engine or fuel displays show an abnormal or emergency situation and the CAS message is not present. An erroneous CAS message may be identified when a CAS message appears which does not agree with other displays or system information.

1. If a CAS message appears, treat it as if the condition exists.
2. If a display indicates an abnormal condition but no CAS message is present, use other system information, such as engine displays, fuel totalizer quantity and flow, to determine if the condition exists. If it cannot be determined that the condition does not exist, treat the situation as if the condition exists.

3.36 AVIONICS SYSTEM FAILURES (Continued)

3.36h Autopilot Malfunction

Indication: An unexpected roll or pitch deviation from the desired flight path, possible flight director commands deviations from desired aircraft attitudes and possible autopilot disconnect with red AFCS annunciation, amber or red AP annunciation on PFD.

- Control Wheel.....GRASP FIRMLY
- Attitude Indicators.....CROSSCHECK
- AP Disconnect/Trim Interrupt SwitchDEPRESS and HOLD
- Pitch Trim.....RETRIM if necessary
- Autopilot Circuit Breaker.....PULL
- Autopilot.....DO NOT RE-ENGAGE

3.36i Automatic Autopilot Disconnect

Indication: Flashing red and white AP on PFD and aural alert

- A/P DISC Switch.....DEPRESS and RELEASE
(cancels disconnect tone, and disconnects Autopilot and Yaw Damper)
- Pitch Trim.....RETRIM if necessary

NOTE

The autopilot disconnect may be accompanied by a red boxed AFCS, PTRM, PTCH (pitch) or ROL (roll) annunciation on the PFD, indicating the axis which has failed. The autopilot cannot be re-engaged with any of these annunciations present.

NOTE

Yaw Damper disengagement is indicated by a 5 second flashing amber "YD".



3.36 AVIONICS SYSTEM FAILURES (Continued)

3.36j Electric Trim Failure

Indication: Red boxed PTRM on PFD

NOTE

Loss of the electric pitch trim servo will not cause the autopilot to disconnect. Monitor pitch attitude for unusual behavior. Be alert to possible autopilot out-of-trim conditions (see AUTOPILOT OUT OF TRIM procedure this section) and expect residual control forces upon disconnect. The autopilot will not re-engage after disconnect with failed pitch trim.

AutopilotDISCONNECT

3.36k Electric Pitch Trim Runaway

Indication: An unexpected pitch deviation from the desired flight path and possible autopilot disconnect with red AFCS annunciation and amber or red AP annunciation.

NOTE

If the autopilot was not engaged when a pitch trim runaway occurs, there will be no related annunciation on the PFD.

Control WheelGRASP FIRMLY
Attitude IndicatorsCROSSCHECK
AP DISC SwitchDEPRESS and HOLD
PITCH TRIM Circuit BreakerPULL
Pitch TrimRETRIM MANUALLY

3.36 AVIONICS SYSTEM FAILURES (Continued)**3.36l Autopilot Overspeed Recovery****Indication:** Amber MAXSPD on PFD speedtape

This submode of the autopilot becomes active when the aircraft actual or projected airspeed exceeds V_{MO} . It remains active until the airspeed is reduced and V_{MO} exceedance is no longer a factor.

ThrottleREDUCE POWER as required
 AutopilotDISCONNECT if required

The pilot may elect to fly the aircraft and reduce airspeed.

NOTE

Overspeed recovery mode provides a pitch up command to decelerate the airplane below V_{MO} . Overspeed recovery is not active in altitude hold (ALT) or glideslope (GS) modes. The speed reference cannot be adjusted while in overspeed recovery mode.

3.36m Loss Of Navigation Information**Indication:** Amber VOR, VAPP, GPS, BC, LOC or GS flashing on PFD**NOTE**

If a navigation signal is lost while the autopilot is tracking it, the autopilot will roll the aircraft wings level and default to roll mode (ROL).

AutopilotSELECT ANOTHER LATERAL MODE
 Nav SourceSELECT A VALID NAV SOURCE
 AutopilotSELECT NAV

If on an instrument approach at the time the navigation signal is lost:

Missed ApproachEXECUTE
 (A second approach may be attempted using other nav aids.)

3.36 AVIONICS SYSTEM FAILURES (Continued)

3.36n Autopilot Out-Of-Trim

Indication: Amber RUD→, ←RUD, ←AIL, AIL→, ←ELE, or ←ELE on PFD

CAUTION

Do not attempt to overpower the autopilot in the event of a mistrim. The autopilot servos will oppose pilot input and will trim opposite the direction of pilot input (pitch axis only). This could lead to a significant out-of-trim condition. Disconnect the autopilot using the A/P DISC / TRIM INTER switch if manual control is desired.

If RUD→ or ←RUD annunciation.... adjust rudder trim.

NOTE

For aileron mistrims, ensure the slip/skid indicator is centered and observe the 125 pound maximum fuel imbalance limitation.

NOTE

Sustained elevator mistrims indicate a possible problem with the electric pitch trim system.

Control WheelGRASP FIRMLY with both hands

CAUTION

Be prepared to apply a sustained control force in the direction of the annunciation arrow. For example, an arrow pointing to the right with AIL annunciation indicates that sustained right wing down control wheel force will be required upon autopilot disconnect.

AP DISC SwitchDEPRESS
 Affected trim systemRETRIM
 AutopilotRE-ENGAGE if available

If the mistrim indication re-occurs, disconnect the autopilot for the remainder of the flight or until the offending condition is resolved.

3.36 AVIONICS SYSTEM FAILURES (Continued)**3.36o Abnormal Flight Director Mode Transitions**

Indication: Flashing lateral or vertical mode annunciations on PFD
NOTE

After 10 seconds, the new mode will be annunciated in green. Upon loss of a selected mode, the system will revert to the default mode for the affected axis, either ROL or PIT.

Loss of selected vertical mode (FLC, VS, ALT, GS)

Autopilot Mode ControlsSELECT ANOTHER VERTICAL MODE

If on an instrument approach:


AutopilotDISCONNECT (if coupled) and
continue manually or execute
missed approach

Loss of selected lateral mode (HDG, NAV, LOC, APP, BC)

Autopilot Mode ControlsSELECT ANOTHER LATERAL MODE

If on an instrument approach:

AutopilotDISCONNECT (if coupled) and
continue manually or execute
missed approach



3.36 AVIONICS SYSTEM FAILURES (Continued)

3.36p Failure of the Preflight Test

Indication: Red Boxed PFT on PFD

Autopilot Circuit Breaker.....PULL

NOTE

When the autopilot circuit breaker is pulled, the red PFT annunciation will be removed and the autopilot will be unavailable. Do not reset the circuit breaker unless the airplane is on the ground.

3.36q Loss of Cabin Altitude Display

Indication: Cabin Altitude Display on the MFD is Red X'd

Monitor cabin differential pressure for indications of pressurization system malfunction or loss of cabin pressure.

If an emergency descent is necessary, refer to paragraph 3.17, Emergency Descent - Maximum Rate.

3.36r Loss of Cabin Altitude Display and Cabin Differential Pressure Display

Indication: Cabin Altitude Display and Cabin Differential Pressure Display on the MFD are Red X'd

Descend to an altitude below which supplemental oxygen use would not be required in the event of a loss of cabin pressure.


If an emergency descent is necessary, refer to paragraph 3.17, Emergency Descent - Maximum Rate.

3.36s Dual GPS Failure

NavigationUse alternate source of navigation (ILS, LOC, VOR, DME, ADF)

If no alternate navigation sources are available:

Dead Reckoning (DR) Mode - Active when the airplane is greater than 30 NM from the destination airport.



3.36s Dual GPS Failure (Continued)

NavigationUse the airplane symbol and magenta course line on the MAP display.

WARNING

Information normally derived from GPS turns amber. Information will become more inaccurate over time.

WARNING

TAWS is Inoperative.

NOTE

DR mode uses heading, airspeed and last known GPS position to estimate the airplanes current position.

All maps with an airplane symbol show a ghosted airplane and a "DR" label.

Traffic Information System (TIS) is not dependent on GPS information. The position of displayed traffic relative to the airplane symbol on the map is still accurate.

Loss of Integrity (LOI) mode - Active when the airplane is within 30 NM of the destination airport (as calculated from the previews GPS or DR position).

NavigationFly towards known VMC. Use ATC or other information sources as possible.

NOTE

All information derived from GPS or DR is removed from the displays.

The airplane symbol is removed from all maps. The map will remain centered at the last known position.

"NO GPS POSITION" is shown in the center of the map.

TAWS and TIS are inoperative.

3.37 FUEL SYSTEM

Indication: Master Warning Indication; Red FUEL PRESS LOW message; Repeating aural chime.

PowerREDUCE

FUEL PUMPS SwitchMAN

Fuel Quantity and BalanceMONITOR

If fuel pressure annunciator remains illuminated, *land as soon as possible.*

If fuel pressure annunciator extinguishes, *land as soon as practical.*

Indication: Master Warning Indication; Red FUEL QTY LOW message; Repeating aural chime; Red fuel quantity low indication.

Land as soon as practical. Monitor fuel quantity. Total fuel quantity (Left and Right tanks) is less than or equal to 100 pounds.

Indication: Master Caution Indication; Amber FUEL QTY LOW message; single aural chime; Amber fuel quantity low indication.

Land as soon as practical. Monitor fuel quantity. Total fuel quantity (Left and Right tanks) is less than or equal to 180 pounds.

Indication: Master Caution Indication; Amber FUEL FILTER message; Single aural chime.

Land as soon as practical. Contaminated fuel or clogged filter is possible. Inspect filter after landing and repair prior to next flight.

3.37 FUEL SYSTEM (Continued)**CAUTION**

Maximum fuel imbalance is 125 pounds.

Indication: Master Warning Indication; Red FUEL IMBALANCE message; Repeating aural chime; Red fuel imbalance indication.

FUEL PUMPS SwitchMAN

If either white "L FUEL PUMP ON" or "R FUEL PUMP ON" message is **NOT** illuminated, turn the FUEL PUMPS Switch to OFF.

A red warning FUEL IMBALANCE message is displayed when the indicated imbalance has reached 125 pounds. Therefore, regardless of fuel quantity indication, *land as soon as possible*.

Indication: Master Caution Indication; Amber FUEL IMBALANCE message; Single aural chime; Amber fuel imbalance indication.

FUEL PUMPS SwitchVerify AUTO

Fuel PumpVerify white L or R FUEL PUMP ON
(High Fuel Side) message on MFD

Fuel QuantityMONITOR

NOTE

When Right and Left Fuel Quantity varies by more than 40 pounds, the amber FUEL IMBALANCE message will illuminate and the fuel pump from the high fuel side will turn on. Fuel pump activation is indicated by illumination of the white L or R FUEL PUMP ON message.

NOTE

When the FUEL PUMPS switch is in the MAN position, the white L and R FUEL PUMP ON messages are illuminated, indicating operation of the L and R fuel pumps.



3.37 FUEL SYSTEM (Continued)

Indication: White FUEL TEMP message. (Fuel temperature less than minimum fuel temperature limit of -34°C.)

Ground:

Do not start engine when fuel temperature is below -34°C.

Flight (Jet A -34°C, Jet A-1 -41°C):

Maintain fuel within fuel temperature limitations by changing altitude into warmer ambient OAT conditions.

Indication: Fuel temperature greater than maximum fuel temperature limit (+50°C).

Ground:

Do not start engine above +50°C Fuel Temperature.

Flight:

FUEL PUMPS SwitchMAN

Land as soon as practical.

Indication: Fuel temperature indicator blank/malfunctions.

Continue flight assuming OAT is equal to fuel temperature and maintain fuel temperatures within limits using OAT.

3.39 PRESSURIZATION / ENVIRONMENTAL SYSTEM MALFUNCTIONS

Fire / Smoke or Fumes in Cabin

If source is known:

- Oxygen Mask.....ON
- MIC SEL SwitchMSK

Extinguish fire using the hand held fire extinguisher located in the bottom drawer of the cabinet located behind the copilot’s seat.

If source is not known:

- Oxygen Mask.....ON
- MIC SEL SwitchMSK
- ECS CABIN COMFORT SwitchOFF
- BLEED AIR LeverPULL OUT (Closed)
- Cabin Pressure DUMP SwitchDUMP
- Cabin Fan Switch (as required).....LO or HI



**3.39 PRESSURIZATION / ENVIRONMENTAL SYSTEM
MALFUNCTIONS (Continued)**

Cabin Altitude Above 10,000 feet

Indication: Master Caution Indication; Amber CABIN ALT 10000 message; Repeating aural chime; Amber cabin altitude indication.

Cabin Altitude.....MONITOR

Cabin Altitude Above 12,000 feet

Indication: Master Warning Indication; Red CABIN ALT 12000 message; Repeating aural chime; Red cabin altitude indication.

Oxygen Mask.....ON

MIC SEL SwitchMSK

ECS CABIN COMFORT Switch.....Verify NORM
or HIGH selected

BLEED AIR LeverVerify IN (open)

CABIN ALT MUTE Switch.....PRESS

Descend as soon as practical.

3.39 PRESSURIZATION / ENVIRONMENTAL SYSTEM MALFUNCTIONS (Continued)

Emergency Pressurization

Indication: White EMER BLEED ON message.

Automatic Operation:

Oxygen Mask.....ON
 MIC SEL SwitchMSK
 ECS CABIN COMFORT SwitchNORM or HIGH
 Activation at 12,000 +/- 500 feet cabin altitude.

NOTE

Emergency pressurization will activate as the cabin altitude approaches 12,000 feet and will deactivate as the cabin altitude approaches 11,000 feet. This cycling can be eliminated by rotating the ECS CABIN COMFORT switch to the EMER position.

Manual Operation:

ECS CABIN COMFORT Switch.....EMER
 Cabin Altitude.....MONITOR

Descend as soon as practical.

3.39 PRESSURIZATION / ENVIRONMENTAL SYSTEM MALFUNCTIONS (Continued)

Bleed Overtemperature

Indication: Master Warning Indication; Red BLEED OVERTEMP message; Repeating aural chime.

POWER LeverREDUCE
Climate ControlSELECT LOWER TEMP.

If message remains illuminated:

Oxygen MaskON
MIC SEL SwitchMSK
ECS CABIN COMFORT SwitchOFF
BLEED AIR LeverPULL OUT (closed)

Descend and land as soon as practical.

Overpressurization

Indication: Master Warning Indication; Red CABIN DIFF PRESS message; Repeating aural chime.

Cabin ControllerSET TO HIGHER ALTITUDE
Cabin Rate ControlINCREASE TO MAXIMUM

Continued increase in differential pressure above 5.5 psi:

Oxygen MaskON
MIC SEL SwitchMSK
ECS CABIN COMFORT SwitchOFF
BLEED AIR LeverPULL OUT (closed)

If overpressurization continues:

Cabin Pressure DUMP SwitchDUMP
Emergency DescentACCOMPLISH PER
SECTION 3.17

3.39 PRESSURIZATION / ENVIRONMENTAL SYSTEM MALFUNCTIONS (Continued)

Rapid or Explosive Decompression

Oxygen Mask.....ON
MIC SEL SwitchMSK

If increase in cabin altitude is explosive:

Emergency Descent.....ACCOMPLISH PER
SECTION 3.17

If increase in cabin altitude is rapid and cabin altitude has not exceeded 14,000 feet (time permitting):

Cabin Controller.....SET TO LOWER ALTITUDE
Cabin Rate Control.....INCREASE TO MAXIMUM
ECS CABIN COMFORT Switch.....HIGH

If cabin altitude exceeds 14,000 feet:

Emergency Descent.....ACCOMPLISH PER
SECTION 3.17

3.40 EMERGENCY EXIT

Exit.....LOCATE
(second window from front on right side)

NOTE

The cabin must be depressurized before attempting to open the emergency exit.

Plexiglas Cover.....REMOVE
Handle.....PULL
Emergency Exit Window.....PULL IN

3.41 VACUUM SYSTEM FAILURE

Indication: Master Caution Indication; Amber VACUUM LOW message; Single aural chime; Amber vacuum indication.

Vacuum gaugeCHECK - WITHIN NORMAL OPERATING RANGE

Monitor vacuum gauge. Low vacuum may lead to improper operation of the wing and empennage deice boots and malfunction of the cabin pressurization. Monitor cabin altitude.

If message remains illuminated, Exit and Avoid IFR and icing conditions.

Before landing, verify cabin is depressurized. If not depressurized:

ECS CABIN COMFORT SwitchOFF

BLEED AIR LeverPULL OUT (closed)

Pressurization.....VERIFY ZERO DIFFERENTIAL PRESSURE

CAUTION

If de-ice boot are not fully deflated, stall speeds will be increased by approximately 5 KIAS.

3.43 ANTI-ICE / DE-ICE SYSTEM MALFUNCTIONS

3.43a Left Pitot Heat Failure

Indication: Master Caution Indication; Amber L PITOT HT FAIL message; Single aural chime.

NOTE

Failure of the L Pitot Heat could cause erroneous indications of pilot's airspeed and standby airspeed. Airspeeds on each PFD should be compared for accuracy.

L PITOT HEAT Circuit BreakerRESET
(Located on the pilot's aft circuit breaker panel, row A, position 2.)

If IAS MISCOMPARE

annunciation illuminatedSELECT GOOD ADC

Exit and avoid IFR and icing conditions and consider terminating flight early due to possible loss of airspeed redundancy.

3.43 ANTI-ICE / DE-ICE SYSTEM MALFUNCTIONS (Continued)**3.43b Right Pitot Heat Failure**

Indication: Master Caution Indication; Amber R PITOT HT FAIL message; Single aural chime.

NOTE

Failure of the R Pitot Heat could cause erroneous indications of copilot's airspeed. Airspeeds on each PFD should be compared for accuracy.

R PITOT HEAT Circuit BreakerRESET

(Located on the pilot's aft circuit breaker panel, row A, position 3.)

If IAS MISCOMPARE

annunciation illuminatedSELECT GOOD ADC

3.43c Both Left and Right Pitot Heat Failure

Indication: Master Warning Indication; Red L PITOT HT FAIL and red R PITOT HT FAIL messages; Repeating aural chime.

NOTE

Failure of both left and right pitot heaters could cause erroneous pilot, copilot and/or standby airspeed indications. Monitor pilot and copilot airspeeds. In the event of complete loss of airspeed, maintain safe airspeed by use of throttle, engine settings and airframe sensory cues.

L PITOT HEAT Circuit BreakerRESET

(Located on the pilot's aft circuit breaker panel, row A, position 2.)

R PITOT HEAT Circuit BreakerRESET

(Located on the pilot's aft circuit breaker panel, row A, position 3.)

If either circuit breaker opens again, do not reset.

Exit and avoid IFR and icing conditions and consider terminating flight early due to possible loss of airspeed redundancy.

3.43 ANTI-ICE / DE-ICE SYSTEM MALFUNCTIONS

(Continued)

3.43d Pitot Heat Off

Indication: Master Caution Indication; Amber PITOT HEAT OFF message.

PITOT HEAT Switch.....Select ON

3.43e Prop Heat Failure

In Flight:

Indication: Master Warning Indication; Red PROP HEAT FAIL message; Repeating aural chime.

PROP HEAT Circuit BreakerCHECK IN
(Located on the pilot's aft circuit breaker panel, row A, position 4.)

If PROP HEAT Circuit Breaker was closed (not out):

PROP HEAT SwitchCycle OFF then ON

If message remains illuminated, Exit and Avoid icing conditions.

On Ground:

Indication: Amber Caution Indication; Amber PROP HEAT FAIL message; Single aural chime.

Flight in icing conditions is prohibited.



3.43 ANTI-ICE / DE-ICE SYSTEM MALFUNCTIONS

(Continued)

3.43f Windshield Over Temp

Indication: Master Warning Indication; Red WNDSHLD OVRTEMP message; Repeating aural chime.

NOTE

During high ambient temperature conditions when switching windshield heat from ANTI ICE to DEFOG, the red WNDSHLD OVRTEMP message may illuminate and remain illuminated until the windshield surface temperature cools to the DEFOG heat temperature range.

WINDSHLD HT Switch.....OFF

If Windshield Over Temp Annunciator extinguishes:

WINDSHLD HT Switch.....DEFOG

If Windshield Over Temp Annunciator remains illuminated:

WINDSHLD HT Switch.....OFF

WINDSHIELD HEAT Circuit Breakers (2)PULL

(Located on the pilot's aft circuit breaker panel, row A, positions 7, 8.)

Exit and avoid IFR and icing conditions and conditions where windshield heat may be necessary.

3.43g Surface De-ice Failure

In Flight:

Indication: Master Warning Indication; Red SURF DE-ICE FAIL message; Repeating aural chime.

SURFACE DE-ICE Circuit BreakerRESET

(Located on the pilot's aft circuit breaker panel, row A, position 6.)

If message remains illuminated, Exit and Avoid icing conditions.

On Ground:

Indication: Master Caution Indication; Amber SURF DE-ICE FAIL message; Single aural chime.

Flight in icing conditions is prohibited.

3.43 ANTI-ICE / DE-ICE SYSTEM MALFUNCTIONS

(Continued)

3.43h Stall Warning Fail

Indication: Master Caution Indication; Amber STALL WARN FAIL message; Single aural chime.

STALL WARN Circuit BreakerRESET

(Located on the pilot's forward circuit breaker panel, row C, position 5.)

Avoid low airspeeds and monitor approach speeds closely.

If message remains illuminated, Exit and Avoid icing conditions.

3.45 DOOR AJAR

On the Ground:

Indication: White DOOR AJAR message.

Door LatchingCHECK AND VERIFY
4 GREEN INDICATORS

In Flight:

Indication: Master Warning Indication; Red DOOR AJAR message; Repeating aural chime.

Ensure all occupants are seated with seat belts on.

Remain clear of the door.

Reduce cabin pressurization.

Reduce airspeed.

Land as soon as practical.

3.47 STANDBY ATTITUDE INDICATOR BATTERY HEATER FAIL

Indication: Master Caution Indication; Amber STBY BAT HT FAIL message; Single aural chime.

STBY GYRO TEST SwitchHOLD IN TEST POSITION
(Minimum 5 seconds to
complete self test)

Monitor MFD for STBY BAT TEST OK message.

If STBY BAT TEST OK message does not illuminate, exit and avoid Instrument Meteorological Conditions (IMC).

3.49 OXYGEN**In Flight:**

Indication: Master Caution Indication; Amber OXYGEN message; Single aural chime.

Indicates one or more of the passenger oxygen cannisters is in use or is expended.

Descend to altitude where supplemental oxygen is not required.

On Ground:

Indication: White OXYGEN message on MFD.

Indicates one or more of the passenger oxygen cannisters is in use or is expended.

If the oxygen system is not working properly, have the condition corrected before flight where oxygen may be required to cover the case of a cabin depressurization.

3.51 SPIN RECOVERY

Rudder	FULL OPPOSITE TO DIRECTION OF ROTATION
Control Wheel	FULL FORWARD WHILE NEUTRALIZING AILERONS
Throttle.....	CLOSED
Rudder (when rotation stops)	NEUTRAL
Control Wheel.....	AS REQUIRED TO SMOOTHLY REGAIN LEVEL FLIGHT ATTITUDE

3.53 ICING (Reference Section 9, Supplements, for Meridian Aircraft Flight Into Known Icing (FIKI))

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS
SECTION 4
NORMAL PROCEDURES

Paragraph No.		Page No.
4.1	General	4-1
4.3	Airspeeds for Safe Operations	4-3
4.5	NORMAL PROCEDURES CHECKLIST	4-4
4.5a	Preflight Checklist (4.9)	4-4
4.5b	Before Starting Engine Checklist (4.11)	4-9
4.5c	Engine Start Checklist (4.13)	4-11
	Engine Start - Using Airplane Battery (4.13a)	4-11
	Engine Start (Manual Mode) - Using Airplane Battery (4.13b)	4-12
	Engine Start - Using External Power (4.13c)	4-13
4.5d	Engine Dry Motoring Run (4.15)	4-14
4.5e	Before Taxiing (4.17)	4-14
4.5f	Taxiing (4.19)	4-15
4.5g	Engine Run Up (4.21)	4-16
4.5h	Before Takeoff (4.23)	4-17
4.5i	Takeoff (4.25)	4-18
	Normal Takeoff - 0° Flaps (4.25a)	4-18
	Short Field Takeoff - 20° Flaps (4.25b)	4-19
4.5j	Maximum Continuous Power Climb (4.27a)	4-19
4.5k	Cruise Climb (4.27b)	4-20
4.5l	Cruise (4.29)	4-20
4.5m	Flight in Icing Conditions (4.31)	4-21
4.5n	Descent (4.33)	4-22
4.5o	Before Landing (4.35)	4-23

TABLE OF CONTENTS (CONT'D)

SECTION 4

NORMAL PROCEDURES

Paragraph No.		Page No.
4.5p	Landing (4.37)	4-24
4.5q	Balked Landing (Go-Around) (4.39)	4-24
4.5r	After Landing (4.41)	4-25
4.5s	Shutdown (4.43)	4-26
4.7	AMPLIFIED NORMAL PROCEDURES	4-27
4.9	Preflight Check (4.5a)	4-27
4.11	Before Starting Engine (4.5b)	4-32
4.13	Engine Start (4.5c)	4-34
4.13a	Engine Start - Using Airplane Battery (4.5c)	4-34
4.13b	Engine Start (Manual Mode) - Using Airplane Battery (4.5c)	4-35
4.13c	Engine Start - Using External Power (4.5c)	4-36
4.15	Dry Motoring Run (4.5d)	4-37
4.17	Before Taxiing (4.5e)	4-38
4.19	Taxiing (4.5f)	4-39
4.21	Engine Run up (4.5g)	4-39
4.23	Before Takeoff (4.5h)	4-40
4.25	Takeoff (4.5i)	4-41
4.25a	Normal Takeoff - 0° Flaps (4.5i)	4-42
4.25b	Short Field Takeoff Performance - 20° Flaps (4.5i)	4-42
4.27	Climb (4.5j)	4-43
4.27a	Maximum Continuous Power Climb (4.5j)	4-43
4.27b	Cruise Climb (4.5k)	4-43
4.29	Cruise (4.5l)	4-43

TABLE OF CONTENTS (CONT'D)

SECTION 4

NORMAL PROCEDURES

Paragraph No.		Page No.
4.31	Flight in Icing Conditions (4.5m)	4-44
4.33	Descent (4.5n)	4-44
4.35	Before Landing (4.5o)	4-45
4.35a	Approach Check (4.5o)	4-45
4.35b	Landing Check (4.5o)	4-45
4.37	Landing (4.5p)	4-46
4.37a	Normal Technique (4.5p)	4-46
4.37b	Short Field Technique (4.5p)	4-46
4.39	Balked Landing - Go Around (4.5q)	4-46
4.41	After Landing (4.5r)	4-47
4.43	Shutdown (4.5s)	4-47
4.45	Stalls	4-48
4.47	Turbulent Air Operation	4-48
4.49	Cabin Pressurization	4-48
4.51	Cabin Climate Control Panel Operation	4-50
4.51a	Cabin Climate Control Panel Controls and Switches	4-50
4.51b	Auto Temp Operation	4-50
4.51c	Manual Temp Operation	4-51
4.51d	Maximum Cabin Cooling	4-51
4.53	Noise Level	4-52
4.55	Reserved	4-52
4.57	High Altitude Operation	4-53

THIS PAGE INTENTIONALLY LEFT BLANK

SECTION 4**NORMAL PROCEDURES****4.1 GENERAL**

This section provides the normal operating procedures for the PA-46-500TP, Meridian airplane. All of the normal operating procedures required by the FAA are presented as well as those procedures which have been determined as necessary for the operation of the airplane, as determined by the operating and designed features of the airplane, are presented.

Normal operating procedures associated with optional systems and equipment which require handbook supplements are presented in Section 9, Supplements.

These procedures are provided to supply information on procedures which are not the same for all airplanes and as a source of reference and review. Pilots should familiarize themselves with these procedures to become proficient in the normal operation of the airplane.

This section is divided into two parts. The first part provides the Normal Procedures Checklists. These checklists supply an action - reaction sequence for normal operating procedures. Numbers in parentheses after each checklist section indicate the paragraph where the corresponding amplified procedure can be found.

The second part of this section contains the amplified normal procedures which provide additional detailed information and explanations of the procedures and how to perform them. The short form checklists should be used on the ground and in flight. Numbers in parentheses after each paragraph title indicate where the corresponding checklist can be found.

CAUTION

Pilots who fly at high altitude must be aware of the physiological problems associated with prolonged flight at such altitudes. Dehydration and the onset of hypoxia may occur in the passengers and crew.

Passenger comfort may be increased by an occasional intake of fluids. Prolonged high altitude flights require warm clothing and monitoring of the cabin temperature and the physical state of the crew and passengers.

THIS PAGE INTENTIONALLY LEFT BLANK

4.3 AIRSPEEDS FOR SAFE OPERATIONS

The following airspeeds are those which are significant to the safe operation of the airplane. These figures are for standard airplanes flown at maximum weight under standard sea level conditions.

Performance for a specific airplane may vary from published figures depending upon the equipment installed, the condition of the engine, airplane and equipment, atmospheric conditions and piloting technique.

Best Rate of Climb Speed (V_y)	125 KIAS
Best Angle of Climb Speed (V_x)	95 KIAS
Maximum Operating Maneuvering Speed (V_0)	127 KIAS
Landing Final Approach Speed (Full Flaps)	85 KIAS
Maximum Demonstrated Crosswind Velocity	17 KTS
Maximum Flaps Extended Speed	
10°	168 KIAS
20°	135 KIAS
Full Flaps (36°)	118 KIAS
Airspeeds for Autopilot Operation	90 - 175 KIAS
Minimum Airspeed for Autopilot Coupled Approach	100 KIAS

4.5a Preflight Checklist (4.9) (Continued)


**WALK-AROUND**

Figure 4-1

EMPENNAGE (4.9b)

Primary and Pressurization Static Ports	CLEAR
Left Alternate Static Port	CLEAR
Storage Compartment Door	CLOSE / SECURE
EPU Access Door	CLOSED
Antennas (Upper and Lower)	CHECK
Surface Condition	CLEAR OF ICE, FROST, SNOW
Deice Boots (Stabilizer and Rudder)	CHECK
Elevator and Elevator Trim Tab	CHECK
Vortex Generators	CHECK

CAUTION

During the preflight inspection, if a total of more than 5 vortex generators are damaged or missing, the aircraft is not airworthy.

Rudder	CHECK
Rudder Trim Tab	CHECK
Static Wicks (11)	CHECK
Tie Down	REMOVE
Right Alternate Static Port	CLEAR

4.5a Preflight Checklist (4.9) (Continued)

RIGHT WING (4.9c)

Surface Condition	CLEAR OF ICE, FROST, SNOW
Flap and Hinges	CHECK
Aileron and Hinges	CHECK
Static Wicks (3)	CHECK
Wing Tip and Lights	CHECK
Fuel Tank Vent	CLEAR
Fuel Tank and Filler Cap	CHECK supply visually - SECURE CAP
Deice Boot	CHECK
Stall Strips	CHECK
Vortex Generators	CHECK

CAUTION

During the preflight inspection, if a total of more than 5 vortex generators are damaged or missing, the aircraft is not airworthy.

Radar Pod and Storage Door.....	CHECK / SECURE
OAT Probes	CHECK
Pitot Head.....	REMOVE COVER and CHECK for OBSTRUCTIONS
Tie Down and Chock.....	REMOVE
Main Gear Strut.....	PROPER INFLATION - approx. 3 in. (8 cm)
Gear Door	CHECK
Tire	CHECK
Brake Block and Disc.....	CHECK

4.5a Preflight Checklist (4.9) (Continued)**NOSE SECTION (4.9d)**

General Condition and Cowling Fasteners.....	CHECK
Right Cowl Door.....	OPEN - CHECK GENERAL CONDITION - SECURE DOOR
Air Outlet and Exhaust Covers.....	REMOVE
Generator / Alternator Cooling Air Inlet.....	CLEAR
Exhaust Stacks.....	CHECK
Forward Upper Cowling.....	HORIZONTAL LATCH SLOTS ALIGNED and PINS EXTENDED
Fuel Sumps (2).....	DRAIN and CHECK for water, sediment and proper fuel
Air Inlets.....	CLEAR
Propeller Spinner.....	CHECK
Propeller.....	CHECK for nicks and general condition, ROTATE PROPELLER - listen for noise, check for binding
Landing Light.....	CHECK
Chock.....	REMOVE
Nose Gear Strut.....	PROPER INFLATION - approx. 2.7 in. (6.8 cm)
Nose Tire.....	CHECK
Gear Doors.....	CHECK
Fuel Sumps (3).....	DRAIN and CHECK for water, sediment and proper fuel
Forward Upper Cowling.....	HORIZONTAL LATCH SLOTS ALIGNED and PINS EXTENDED
Left Cowl Door.....	OPEN and CHECK OIL LEVEL
Oil Filler Cap.....	VERIFY FULLY CLOSED
Alternator and Aircond Compressor Belts.....	CHECK FOR TENSION and EXCESSIVE WEAR
Brake Fluid Reservoir Cap.....	VERIFY CLOSED
Left Cowl Door.....	CLOSED and SECURE

4.5a Preflight Checklist (4.9)(Continued)

LEFT WING (4.9e)

Surface Condition	CLEAR OF ICE, FROST, SNOW
Main Gear Strut.....	PROPER INFLATION - approx. 3 in. (8 cm)
Gear Door	CHECK
Tire	CHECK
Brake Block and Disc.....	CHECK
Tie Down and Chock.....	REMOVE
Pitot Head.....	CHECK
Deice Boot	CHECK
Stall Strips	CHECK
Vortex Generators.....	CHECK

CAUTION

During the preflight inspection, if a total of more than 5 vortex generators are damaged or missing, the aircraft is not airworthy.

Stall Warning Vane	CHECK
Fuel Tank and Filler Cap	CHECK supply visually - SECURE CAP
Fuel Tank Vent	CLEAR
Wing Tip and Lights	CHECK
Static Wicks (3)	CHECK
Aileron and Hinges	CHECK
Flap and Hinges	CHECK

4.5b Before Starting Engine Checklist (4.11) (Continued)**BEFORE STARTING ENGINE (4.11) (Continued)**

LTS/GEAR ANNUN TEST SwitchPRESS and HOLD
 Verify switches adjacent to pilot's
 PFD and GEAR WARNING
 annunciator illuminate

GEAR WARN MUTE Switch.....PRESS
 Verify gear horn silences
 and switch illuminates

MIC SEL (BOM/MSK) Switch.....BOM (Boom)

Alternate Static SourceCHECK PRIMARY POSITION

Pitot and Static Drains (5)PUSH to drain

Fuel Gauges.....CHECK QUANTITY & IMBALANCE

OAT.....VERIFY WITHIN LIMITS

Fuel TemperatureVERIFY WITHIN LIMITS

FIRE DET TEST.....PRESS
 Verify ENGINE FIRE CAS message

CAS Messages.....CONSIDER ANY ILLUMINATED

PFD Annunciations.....CONSIDER ANY ILLUMINATED

Proceed with appropriate Engine Start Checklist.

4.5c Engine Start Checklist (4.13)**ENGINE START - USING AIRPLANE BATTERY (4.13a)**

BATTERY VoltageCHECK 24 to 26 VOLTS

NOTE

Allow G1000 avionics to initialize and display CAS messages prior to initiating an engine Auto Start sequence. Starting the engine prior to display of G1000 CAS messages will result in disruption of the auto start sequence possibly resulting in an engine overtemp condition.

NOTE

For warm weather operation engine starts may be attempted with a battery voltage of 23.5 volts minimum. Observe the engine start ITT limitation, Ng minimum speed of 13% and ensure combustion occurs within 10 seconds after moving the condition lever to run. Failure to observe these limitations can result in damage to the engine.

FUEL PUMPS SwitchMAN
 L and R FUEL PUMP ON Annunciators.....ILLUMINATED
 IGNITION SwitchMAN
 IGNITION ON AnnunciatorILLUMINATED
 Prop AreaCLEAR
 START MODE SwitchAUTO (Light in Switch Extinguished)
 PUSH START SwitchLIFT COVER/PUSH
 Oil PressureCHECK RISING
 Ng (min. 13%).....STABILIZED
 CONDITION LeverRUN
 ITTMAX. 1000°C LIMITED TO 5 SEC.

4.5c Engine Start Checklist (4.13) (Continued)

ENGINE START - USING AIRPLANE BATTERY (4.13a) (Continued)

If combustion is not initiated within 10 sec. of moving Condition Lever to Run then:

- CONDITION Lever.....CUT-OFF/FEATHER
- START MODE Switch.....PUSH MAN/STOP
- Allow minimum of 30 seconds fuel draining period, then refer to DRY MOTORING RUN (4.5 d)

Starter @ 56% Ng.....Verify STARTER ENGAGED
message extinguished (If not - PUSH
START MODE MAN/STOP SWITCH)

NgSTABLE above 60%

NpVERIFY 1200 RPM MINIMUM

GEN Switch.....ON/CHECK POSITIVE AMPS/28 VOLTS/
GENERATOR OFF message extinguished

ALT SwitchON/ALTERNATOR OFF message extinguished

FUEL PUMPS SwitchAUTO

IGNITION SwitchOFF

Oil PressureCHECK (Min. 60 PSI)

ENGINE START (MANUAL MODE) - USING AIRPLANE BATTERY (4.13b)

BATTERY VoltageCHECK 24 to 26 VOLTS

NOTE

For warm weather operation engine starts may be attempted with a battery voltage of 23.5 volts minimum. Observe the engine start ITT limitation, Ng minimum speed of 13% and ensure combustion occurs within 10 seconds after moving the condition lever to run. Failure to observe these limitations can result in damage to the engine.

4.5c Engine Start Checklist (4.13) (Continued)**ENGINE START (MANUAL MODE) - USING AIRPLANE BATTERY
(4.13b) (Continued)**

FUEL PUMPS Switch	MAN
L and R FUEL PUMP ON Annunciators.....	ILLUMINATED
IGNITION Switch	MAN
IGNITION ON Annunciator	ILLUMINATED
Prop Area	CLEAR
START MODE Switch	MAN (Light in Switch Illuminated)
PUSH START Switch	LIFT COVER/PRESS & HOLD
Oil Pressure.....	CHECK RISING
Ng (min. 13%).....	STABILIZED
CONDITION Lever.....	RUN
ITT	MAX. 1000°C LIMITED TO 5 SEC.

4.5c Engine Start Checklist (4.13) (Continued)

**ENGINE START (MANUAL MODE) - USING AIRPLANE BATTERY
(4.13b) (Continued)**

If combustion is not initiated within 10 sec. of moving Condition Lever to Run then:

- a. CONDITION Lever.....CUT-OFF/FEATHER
- b. START MODE SwitchRELEASE
- c. Allow minimum of 30 seconds fuel draining period, then refer to DRY MOTORING RUN (4.5 d)

PUSH START Switch @ 56% NgRELEASE and verify STARTER ENGAGED message extinguished

NgSTABLE above 60%

NpVERIFY 1200 RPM MINIMUM

GEN Switch.....ON/CHECK POSITIVE AMPS/28 VOLTS/
GENERATOR OFF message extinguished

ALT SwitchON/ALTERNATOR OFF message extinguished

FUEL PUMPS SwitchAUTO

IGNITION SwitchOFF

Oil PressureCHECK (Min. 60 PSI)

ENGINE START - USING EXTERNAL POWER (4.13c)

BATTERY SwitchVerify OFF

External Power Unit.....CONNECT

NOTE

Allow G1000 avionics to initialize and display CAS messages prior to initiating an engine Auto Start sequence. Starting the engine prior to display of G1000 CAS messages will result in disruption of the auto start sequence possibly resulting in an engine overtemp condition.

NOTE

For engine starting, the external power source must be capable of providing 24 to 29 Volts and 1200 Amps.

4.5c Engine Start Checklist (4.13) (Continued)

ENGINE START - USING EXTERNAL POWER (4.13c) (Continued)

VoltmeterCHECK STABLE 24 to 29 VOLTS
 FUEL PUMPS SwitchMAN
 L and R FUEL PUMP ON Annunciators.....ILLUMINATED
 IGNITION SwitchMAN
 IGNITION ON AnnunciatorILLUMINATED
 Prop AreaCLEAR
 START MODE SwitchAUTO (Light in Switch Extinguished)
 PUSH START SwitchLIFT COVER/PUSH
 Oil PressureCHECK RISING
 Ng (min. 13%).....STABILIZED
 CONDITION LeverRUN
 ITTMAX. 1000°C LIMITED TO 5 SEC.

If combustion is not initiated within 10 sec. of moving Condition Lever to Run then:

- a. CONDITION Lever.....CUT-OFF/FEATHER
- b. START MODE Switch.....PUSH MAN/STOP
- c. Allow minimum of 30 seconds fuel draining period, then refer to DRY MOTORING RUN (4.5 d)

Starter @ 56% Ng.....Verify STARTER ENGAGED
 message extinguished (If not - PUSH
 START MODE MAN/STOP SWITCH)

NgSTABLE above 60%
 NpVERIFY 1200 RPM MINIMUM
 FUEL PUMPS SwitchAUTO
 IGNITION SwitchOFF
 Oil PressureCHECK (Min. 60 PSI)
 BATTERY SwitchON
 External Power UnitDISCONNECT
 GEN Switch.....ON/CHECK POSITIVE AMPS/28 VOLTS/
 GENERATOR OFF message extinguished
 ALT SwitchON/ALTERNATOR OFF message extinguished

4.5d ENGINE DRY MOTORING RUN (4.15)

Allow minimum of 30 seconds fuel draining period, then:

POWER Lever	IDLE
CONDITION Lever	CUT-OFF/FEATHER
FUEL PUMPS Switch	OFF
IGNITION Switch	OFF
BATTERY Switch	ON
START MODE Switch	MAN (Switch Light Illuminated)
PUSH START Switch	PUSH and HOLD (15 SEC.)
PUSH START Switch.....	RELEASE

NOTE

Observe starter cooling limits (Section 2, Paragraph 2.9).

4.5e BEFORE TAXIING (4.17)

AVIONICS Switch	ON
Multi-Function Display (MFD).....	VERIFY DATABASE CURRENCY
MFD - Weight Planning	ENTER WEIGHTS AS REQUIRED
Fuel Totalizer (Weight)	FOB SYNC or ENTER MANUALLY
CAS Messages	CONSIDER ANY MESSAGES ILLUMINATED
Autopilot	Verify Preflight Self-Test (PFT) completed and Disconnect Tone heard
PITOT HEAT Switch.....	ON, CHECK OPERATION (Amber PITOT HEAT OFF annunciator extinguished. Monitor volt/ammeter.)
PITOT HEAT Switch.....	OFF
TAXI/REC LT Switch.....	AS REQUIRED
NAV and STROBE LIGHT Switches.....	AS REQUIRED
Cabin Climate Controls	AS REQUIRED
Radios/Avionics	CHECK/SELF-TEST
Flaps	VERIFY RETRACTED
Elevator Trim.....	SET IN TAKEOFF RANGE
Rudder Trim	SET 2° To 3° RT

4.5e BEFORE TAXIING (4.17) (Continued)

BLEED AIR Lever.....PUSH IN (on)
 Cabin Pressure DUMP Switch.....VERIFY POSITION
 ECS CABIN COMFORT Switch.....NORM
 STALL TEST Switch.....PRESS TO TEST
 Pressurization Control.....SET

NOTE

Maximum cooling on the ground may be achieved by operating with the BLEED AIR lever in the OUT (closed) position and the ECS CABIN COMFORT control selected OFF.

STBY GYRO TEST.....PRESS TO TEST
 (verify STBY BAT TEST OK
 message)/ON
 STBY GYRO.....ON
 Altimeter/Standby Altimeter.....SET
 TAWS and TRAFFIC (if installed).....TEST as required
 PARK BRAKE.....RELEASE

4.5f TAXIING (4.19)


Taxi Area.....CLEAR
 POWER Lever.....ADVANCE SLOWLY
 Brakes.....CHECK
 Steering.....CHECK
 Flight Instruments.....CHECK

WARNING

Propeller operation below 1200 rpm is prohibited.

NOTE

BETA range (aft of IDLE detent) may be used during taxi to control taxi speed and reduce wear on brakes.



4.5g ENGINE RUN UP (4.21)

PARK BRAKE.....SET
 POWER Lever 1900 RPM
 OVERSPEED GOV TEST Switch.....LIFT COVER/PUSH and HOLD
 NPOBSERVE APPROX. 60 RPM DROP
 Overspeed Governor Test SwitchRELEASE
 Np.....RETURN TO 1900 RPM
 POWER LeverIDLE
 REVERSE LOCK OUT SwitchPUSH and HOLD (Min. 5 sec.)
 POWER Lever.....LIFT and RETARD TOWARDS REVERSE
 Beta and Prop ReverseNOT ATTAINABLE
 REVERSE LOCK OUT Switch.....RELEASE, POWER LEVER CAN
 BE MOVED TOWARDS REVERSE
 POWER LeverIDLE
 GEN SwitchOFF (verify alternator picks up load
 and white GENERATOR OFF message
 is illuminated)
 GEN SwitchON (white GENERATOR OFF
 message extinguished)
 ALT Switch.....OFF (white ALTERNATOR OFF
 message illuminated)
 ALT SwitchON (white ALTERNATOR OFF
 message extinguished)
 Quadrant FRICTION Lock.....SET

NOTE

Refer to Section 9, Supplements, for Meridian Aircraft Flight Into Known Icing (FIKI), prior to any flight operations (takeoff, cruise, landing, etc.) in icing conditions.

4.5h BEFORE TAKEOFF (4.23)

Seat Backs	ERECT
Seats	ADJUSTED & LOCKED IN POSITION
Armrests	STOWED
Belts/Harness	FASTENED / ADJUSTED
GEN Switch	ON
ALT Switch	ON
BLEED AIR Lever	IN (open)
ECS CABIN COMFORT Switch.....	NORM
Pressurization System	SET
Fuel Temperature	CHECK WITHIN LIMITS
FUEL PUMPS Switch	MAN
IGNITION Switch	MAN
PITOT HEAT Switch	ON
Additional Ice Protection Equipment	AS REQUIRED
	(Per Section 9, Supplement 1)
TAXI/REC LT Switch.....	AS REQUIRED
LANDING LIGHT Switch.....	AS REQUIRED
NAV LIGHT Switch	AS REQUIRED
STROBE LIGHT Switch	ON
Flight Instruments	CHECK (Primary and Standby)
CAS messages	CONSIDER ANY MESSAGES ILLUMINATED
Engine Instruments.....	CHECK
Radios / Avionics	AS REQUIRED
Flaps	SET (0° - 20°)
Elevator Trim	SET IN TAKEOFF RANGE
Rudder Trim	SET 2° To 3° RT
Flight Controls	FREE & PROPER TRAVEL

NOTE

Refer to Section 9, Supplements, for Meridian Aircraft Flight Into Known Icing (FIKI), prior to any flight operations (takeoff, cruise, landing, etc.) in icing conditions.

NOTE

Prolonged operation of the stall warning vane heater in temperatures greater than 5°C will reduce the operational life of the stall warning vane.

**4.5h BEFORE TAKEOFF (4.23) (Continued)****NOTE**

The transponder will automatically switch from STBY or GND mode to ALT mode once airborne. If this automatic transition fails, manually select transponder to ALT mode.

4.5i TAKEOFF (4.25)**WARNING**

Positioning the POWER Lever aft of the flight idle stop in flight is prohibited. Such positioning may cause loss of airplane control or may result in an engine overspeed condition and consequent loss of engine power.

NOTE

Increasing airspeed will cause torque to increase.

NOTE

Demonstrated crosswind component is 17 knots.

NORMAL TAKEOFF (0° FLAPS) (4.25a)

Brakes	APPLY
POWER Lever.....	SET TO TAKEOFF
Brakes	RELEASE
Engine Instruments.....	MONITOR
Rotation and Liftoff (V_R).....	85 KIAS
Obstacle Clearance Speed	100 KIAS
After liftoff and positive rate of climb:	
Landing Gear	UP

4.5i TAKEOFF (4.25) (Continued)

SHORT FIELD TAKEOFF PERFORMANCE (20° FLAPS) (4.25b)

Flaps	20°
Brakes	APPLY
POWER Lever.....	SET TO TAKEOFF (MCP)
Brakes	RELEASE
Engine Instruments.....	MONITOR
Rotation and Liftoff (V _R).....	85 KIAS
Obstacle Clearance Speed	95 KIAS

After liftoff and positive rate of climb:

Flaps.....	RETRACT
Landing Gear	UP

4.5j MAXIMUM CONTINUOUS POWER CLIMB (4.27a)

POWER Lever	MCP
FUEL PUMPS Switch	AUTO
IGNITION Switch.....	AUTO
LANDING LIGHT Switch.....	OFF
TAXI/REC LT Switch.....	AS REQUIRED
Ice Protection Equipment	AS REQUIRED
Engine Instruments	
a. Torque.....	MONITOR (1313 FT-LB MAX.)
b. ITT	MONITOR (770°C MAX.)
c. Ng	MONITOR (101.7% MAX.)
Climb Speed (best rate)	125 KIAS
Pressurization System	SET & MONITOR
Transponder	Verify ALT mode

NOTE

The Ignition may be operated continuously and can be used for takeoff, landing, or flight into precipitation. There is no time limitation, although continuous operation will reduce component life.



4.5k CRUISE CLIMB (4.27b)

- Climb PowerSET MCP
- Ice Protection EquipmentAS REQUIRED
- Engine Instruments
 - a. TorqueMONITOR (1313 FT-LB MAX.)
 - b. ITTMONITOR (770°C MAX.)
 - c. NgMONITOR (101.7% MAX.)

- Cruise Climb Speed.....145 KIAS (to 20,000 FT)
135 KIAS (20,000 FT to 30,000 FT)
- Pressurization SystemSET& MONITOR
- AltimetersCHECK
- TransponderVerify ALT mode

4.5l CRUISE (4.29)

- Cruise Power.....SET PER POWER
TABLES IN SECTION 5
- Engine / Fuel InstrumentsMONITOR
- Pressurization SystemSET & MONITOR
- Fuel Temperature / OATMONITOR
- Cabin Climate Controls.....AS DESIRED

4.5m FLIGHT IN ICING CONDITIONS

**Reference Section 9, Supplements, for Meridian
Aircraft Flight Into Known Icing (FIKI).**

THIS SPACE INTENTIONALLY LEFT BLANK



4.5n DESCENT (4.33)

- Windshield DEFROSTPULL ON (IF REQUIRED)
- WINDSHLD HT SwitchDEFOG (IF REQUIRED)
- Ice Protection Equipment.....AS REQUIRED
- POWER LeverSET TO DESIRED TORQUE
- Altimeter & Standby Altimeter.....CHECK
- Cabin Pressure ControllerSET (field elev. +500 ft)
- Cabin Rate ControlSET for comfort
(approx. 9 o'clock position)
- Cabin Climate ControlsAS REQUIRED

NOTE

Prolonged operation of the stall warning vane heater in temperatures greater than 5°C will reduce the operational life of the stall warning vane.

4.5o BEFORE LANDING (4.35)**APPROACH CHECK (4.35a)****CAUTION**

Although the minimum approved operating speed with the autopilot coupled is 90 KIAS, coupled approaches below 100 KIAS, particularly in gusty conditions, can create high pilot workloads. The minimum speed for autopilot coupled approaches is 100 KIAS.

Altimeter & Standby Altimeter.....	SET
Pressurization.....	SET
FUEL PUMPS Switch.....	MAN
IGNITION Switch.....	MAN
LANDING LIGHT Switch.....	ON
Fuel Quantity.....	CHECK
Seats.....	ADJUSTED & LOCKED IN POSITION
Armrests.....	STOWED
Belts/Harness.....	FASTEN & ADJUSTED
Landing Gear.....	DOWN (below 168 KIAS)
Flaps.....	SET (10° @ 168 KIAS max.)

LANDING CHECK (4.35b)

Landing Gear.....	3 GREEN LIGHTS
Brakes.....	CHECK

WARNING

After pumping several times, if one or both toe brakes are inoperative, DO NOT attempt landing on a short field.

Flaps.....	SET (36° @ 118 KIAS max.)
Airspeed.....	85 KIAS

NOTE

Landing distance performance was established by maintaining a power-on (280 ft. lb. torque), stabilized 3° approach at 85 KIAS, and reducing power to idle during the landing flare.

4.5o BEFORE LANDING (4.35) (Continued)**LANDING CHECK (4.35b) (Continued)**

AutopilotDISENGAGE
 Yaw Damper (prior to landing)DISENGAGE
 TASAS REQUIRED

4.5p LANDING (4.37)**NOTE**

In crosswind conditions, the nosewheel may not be aligned with the runway as the wheel touches down because of opposite rudder input. To prevent swerving in the direction the nosewheel is offset, the rudder must be promptly centered just as the nosewheel touches down.

NORMAL TECHNIQUE (4.37a)

POWER LeverIDLE

Touch Down Main Wheels First, Then Gently Lower Nose

Brakes.....MODERATE or as required
 POWER LeverBETA or as required

NOTE

Landing distance was determined by selecting beta immediately after touchdown (all three landing gear) and applying moderate braking.

SHORT FIELD TECHNIQUE (4.37b)

POWER LeverIDLE

Touch Down Main Wheels First, Then Gently Lower Nose

Reverse (After Touchdown)MAXIMUM
 Brakes.....MODERATE
 POWER Lever.....IDLE (before aircraft stops)

4.5q BALKED LANDING (Go-Around) (4.39)

POWER Lever.....SET TAKEOFF TORQUE
 Climb Airspeed85 KIAS
 Flaps (after climb establishedRETRACT TO 20°
 and obstacle has been cleared)
 Climb AirspeedACCELERATE TO 100 KIAS
 FlapsRETRACT TO 0°
 Landing GearRETRACT

4.5r AFTER LANDING (4.41)

FUEL PUMPS SwitchAUTO
 IGNITION SwitchOFF
 PITOT HEAT Switch.....OFF
 Additional Ice Protection EquipmentOFF
 Landing / Taxi Lights.....AS REQUIRED
 Strobe LightAS REQUIRED
 WX RadarSTBY
 FlapsRETRACT
 TransponderAS REQUIRED

4.5s SHUTDOWN (4.43)

WARNING

If there is evidence of fire within the engine after shutdown, proceed immediately with the Dry Motoring Run Procedure, Section 4, Paragraph 4.5d.

CAUTION

When the CONDITION lever is selected to CUT-OFF/FEATHER, the propeller should quickly stop (20 to 30 seconds) in the feather position and a white FEATHER message on the PFD should be displayed. If the propeller continues to windmill for an extended period, or an amber FEATHER message appears on the PFD; a feathering system failure has occurred. Investigate and correct the problem prior to the next flight.

PARK BRAKE	SET
ECS CABIN COMFORT Switch	OFF
POWER Lever	IDLE
Cabin Climate Controls	OFF
FUEL PUMPS Switch	OFF
AVIONICS Switch	OFF
GEN Switch	OFF
ALT Switch	OFF

NOTE

Allow ITT to stabilize at least two minutes at idle.

CONDITION Lever	CUT-OFF/FEATHER
"FEATHER" CAS Message	CHECK ON
BLEED AIR Lever	OUT (closed)
Exterior Lighting Switches	OFF
STBY GYRO	OFF
BATTERY Switch	OFF
Flight Controls	SECURED
Oxygen System	OFF
Wheel Chocks	AS REQUIRED
Tie Downs	AS REQUIRED
Air Inlets, Exhaust and Pitot Covers	INSTALL

4.7 AMPLIFIED NORMAL PROCEDURES (GENERAL)

The following paragraphs are provided to supply detailed information and the explanation of the normal procedures for operation of the airplane.

4.9 PREFLIGHT CHECK (4.5a)

The airplane should be given a thorough preflight and walk-around check. The preflight should include a check of the airplane's operational status, computation of weight and C.G. limits, takeoff distance, and in-flight performance. A weather briefing should be obtained for the intended flight path, and any other factors relating to a safe flight should be checked before takeoff.

4.9a Cockpit (4.5a)

Upon entering the cockpit, check seat belts on empty seats are snugly fastened and check the windows for cleanliness. Verify that all required papers, flight manuals, flight manual supplements, and pilot operating handbooks are on board. Ensure that all electrical switches are OFF. Release the seatbelts securing the control wheel.

Check the primary flight controls for proper operation.

Set the parking brake by first depressing and holding the toe brake pedals and then pulling the PARK BRAKE knob. Then verify the landing gear handle is in the DN (down) position.

Turn ON the BATTERY switch. Verify three green landing gear indicator lights are illuminated. Extend the flaps to the full deflection position.

Check the charge and operation of the pilot's emergency oxygen system. Verify the charge is above the yellow arc (800 psi minimum). Verify proper mask and microphone operation as follows: Depress and hold the reset test button on the mask, while depressing the press-to-test button on the stowage box. Visually verify that the test indicator located on the stowage box and auditory cues signify oxygen flow. Also verify the mask microphone operation by monitoring the ship speaker system during the oxygen system test. The mask microphone, intercom, and ship speaker must be activated prior to testing. The mask does not have to be removed from the stowage box for preflight testing.

Turn ON and check operation of exterior lights (TAXI/REC LT, LANDING LIGHT, NAV LIGHT, STROBE LIGHT and ICE LIGHT).

Check operation of interior lighting, then turn OFF interior lighting.

Turn the BATTERY switch OFF.

Stow and secure any baggage.

4.9 PREFLIGHT CHECK (4.5a) (Continued)

4.9b Empennage (4.5a)

Begin the walk-around at the left side of the aft fuselage. Ensure that the primary and pressurization static ports on the underside of the aft fuselage and the alternate static port on the left side of the aft fuselage are clear of obstructions. Verify the contents of the tail storage compartment are secured properly, then close and verify that the compartment door is secured. Verify the EPU access door is closed or the EPU is connected. Check the condition of antennas located on the fuselage and the vertical tail. All surfaces of the empennage must be clear of ice, frost, snow or other extraneous substances. Check the condition of the stabilizer and rudder de-ice boots for any nicks, tears or delamination. Check the condition of the elevator trim tab and ensure that all hinges and pushrods are sound and operational. Check that all vortex generators on the underside of the horizontal stabilizer are installed and in good condition.

CAUTION

During the preflight inspection, if a total of more than 5 vortex generators are damaged or missing, the aircraft is not airworthy.

The elevator and rudder should be operational and free from damage or interference of any type, and the static wicks (total of 11) should be firmly attached and in good condition. Check the rudder trim tab for neutral position and excessive free play. If the tail has been tied down, remove the tie-down rope. Verify the alternate static port on the right side of the aft fuselage is clear of obstructions.

4.9 PREFLIGHT CHECK (4.5a) (Continued)**4.9c Right Wing (4.5a)**

Check that the wing surface and control surfaces are clear of ice, frost, snow or other extraneous substances. Check the flap, aileron and hinges for damage and operational interference. Static wicks (total of 3) should be firmly attached and in good condition. Check the wing tip and lights for damage.

Check and verify that the fuel tank vent is clear of any obstructions. Open the fuel cap and visually check the fuel quantity. Replace the cap securely. Check the condition of the deice boot for any nicks, tears or delamination, and verify that the stall strips are securely attached. Check that all vortex generators are installed and in good condition.

CAUTION

During the preflight inspection, if a total of more than 5 vortex generators are damaged or missing, the aircraft is not airworthy.

Check the radar pod for any damage, that all attachment points are secure, and the storage door is closed and latched. Check the OAT probes for security and ensure holes in cover are unobstructed. If installed, remove the cover from the pitot head and verify that it is clear of obstructions.

Remove the tiedown and chock.

Next, complete a check of the landing gear and general area. Check the gear strut for proper inflation. There should be approximately 3 in. (8 cm) of strut exposure under a normal static load. Also, check for hydraulic leaks. Check the integrity of the gear door, and check the tire for cuts, wear, and proper inflation. Make a visual check of the brake block and disc.

4.9 PREFLIGHT CHECK (4.5a) (Continued)

4.9d Nose Section (4.5a)

Check the general condition of the nose section; look for oil or fluid leakage and that the cowling fasteners are secure. The upper forward cowling latches consist of three slot type latches on the right and three on the left side of the cowling. Prior to flight, visually verify that each latch fastener is properly fastened. When the latch is properly fastened, the slot will be in the horizontal position and aligned with indicator marks on the cowling, and the indicator pin in the center of the slot will be extended into the slot. Open the right side cowling door and check general condition of the linkage, hoses, and wiring, then close and secure the door. Remove the outlet and exhaust covers, and verify the generator/alternator cooling air inlet is clear of obstructions. Check the exhaust stacks for cracks and that they are securely attached. Verify that the engine and oil cooler air inlets and outlets are clear of obstructions. The propeller spinner and propeller should be checked for detrimental nicks, cracks, or other defects. Rotate the propeller and listen for noises and check for binding. Verify that the landing light is clean and intact.

Remove the chock and check the nose gear strut for proper inflation. There should be approximately 2.7 in. (6.8 cm) of strut exposure under a normal static load. Check the tire for cuts, wear, and proper inflation. Check the integrity of the gear doors. Drain the fuel sumps through the quick drains located under the aft nose section, making sure that enough fuel has been drained to ensure that all water and sediment is removed and to verify proper fuel type. The fuel system should be drained daily prior to the first flight and after each refueling.

Open the left cowl door and visually check the oil level. If low, refer to Section 8 for servicing.

Oil quantity may be checked either by the sight gage or the dipstick (refer to Section 8 for procedures). Verify the oil filler cap is closed and the locking tab is down. Check the alternator and air conditioner drive belts for tension and excessive wear. Verify no leaks and that the brake fluid reservoir cap is secure. Close and secure the cowl door.

4.9 PREFLIGHT CHECK (4.5a) (Continued)

4.9e Left Wing (4.5a)

Check that the wing surface and control surfaces are clear of ice, frost, snow or other extraneous substances. Next, make a check of the landing gear area. Check the gear strut for proper inflation. There should be approximately 3 in. (8 cm) of strut exposure under a normal static load. Also, check for hydraulic leaks. Check the integrity of the gear door and check the tire for cuts, wear, and proper inflation. Make a visual check of the brake block and disc. Remove the tiedown and chock.

If installed, remove the cover from the pitot head and verify that it is clear of obstructions. Check the condition of the deice boot for any nicks or tears and verify that the stall strips are securely fastened. Check the stall warning vane for obstructions and freedom of movement. Check that all vortex generators are installed and in good condition.

CAUTION

During the preflight inspection, if a total of more than 5 vortex generators are damaged or missing, the aircraft is not airworthy.

Open the fuel cap and visually check the fuel quantity. Replace the cap securely. Check and verify that the fuel tank vent is clear of any obstructions.

Check the wing tip and lights for damage. Static wicks should be firmly attached and in good condition. Check the aileron, hinges, and flap for damage and operational interference.



4.11 BEFORE STARTING ENGINE (4.5b)

When all passengers are on board, the pilot should check that the cabin door is properly closed and latched, and visually check that all four door pin indicators are green.

WARNING

Do not initiate any flight if all four door pin indicators are not green and/or the DOOR AJAR message is illuminated.

Seats should be adjusted and locked in position. Seat belts on empty seats should be snugly fastened. All passengers should fasten their seat belts and shoulder harnesses. A pull test of the inertia reel locking restraint feature should be performed.

Verify that all electrical switches are OFF and the DAY/NIGHT switch is in the proper setting. Check that the cabin climate controls (blower, air conditioner, etc.) are OFF. Check that all circuit breakers are IN.

Before starting the engine, verify the parking brake is set and the area around the airplane is clear of personnel and equipment.

Verify the firewall FUEL SHUTOFF valve is open (IN position) and the cover is closed. The BLEED AIR lever should be closed (OUT position). The POWER lever should be in the IDLE position and the CONDITION lever should be in CUT-OFF/FEATHER. Check that the MANUAL OVRD lever is FULL AFT and locked in place. Verify the ECS switch, cabin comfort controls, and electrical switches are in the OFF positions. Check the circuit breaker panels and verify circuit breakers are in. The avionics switch should be OFF.

Push ON the EMER switch and verify activation of the pilot's PFD, No. 1 Nav/GPS, the audio panel, and illumination of the landing gear down indicators, standby airspeed, altitude and attitude indicators, and the magnetic compass.

If required, connect the external power unit to the aircraft.

Turn the BATTERY switch ON unless external power has been applied, in which case the BATTERY switch should be OFF.

Retract the flaps.

4.11 BEFORE STARTING ENGINE (4.5b) (Continued)

Press the LTS/GEAR ANNUN TEST switch while observing that the switches around the pilot's PFD and the GEAR WARNING annunciator are illuminated and the landing gear warning horn is activated. While pressing the LTS/GEAR ANNUN TEST switch, the GEAR WARN MUTE switch should be pressed. The mute switch should remain illuminated and the gear warning horn should silence. If the flaps are extended beyond 10° this muting feature is not functional. Verify that the MIC SEL switch is in the BOM (boom) position.

Verify that the alternate static source valve is in the primary (DOWN) position. Drain the pitot and static systems using drain valves located on both the right and left cockpit lower side panels next to the crew seats (two valves on the pilot's side and three on the copilot's side).

Check the fuel quantity to ensure that fuel to destination plus reserves are met and that the imbalance, if any, is within established limits. Verify that the OAT and fuel temperature are within engine starting limitations. After the CAS message window is initialized, press the FIRE DET TEST switch and verify that the red ENGINE FIRE message is displayed. Consider any CAS messages and PFD annunciators that are illuminated to ensure that the engine can be started safely.

4.13 ENGINE START (4.5c)

4.13a Engine Start - Using Airplane Battery (4.5c)

Check the battery voltage for output of 24 to 26 Volts.

NOTE

Allow G1000 avionics to initialize and display CAS messages prior to initiating an engine Auto Start sequence. Starting the engine prior to display of G1000 CAS messages will result in disruption of the auto start sequence possibly resulting in an engine overtemp condition.

NOTE

For warm weather operation engine starts may be attempted with a battery voltage of 23.5 volts minimum. Observe the engine start ITT limitation, Ng minimum speed of 13% and ensure combustion occurs within 10 seconds after moving the condition lever to run. Failure to observe these limitations can result in damage to the engine.

Select MAN on the FUEL PUMPS switch and verify the white L and R FUEL PUMP ON advisory messages illuminate. Select the IGNITION switch to MAN and verify the white IGNITION ON advisory message illuminates.

Verify area around propeller is clear. Verify the START MODE switch is in the AUTO position (light in the switch is extinguished).

NOTE

To allow the PFD to maintain maximum brightness during engine starting with high levels of ambient light present, run the AVIONICS dimmer to its minimum setting (photocell mode).

Lift cover and push the PUSH START switch to engage the starter. Check that oil pressure rises, and Ng stabilizes above 13%.

Move the CONDITION lever to RUN.

Monitor ITT to make sure the temperature does not exceed the maximum of 1000°C for more than 5 seconds.

4.13 ENGINE START (4.5c) (Continued)**4.13a Engine Start - Using Airplane Battery (4.5c) (Continued)**

If combustion is not initiated within 10 seconds of moving the Condition Lever to Run then:

- a. Move the CONDITION lever to CUT-OFF/FEATHER.
- b. Push the START MODE switch to MAN/STOP.
- c. Allow a minimum of 30 seconds for fuel draining, then refer to Dry Motoring Run, Section 4.5d.

Verify that the starter automatically disengages at 56% Ng. If the starter does not automatically disengage at 56% Ng, push the start mode MAN/STOP switch. Verify Ng is stable above 60% and prop rpm (Np) is 1200 rpm or above.


Select the GEN switch ON and check for an indication of positive amps, 28 Volts, and white GENERATOR OFF advisory message extinguished. Select the ALT switch ON, verify the white ALTERNATOR OFF message has extinguished and that the alternator remains in its standby state by indicating zero(s) on the display. Select the FUEL PUMPS switch to AUTO and the IGNITION switch to OFF. Monitor oil pressure to verify a minimum of 60 psi.

4.13b Engine Start (Manual Mode) - Using Airplane Battery (4.5c)

Check the battery voltage for output of 24 to 26 Volts.

NOTE

For warm weather operation engine starts may be attempted with a battery voltage of 23.5 volts minimum. Observe the engine start ITT limitation, Ng minimum speed of 13% and ensure combustion occurs within 10 seconds after moving the condition lever to run. Failure to observe these limitations can result in damage to the engine.



4.13 ENGINE START (4.5c) (Continued)

4.13b Engine Start (Manual Mode) - Using Airplane Battery (4.5c)

Select MAN on the FUEL PUMPS switch and verify the white L and R FUEL PUMP ON advisory messages illuminate. Select the IGNITION switch to MAN and verify the white IGNITION ON advisory message illuminates. Select manual mode by depressing the START MODE switch and verify the switch light is illuminated.

NOTE

To allow the PFD to maintain maximum brightness during engine starting with high levels of ambient light present, run the AVIONICS dimmer to its minimum setting (photocell mode).

Verify area around propeller is clear. Lift the PUSH START switch guard cover and press and *hold* the PUSH START switch to engage the starter. Check that oil pressure rises, and Ng increases and stabilizes above 13%. Once Ng stabilizes, move the CONDITION lever to RUN. Monitor ITT to make sure the temperature does not exceed the maximum of 1000°C for more than 5 seconds.

If combustion is not initiated within 10 seconds of moving the Condition Lever to Run then:

- a. Move the CONDITION lever to CUT-OFF/FEATHER.
- b. Release the PUSH START switch.
- c. Allow a minimum of 30 seconds for fuel draining, then refer to Dry Motoring Run, Section 4.5d.

If the start is proceeding normally, release the PUSH START switch at 56% Ng and verify the white STARTER ENGAGED advisory message is extinguished. Verify Ng is stable above 60% and prop rpm (Np) is 1200 rpm or above.

Select the GEN switch ON and check for an indication of positive amps, 28 Volts, and white GENERATOR OFF advisory message extinguished. Select the ALT switch ON and verify the white ALTERNATOR OFF message has extinguished and that the alternator remains in its standby state by indicating zero(s) on the display. Select the FUEL PUMPS switch to AUTO and the IGNITION switch to OFF. Monitor oil pressure to verify a minimum of 60 psi.

THIS PAGE INTENTIONALLY LEFT BLANK

**4.13 ENGINE START (4.5c) (Continued)****4.13c Engine Start - Using External Power (4.5c)**

Verify the BATTERY switch is OFF.

Connect the external power unit to the aircraft and check that the voltmeter remains stable at 24 to 29 Volts.

NOTE

Allow G1000 avionics to initialize and display CAS messages prior to initiating an engine Auto Start sequence. Starting the engine prior to display of G1000 CAS messages will result in disruption of the auto start sequence possibly resulting in an engine overtemp condition.

NOTE

For engine starting, the external power source must be capable of providing 24 to 29 Volts and 1200 Amps.

Select MAN on the FUEL PUMPS switch and verify the white L and R FUEL PUMP ON advisory messages illuminate. Select MAN on the IGNITION switch and verify the white IGNITION ON advisory message illuminates.

Verify area around propeller is clear. Verify the START MODE switch is in the AUTO position (light in the switch is extinguished).

Lift cover and push the PUSH START switch to engage the starter. Check that oil pressure rises, and Ng stabilizes above 13%. Move the CONDITION lever to RUN.

Monitor ITT to make sure the temperature does not exceed the maximum of 1000°C for more than 5 seconds.

4.13 ENGINE START (4.5c) (Continued)

4.13c Engine Start - Using External Power (4.5c) (Continued)

If combustion is not initiated within 10 seconds of moving the **CONDITION** Lever to **Run** then:

- a. Move the **CONDITION** lever to **CUT-OFF/FEATHER**.
- b. Push the **START MODE** switch to **MAN/STOP**.
- c. Allow a minimum of 30 seconds for fuel draining, then refer to **Dry Motoring Run**, Section 4.5d.

Verify that the starter automatically disengages at 56% Ng. by noting the white **STARTER ENGAGED** advisory message is extinguished. If the starter does not automatically disengage at 56% Ng, push the **START MODE** switch to **MAN/STOP**. Verify Ng is stable above 60% and prop rpm (Np) is 1200 rpm or above.

Select the **FUEL PUMPS** switch to **AUTO** and the **IGNITION** switch to **OFF**. Monitor oil pressure to verify a minimum of 60 psi.

Turn the **BATTERY** switch **ON** then disconnect the external power unit from the aircraft.

Select the **GEN** switch **ON** and check for an indication of positive amps, 28 Volts, and the white **GENERATOR OFF** advisory message extinguished. Select the **ALT** switch **ON** and verify the white **ALTERNATOR OFF** advisory message has extinguished and remains in its standby state by indicating zero(s) on the display.

4.15 DRY MOTORING RUN (4.5d)

After allowing a minimum of 30 seconds for fuel to drain, move the **POWER** lever to **IDLE** and the **CONDITION** lever to **CUT-OFF/FEATHER**. The **FUEL PUMPS** switch and the **IGNITION** switch should be selected **OFF**. Turn the **BATTERY** switch **ON** and select **MAN** on the **START MODE** switch. The light in the **START MODE** switch should be illuminated.

NOTE

To allow the **PFD** to maintain maximum brightness during engine starting with high levels of ambient light present, run the **AVIONICS** dimmer to its minimum setting (photocell mode).

Select and hold the **PUSH START** switch to engage for 15 seconds, then release the **PUSH START** switch to **OFF**.

4.15 DRY MOTORING RUN (4.5d) (Continued)**NOTE**

Observe starter cooling limits (Section 2, Paragraph 2.9).

4.17 BEFORE TAXIING (4.5e)

Select the AVIONICS switch to ON.

The MFD will power-up with a splash screen that lists all databases and expiration dates. The pilot should verify database currency. The MFD - Weight Planning page will appear to allow the appropriate weights to be entered and summarized. The weight of fuel on board may be entered manually or by pressing the FOB SYNC Softkey. Consider any CAS messages that are illuminated.

Verify that the autopilot automatically completes its preflight self-test (PFT) and the disconnect tone is heard.

Select PITOT HEAT switch ON, check operation then select OFF. Note proper operation of pitot heat by verifying amber PITOT HEAT OFF message extinguished and monitoring the volt/ammeter for a corresponding voltage drop and amperage rise. When the PITOT HEAT switch is turned OFF, a chime will not accompany the amber PITOT HEAT OFF message.

The navigation and strobe lights and the taxi/rec lights should be utilized as required. The cabin climate controls can be set as desired.

Check that the radios and avionics are set and functioning as required. (Utilize the avionics self test operations where applicable.) Retract the flaps.

Set elevator trim to the takeoff range (T/O RNG) and rudder trim to the takeoff range (green arc 2° to 3° right of center).

Push the BLEED AIR lever to the open position (IN). Verify the cabin pressure DUMP switch is in the pressurize position (DUMP light in switch extinguished and switch in the out position). Select NORM on the ECS CABIN COMFORT switch and set the pressurization control to field elevation plus 500 feet and the rate control knob to the 9 o'clock position.

NOTE

Maximum cooling on the ground may be achieved by operating with the BLEED AIR lever in the OUT (closed) position and the ECS CABIN COMFORT control selected OFF.

Press the STALL TEST switch and verify the stall warning tone is heard.

4.17 BEFORE TAXIING (4.5e) (Continued)

Select STBY GYRO TEST on the standby attitude indicator switch and verify the STBY BAT TEST OK message is displayed on the MFD, then select ON on the STBY GYRO switch. If required, pull the PULL TO CAGE knob to erect the gyro. Set the altimeter/standby altimeters as required. Press the stall warning press-to-test button and verify activation of the stall aural warning horn.

Verify TAWS self-test completed by the audible "TAWS System Test OK". TAWS and Traffic tests may also be performed manually via the MENU selection on the MAP page corresponding to TAWS and Traffic, respectively.

NOTE

The TIS traffic system does not have a manual test feature.

Release the parking brake.

4.19 TAXIING (4.5f)

After making sure the taxi area is clear, slowly advance the POWER lever. Taxi a few feet forward and apply the brakes to determine their effectiveness. While taxiing, make slight turns to check the effectiveness of the steering. Check the flight instruments for proper operation.

WARNING

Propeller operation below 1200 rpm is prohibited.

NOTE

BETA range (aft of IDLE detent) may be used during taxi to control taxi speed and reduce wear on brakes.

4.21 ENGINE RUN UP (4.5g)

Make sure the parking brake is set. Apply brakes with rudder pedals, then pull out the PARK BRAKE control. Advance the POWER lever to attain 1900 RPM. Move the FRICTION lever forward to apply throttle friction so that the throttle will maintain a set position.

Lift the cover, push and hold the OVERSPEED GOV TEST switch and observe approximate 60 RPM drop in Np. Release the OVERSPEED GOV TEST switch and check that Np returns and stabilizes at 1900 RPM.

4.21 ENGINE RUN UP (4.5g) (Continued)

Move the POWER lever to IDLE and depress and hold the REVERSE LOCK OUT switch for a minimum of 5 seconds. Keeping the REVERSE LOCK OUT switch depressed, lift and retard the POWER lever toward BETA and REV (reverse). Beta and reverse should not be attainable. Release the REVERSE LOCK OUT switch and repeat lifting and retarding the POWER lever aft to BETA and REV (reverse). Beta and reverse should now be attainable.

Return the POWER lever to IDLE. Select the GEN switch OFF, verify the alternator picks up the load. Verify the white GENERATOR OFF advisory message is illuminated. Select the GEN switch ON. Verify the white GENERATOR OFF advisory message is extinguished. Select the ALT switch OFF, verify the generator picks up the load and the white ALTERNATOR OFF advisory message is illuminated. Select the ALT switch ON, verify the white ALTERNATOR OFF advisory message is extinguished. Set the quadrant FRICTION lock.

NOTE

Refer to Section 9, Supplements, for Meridian Aircraft Flight Into Known Icing (FIKI), prior to any flight operations (takeoff, cruise, landing, etc.) in icing conditions.

4.23 BEFORE TAKEOFF (4.5h)

Check that seat backs are erect and seats are adjusted and locked in position. Armrests should be stowed and seat belts and harnesses should be fastened and adjusted. Verify the generator and alternator are ON with a positive indication of amps.

The BLEED AIR lever should be IN (open), the ECS CABIN COMFORT switch should be set to NORM, the pressurization controller should be set to 500 feet above the airport pressure altitude, the rate control should be set to the approximate 9 o'clock position, and the CABIN PRESS switch should be set to the normal mode whereby the word DUMP is not displayed and the cover closed. Verify fuel temperature is within specified limitations.

4.23 BEFORE TAKEOFF (4.5h) (Continued)

Select the FUEL PUMPS switch and the IGNITION switch to the MAN position. Select PITOT HEAT switch ON and select the additional ice protection equipment ON as required per Section 9, Supplement 1. Select STROBE LIGHT switch ON and the NAV LIGHT, LANDING LIGHT and TAXI/REC LT switches as required. The nose gear landing light is only usable when the landing gear is extended. For maximum aircraft visibility by other aircraft in flight, select PULSE mode on the TAXI/REC LT switch.

Check all the flight instruments and set as required. Check the CAS messages that are illuminated. Check all the engine instruments to verify the engine indications are within the normal operating range. Radios and avionics should be set as required. Verify elevator trim is set in the takeoff range and rudder trim is set 2° to 3° to the right, and flaps are up. Check the flight controls for free and proper travel.

NOTE

Refer to Section 9, Supplements, for Meridian Aircraft Flight Into Known Icing (FIKI), prior to any flight operations (takeoff, cruise, landing, etc.) in icing conditions.

NOTE

Prolonged operation of the stall warning vane heater in temperatures greater than 5°C will reduce the operational life of the stall warning vane.

NOTE

The transponder will automatically switch from STBY or GND mode to ALT mode once airborne. If this automatic transition fails, manually select transponder to ALT mode.

4.25 TAKEOFF (4.5i)**WARNING**

Positioning the POWER lever aft of the flight idle stop in flight is prohibited. Such positioning may cause loss of airplane control or may result in an engine overspeed condition and consequent loss of engine power.

4.25 TAKEOFF (4.5i) (Continued)**NOTE**

Increasing airspeed will cause torque to increase.

NOTE

Demonstrated crosswind component is 17 knots.

4.25a NORMAL TAKEOFF (0° FLAPS) (4.5I)

Align the airplane with the runway and apply the brakes. Move the POWER lever to takeoff power and release the brakes. Scan the engine instruments to verify all indications are within the normal operating range. Accelerate to attain rotation speed (V_R) of 85 KIAS. After liftoff, adjust the airplane attitude as required to attain the obstacle clearance speed of 100 KIAS.

After liftoff and a positive rate of climb is established, retract the landing gear.

4.25b Short Field Takeoff Performance (20° Flaps) (4.5i)

Set the flaps to the 20° position. Align the airplane with the runway and apply the brakes. Set the POWER lever to takeoff power (MCP) and release the brakes. Monitor the engine instruments to verify all indications are within the normal operating range. Accelerate to attain rotation speed of 85 KIAS. After liftoff, adjust the airplane attitude as required to attain the obstacle clearance speed of 95 KIAS.

After liftoff and a positive rate of climb is established, retract the flaps and the landing gear.

4.27 CLIMB (4.5j)

4.27a Maximum Continuous Power Climb (4.5j)

Position the POWER control lever to maintain maximum continuous power climb. Select the FUEL PUMPS and IGNITION switches to the AUTO position and turn OFF the LANDING LIGHT. The taxi/rec lights may be utilized as required. Use ice protection equipment as required. Monitor the engine instruments: torque 1313 ft. lb. max, ITT (770°C max.), and Ng (101.7% max.). Adjust the airplane attitude to obtain the best rate of climb speed of 125 KIAS. Check that the pressurization system controls are properly set, and continuously monitor. Verify the transponder is in ALT mode.

NOTE

The ignition may be operated continuously and can be used for takeoff, landing, or flight into precipitation. There is no time limitation, although continuous operation will reduce component life.

4.27b Cruise Climb (4.5k)

Position the POWER lever to maintain maximum continuous power. Use ice protection equipment as required. Monitor the engine instruments: torque 1313 ft. lb. max, ITT (770°C max.), and Ng (101.7% max.). Adjust the airplane attitude to obtain the best cruise climb speed of 145 KIAS (to 20,000 feet) or 135 KIAS (20,000 to 30,000 feet). Check that the pressurization system controls are properly set, and continuously monitor. Check the primary and standby altimeters. Verify the transponder is in ALT mode.

4.29 CRUISE (4.5l)

The cruising speed is determined by many factors including power setting, altitude, temperature, loading, and equipment installed on the airplane. Also, weather conditions should be continuously monitored, with special attention to conditions which could lead to icing.

When leveling off at cruise altitude, determine the cruise power setting by referring to the power tables located in Section 5, Performance. Continuously monitor the engine and fuel instruments to verify all indications are within the normal operating range and that fuel is being properly managed. Check that the pressurization system controls are properly set, and continuously monitor. Verify fuel temperature and OAT are within specified limitations. Adjust the cabin climate controls as desired.

4.31 FLIGHT IN ICING CONDITIONS

Reference Section 9, Supplements, for Meridian Aircraft Flight Into Known Icing (FIKI).

NOTE

Prolonged operation of the stall warning vane heater in temperatures greater than 5°C will reduce the operational life of the stall warning vane.

4.33 DESCENT (4.5n)

If required, pull the windshield DEFROST control on and turn the WINDSHLD HT switch to DEFOG. Position the POWER lever to obtain the desired torque required for the descent. Check the altimeter and standby altimeter. The cabin pressure controller should be set to field elevation +500 feet. The cabin rate control should be set to approximately the 9 o'clock position and the cabin climate controls should be set as desired to obtain comfortable conditions.

THIS SPACE INTENTIONALLY LEFT BLANK

4.35 BEFORE LANDING (4.5o)

4.35a Approach Check (4.5o)

CAUTION

Although the minimum approved operating speed with the autopilot coupled is 90 KIAS, coupled approaches below 100 KIAS, particularly in gusty conditions, can create high pilot workloads. The minimum speed for autopilot coupled approaches is 100 KIAS.

Set the altimeter and standby altimeter. Verify that the cabin pressurization is set. Select the FUEL PUMPS and IGNITION switches to MAN. Turn the LANDING LIGHT switch ON. Verify fuel quantity and balance. Make sure seat backs are erect and seats are adjusted and locked in position. Armrests should be stowed and seat belts and harnesses should be fastened and adjusted. The landing gear may be extended and the flaps may be set to 10° at airspeeds up to 168 KIAS maximum.

4.35b Landing Check (4.5o)

Verify 3 green lights indicating that the landing gear are down and locked. Pump the toe brakes to ensure that the system is capable of uniform braking during landing rollout.

WARNING

After pumping several times, if one or both toe brakes are inoperative. DO NOT attempt landing on a short field.

As the airspeed is reduced to 118 KIAS or lower, the flaps can be set to 36°. Set power (approximately 280 ft. lb. torque for a 3° approach) to maintain an airspeed of 85 KIAS.

NOTE

Landing distance performance was established by maintaining a power-on (280 ft. lb. torque), stabilized 3° approach at 85 KIAS, and reducing power to idle during the flare.

The autopilot and yaw damper must be disengaged for landing. Use TAS as required.

4.37 LANDING (4.5p)

NOTE

In crosswind conditions, the nosewheel may not be aligned with the runway as the wheel touches down because of opposite rudder input. To prevent swerving in the direction the nosewheel is offset, the rudder must be promptly centered just as the nosewheel touches down.

4.37a Normal Technique (4.5p)

When performing a normal landing, reduce the power to IDLE during the flare. *Touchdown should be made with the main wheels first, then gently lower the nose.* After touchdown (all three landing gear), apply moderate braking, and lift and retard the POWER lever to the BETA position.

NOTE

Landing distance was determined by selecting BETA immediately after touchdown (all three landing gear) and applying moderate braking.

4.37b Short Field Technique (4.5p)

When performing a short field landing, reduce the power to IDLE during the flare. *Touchdown should be made with the main wheels first, then gently lower the nose.* After touchdown (all three landing gear), apply moderate braking, and lift and retard the POWER lever to maximum reverse. Move the POWER lever to IDLE before the airplane comes to a stop.

4.39 BALKED LANDING (Go-around) (4.5q)

To initiate a go-around from a landing approach, apply takeoff torque and adjust the airplane attitude to obtain a climb airspeed of 85 KIAS. After a positive climb is established and obstacle has been cleared, retract the flaps to 20° and accelerate to a climb airspeed of 100 KIAS. Retract the flaps to 0° and then retract the landing gear. Verify aircraft heading against the correction card.

4.41 AFTER LANDING (4.5r)

Select the FUEL PUMPS switch to AUTO and the IGNITION switch to OFF. Turn the PITOT HEAT and all additional ice protection equipment OFF. The landing, taxi, and strobe lights may be used as required. Turn the weather radar to STBY. Retract the flaps. Select the transponder to STBY or ALT, as required.

4.43 SHUTDOWN (4.5s)

WARNING

If there is evidence of fire within the engine after shutdown, proceed immediately with the Dry Motoring Run Procedure, Section 4, Paragraph 4.5d.

CAUTION

For normal engine shutdowns, when the condition lever is selected to CUT-OFF/FEATHER, the propeller should quickly stop (20 to 30 seconds) in the feather position and a white advisory FEATHER message on the PFD should be displayed. If, however, the propeller continues to windmill for an extended period or an amber FEATHER message appears on the PFD, a feathering system failure has occurred. Investigate and correct the problem prior to the next flight.

With the POWER lever in IDLE and the airplane at a complete stop, set the PARK BRAKE knob. Turn the ECS CABIN COMFORT switch and cabin climate controls to OFF. The FUEL PUMPS, IGNITION, and AVIONICS switches should all be set to OFF. Turn the GEN and ALT switches to OFF.

NOTE

Allow ITT to stabilize at least two minutes at idle.

The CONDITION lever can now be moved to CUT-OFF/FEATHER. Check for a FEATHER CAS message. The BLEED AIR lever should be closed (OUT position). After turning the exterior lighting switches OFF, turn the STBY GYRO switch OFF. Then the BATTERY switch can be turned OFF.

The aileron and elevator controls should be secured by looping the safety belt through the control wheel and pulling it snug. Turn the pilot's emergency oxygen system OFF. Wheel chocks should be positioned in place and tiedowns should be secured to the main landing gear and to the tail skid. The rudder is held in position by its connections to the nose wheel steering and normally does not have to be secured.

Place protective covers on all air inlets, exhaust openings and pitot heads.



4.45 STALLS

The stall characteristics of the Meridian are conventional. An approaching stall is indicated by a stall warning horn which is activated at least 5 knots above the actual stall. Mild airframe buffeting and pitching may also precede the stall.

The stalling speed at maximum gross weight with power off, landing gear extended, and full flaps is 69 KIAS. With the landing gear retracted and flaps up, stall speed is increased to 79 KIAS. Loss of altitude during stalls can be as great as 900 feet, depending on configuration and power.

NOTE

The stall warning system is inoperative with the BATTERY and GEN and ALT switches OFF.

During preflight, the stall warning system should be checked by turning the BATTERY switch ON and pressing the STALL TEST switch to determine if the horn is actuated.

4.47 TURBULENT AIR OPERATION

In keeping with good operating practice, it is recommended that when turbulent air is encountered or expected, the airspeed be reduced to maneuvering speed to reduce the structural loads caused by gusts and to allow for inadvertent speed build-ups which may occur as a result of the turbulence or of distractions caused by the conditions (refer to Section 2, Paragraph 2.3 for maneuvering speeds).

4.49 CABIN PRESSURIZATION

Cabin pressurization system controls and switches are located on the lower left instrument panel while the pressurization system displays are incorporated into the MFD, or PFD if in Reversionary mode. (Refer to Section 7, Figure 7-9.)

The cabin pressurization system controls, displays and switches are as follows:

- (a) Cabin Altitude Controller with Rate of Change Control
- (b) Cabin Pressure Altitude, Differential Pressure, and Rate of Climb Display
- (c) Cabin Pressure Dump/Normal Switch
- (d) Cabin Pressurization Control
- (e) Vacuum Display

4.49 CABIN PRESSURIZATION (continued)

Set *cabin* altitude (outer scale) on the cabin altitude controller to 500 feet above the field pressure altitude before takeoff. (Cabin pressurization will begin as the cabin passes through the altitude selected.) If no further adjustments are made, cabin altitude will remain at the selected altitude until maximum cabin differential (5.5 PSI) is reached, at which time the cabin altitude will begin to climb at the same rate as the airplane until 30,000 feet aircraft pressure altitude is reached where the cabin pressure altitude will be approximately 10,630 feet.

For flight below an airplane altitude of 12,500 feet, the cabin altitude control should be left at the takeoff setting. For flights planned above 12,500 feet (the point at which maximum differential will be achieved), smoother operation will result by setting the *cabin* altitude (outer scale) on the cabin altitude controller to 500 feet above field elevation for takeoff. Once the cabin has begun to pressurize and the controller has captured isobaric control, reset the *aircraft* altitude (inner scale) on the cabin altitude controller to 500 feet above the cruise altitude and adjust the cabin rate of climb as desired. The normal 9 o'clock position should provide a cabin rate of climb of approximately 500 feet per minute. No additional adjustment should be required prior to descent unless cruise altitude is changed, at which point the *aircraft* altitude (inner scale) should be reset to 500 feet above the new cruise altitude.

To descend for landing be certain that the selected *cabin* altitude (outer scale) is higher than the pressure altitude of the landing field. Shortly after letdown is initiated, set the *cabin* altitude (outer scale) to 500 feet above the pressure altitude of the landing field and adjust the rate of control high enough to allow the cabin to descend to the landing setting before the aircraft descends to that altitude. For normal letdown the rate knob should be at the 9 o'clock position. A higher setting should be selected for rapid descents so that the aircraft altitude does not catch up with the cabin altitude.

WARNING

Do not land with aircraft pressurized.

4.51 CABIN CLIMATE CONTROL PANEL OPERATION

4.51a Cabin Climate Control Panel Controls and Switches

Cabin climate controls and switches are located just to the right of the flap selector handle in the cabin comfort control panel. (Refer to Section 7, Figure 7-9.)

The cabin climate system controls and switches from left to right on the panel are:

- AIR COND / ON switch
- HI / LO blower switch
- VENT FAN / ON switch
- CLIMATE CONTROL - AUTO / COOL / WARM rotary switch
- AUTO / MANUAL mode switch
- MANUAL WARM / COOL switch

4.51b Auto Temp Operation

Set the ECS CABIN COMFORT switch to the NORM position.

Under normal conditions, temperature will be maintained automatically. For automatic operation, set the mode switch to AUTO. Set the temperature control to the desired temperature. Set the blower fan switch to either HI or LOW as desired.

4.51 CABIN CLIMATE CONTROL PANEL OPERATION (continued)

4.51c Manual Temp Operation

NOTE

Maximum heat can be obtained in the manual mode by positioning the ECS CABIN COMFORT switch to HIGH. This position should only be used on the ground with ambient temperature less than 20°F (-7°C). Should the bleed overtemperature annunciator light illuminate, manually decrease the temperature by pulsing the WARM/COOL switch to the cool position.

For maximum airconditioning, hold the manual WARM/COOL switch to the cool position for 45 seconds. The switch may be pulsed to the WARM position to control the cabin temperature desired.

To meet POH performance figures, the ECS CABIN COMFORT switch must be in the NORM position.

4.51d Maximum Cabin Cooling

On Ground:

On the ground, maximum cabin cooling may be obtained by placing the bleed air lever OUT (closed) position, the ECS CABIN COMFORT switch OFF, Air Conditioner ON and the blower fan to HI.

In Flight:

Unpressurized flights can be conducted with the bleed air lever pulled OUT (closed) and the ECS CABIN COMFORT switch OFF. This will provide maximum ventilation. Set the blower fan to HI or LO as desired and turn the vent fan ON.

4.53 NOISE LEVEL

The corrected noise level of this aircraft is 76.8 dB(A) as measured per ICAO Annex to Volume 1, Chapter 10 and FAR 36 Appendix G, Amendment 22.

No determination has been made by the Federal Aviation Administration that the noise levels of this airplane are or should be acceptable or unacceptable for operation at, into, or out of, any airport.

The above statement notwithstanding, the noise level stated above has been verified by and approved by the Federal Aviation Administration in noise level test flights conducted in accordance with F.A.R. 36, Noise Standards - Aircraft Type and Airworthiness Certification. This aircraft model is in compliance with all F.A.R. 36 noise standards applicable to this type.

4.55 RESERVED

4.57 HIGH ALTITUDE OPERATION

During high altitude operations above approximately 28,500 ft. MSL, the cabin altitude will exceed 10,000 ft. MSL and an amber CABIN ALT 10,000 caution message will be displayed. This is an indication for the pilot to:

- Be vigilant about monitoring the cabin altitude.
- Check the BLEED AIR knob is pushed IN and the ECS rotary switch is set to NORM.
- Check the CAB PRES/DUMP switch is OFF.
- Check the cabin altitude selector is properly set to 500 ft. above the destination airport altitude.
- Check the pilot's emergency oxygen system charge (1850 psig).

If the cabin altitude rises above 12,000 ft. MSL, a red CABIN ALT 12000 message will illuminate, a warning horn that the pilot can mute will sound and the emergency pressurization system will activate, indicating the pilot should:

- Don the pilot's emergency oxygen mask and insure that oxygen is flowing.
- Descend to an altitude where the red CABIN ALT 12000 message extinguishes.

AND

- Make an emergency descent if required.

CAUTION

A fully charged (1850 psig) pilot supplemental demand flow oxygen system contains a supply (approximately 30 minutes) of oxygen for the pilot to breath in the "normal" setting for a duration in excess of that required for an emergency descent. The minimum duration of oxygen required for an emergency descent to an appropriate altitude for unpressurized flight is indicated on the oxygen gauge by a yellow arc.



THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS
SECTION 5
PERFORMANCE

Paragraph No.		Page No.
5.1	General	5-1
5.2	Aircraft Configuration	5-1
5.3	Introduction - Performance and Flight Planning	5-1
5.5	Flight Planning Example	5-3
5.7	Performance Graphs	5-9
	List of Figures	5-9
	List of Figures - Metric	5-13

THIS PAGE INTENTIONALLY LEFT BLANK

SECTION 5

PERFORMANCE

5.1 GENERAL

All of the required (FAA regulations) and complementary performance information is provided by this section.

True airspeed may vary $\pm 1\%$ due to tolerances in power, airspeed and temperature indications.

Performance information associated with those optional systems and equipment which require handbook supplements is provided by Section 9 (Supplements).

Performance is predicated on NORMAL ECS setting. Setting ECS to HI, while maintaining a constant power, will increase fuel flow by approximately 9 pph, or, if ITT is maintained at the temperature limit, power will be reduced by 8%.

While some performance charts show information below -54°C , performance information presented in this chapter is valid for the range from $+50^{\circ}\text{C}$ (122°F) to -54°C (-65°F) only.

5.2 AIRCRAFT CONFIGURATION

Performance depicted in Section 5 is applicable to aircraft equipped with a weather radar pod, main landing gear fairings, 2 communications antennas, 2 GPS antennas, 1 dual purpose navigation antenna, 1 radar altitude antenna, 2 transponder antennas, 1 marker beacon antenna, 1 stormscope antenna, 1 ADF antenna, 1 DME antenna and 1 AM/FM radio antenna.

5.3 INTRODUCTION - PERFORMANCE AND FLIGHT PLANNING

The performance information presented in this section is based on measured Flight Test Data corrected to I.C.A.O. standard day conditions, or non parametric coefficients, and analytically expanded for the various parameters of weight, altitude, temperature, etc.

The performance charts are unfactored and do not make any allowance for varying degrees of pilot proficiency or mechanical deterioration of the aircraft. This performance, however, can be duplicated by following the stated procedures in a properly maintained airplane.

5.3 INTRODUCTION - PERFORMANCE AND FLIGHT PLANNING
(continued)

Effects of conditions not considered on the charts must be evaluated by the pilot, such as the effect of winds aloft on cruise and range performance.

REMEMBER! To get chart performance, follow the chart procedures.

The information provided by paragraph 5.5 (Flight Planning Example) outlines a detailed flight plan using performance charts in this section. Each chart includes its own example to show how it is used.

WARNING

Performance information derived by extrapolation beyond the limits shown on the charts should not be used for flight planning purposes.

5.5 FLIGHT PLANNING EXAMPLE

(a) Aircraft Loading

The first step in planning the flight is to calculate the airplane weight and center of gravity by utilizing the information provided by Section 6 (Weight and Balance) of this handbook.

The basic empty weight for the airplane as licensed at the factory has been entered in Figures 6-5 and 6-39. If any alterations to the airplane have been made affecting weight and balance, reference to the aircraft logbook and Weight and Balance Record (Figures 6-7 and 6-41) should be made to determine the current basic empty weight of the airplane.

Make use of the Weight and Balance Loading Forms (Section 6) and the C.G. Range and Weight graph (Figures 6-33 and 6-69) to determine the total weight of the airplane and the center of gravity position.

After proper utilization of the information provided, the following weights have been determined for consideration in the flight planning example.

5.5 FLIGHT PLANNING EXAMPLE

(a) Aircraft Loading (continued)

The landing weight cannot be determined until the weight of the fuel to be used has been established. Refer to item (g) (1).

(1) Basic Empty Weight	3380 lb (1533.1 kg)
(2) Occupants	520 lb (235.8 kg)
(3) Baggage and Cargo	80 lb (36.3 kg)
Total Zero Fuel Weight {(1) + (2) + (3)}	3980 lb (1805.3 kg)
(4) Fuel (6.7 lb/gal. x 135) (3.041 kg/gal x 135)	904.5 lb (410.3 kg)
(5) Ramp Weight	4884.5 lb (2215.6 kg)
(6) Start, Taxi and Runup Weight	-43.0 lb (-19.33 kg)
(7) Takeoff Weight	4841.5 lb (2196.2 kg)
(8) Landing Weight	
(a)(5) minus (g)(1),	
(4884.5 lb minus 225 lb) (2215.6 kg minus 102.1 kg)	4659.5 lb (2113.5 kg)

The total zero fuel weight is below the maximum of 4850 lbs (2063.8 kg).

The takeoff weight is below the maximum of 5092 lbs (2309.7 kg) and the weight and balance calculations have determined the C.G. position within the approved limits. Refer to Figures 6-9 and 6-43.



5.5 FLIGHT PLANNING EXAMPLE (continued)

(b) Takeoff and Landing

Now that the aircraft loading has been determined, all aspects of the takeoff and landing must be considered.

All of the existing conditions at the departure and destination airport must be acquired, evaluated and maintained throughout the flight.

Apply the departure airport conditions and takeoff weight to the appropriate Takeoff Ground Roll and Takeoff Distance (Figures 5-41, 5-43, 5-45 and 5-47) (for Metric units see Figures 5-175, 5-177, 5-179 and 5-181) to determine the length of runway necessary for the takeoff and/or obstacle clearance.

The landing distance calculations are performed in the same manner using the existing conditions at the destination airport and, when established, the landing weight.

The conditions and calculations for the example flight are listed below. The takeoff and landing distances required for the flight have fallen well below the available runway lengths.

	Departure Airport	Destination Airport
(1) Pressure Altitude	1000 ft	3500 ft
(2) Temperature	29°C	25°C
(3) Wind Component (Headwind)	10 KTS	5 KTS
(4) Runway Length Available	3400 ft (1036.3 meters)	5000 ft (1524 meters)
(5) Runway Gradient	2% up	2% up
(6) Takeoff and Landing Distance Required	2488 ft* (758.3 meters)	2205 ft** (672.1 meters)

* reference Figure 5-47 (Figure 5-181 for metric)

** reference Figure 5-131 (Figure 5-265 for metric)

5.5 FLIGHT PLANNING EXAMPLE (continued)**NOTE**

The remainder of the performance charts used in this flight plan example assume a no wind condition. The effect of winds aloft must be considered by the pilot when computing climb, cruise and descent performance.

(c) Climb

The next step in the flight plan is to determine the necessary climb segment components.

The desired cruise pressure altitude and corresponding cruise outside air temperature values are the first variables to be considered in determining the climb components from the Fuel, Time, and Distance to Climb graph (Figures 5-55, 5-57 and 5-59) (for Metric units see Figures 5-129, 5-191 and 5-193). After the fuel, time, and distance for the cruise pressure altitude and outside air temperature values have been established, apply the existing conditions at the departure field to graph (Figures 5-55, 5-57 and 5-59) (for Metric units see Figures 5-189, 5-191 and 5-193). Now, subtract the values obtained from the graph for the field of departure conditions from those for the cruise pressure altitude.

The remaining values are the true fuel, time, and distance components for the climb segment of the flight plan corrected for field pressure altitude and temperature.



5.5 FLIGHT PLANNING EXAMPLE (continued)

(c) Climb (Continued)

The following values were determined from the above instructions in the flight planning example.

- | | |
|--|------------------------|
| (1) Cruise Pressure Altitude | 25000 ft |
| (2) Cruise OAT | -20° C |
| (3) Fuel to Climb (includes Start, Taxi and Takeoff)
(152 lb. minus 48 lb.) (69 kg minus 21.8 kg) | 104 lb.*
(47.2 kg)* |
| (4) Time to Climb
(20 min. minus 0.7 min.) | 19.3 min.** |
| (5) Distance to Climb
(54 nautical miles minus 1.3
nautical miles) | 52.7 nautical miles*** |

* reference Figure 5-57 (Figure 5-191 for metric)

** reference Figure 5-55 (Figure 5-189 for metric)

***reference Figure 5-59 (Figure 5-193 for metric)

(d) Descent

The descent data will be determined prior to the cruise data to provide the descent distance for establishing the total cruise distance.

Utilizing the cruise pressure altitude and OAT, determine the basic fuel, time, and distance for descent (Figures 5-115, 5-117 and 5-119) (for Metric units see Figures 5-249, 5-251 and 5-253). These figures must be adjusted for the field pressure altitude and temperature at the destination airport. To find the necessary adjustment values, use the existing pressure altitude and temperature conditions at the destination airport as variables to find the fuel, time, and distance values from the graph (Figures 5-115, 5-117 and 5-119) (for Metric units see Figures 5-249, 5-251 and 5-253). Now, subtract the values obtained from the field conditions from the values obtained from the cruise conditions to find the true fuel, time and distance values needed for the descent segment of the flight plan.

5.5 FLIGHT PLANNING EXAMPLE (continued)**(d) Descent (Continued)**

The values obtained by proper utilization of the graphs for the descent segment of the example are shown below.

- | | |
|--|-------------------------|
| (1) Fuel to Descend
(50.1 lb. minus 10.7 lb.) (22.7 kg minus 4.9 kg) | 39.4 lb.*
(17.8 kg)* |
| (2) Time to Descend
(16.6 min. minus 2.6 min.) | 14 min.** |
| (3) Distance to Descend
(60.2 nautical miles minus 8.2
nautical miles) | 52 nautical miles*** |

(e) Cruise

Using the total distance to be traveled during the flight, subtract the previously calculated distance to climb and distance to descend to establish the total cruise distance. Refer to the appropriate Power Setting Table (refer to Figure 5-69) (for Metric units see Figure 5-203) when selecting the cruise power setting. The established pressure altitude and temperature values and the selected cruise power should now be used to determine the true airspeed from the Power Setting tables (Figure 5-69) (for Metric units see Figure 5-203). Interpolation may be required if altitude and/or temperature falls between cardinal values on power tables.

* reference Figure 5-117 (Figure 5-251 for metric)

** reference Figure 5-115 (Figure 5-249 for metric)

***reference Figure 5-119 (Figure 5-253 for metric)



5.5 FLIGHT PLANNING EXAMPLE (continued)

Calculate the cruise fuel consumption for the cruise power setting from the information provided by the Power Setting Table (refer to Figure 5-69) (for Metric units refer to Figure 5-203).

The cruise time is found by dividing the cruise distance by the cruise speed and the cruise fuel is found by multiplying the cruise fuel consumption by the cruise time.

The cruise calculations established for the cruise segment of the flight planning example are as follows:

- | | |
|--------------------------------------|-------------------------|
| (1) Total Distance | 188 nautical miles |
| (2) Cruise Distance | |
| (e)(1) minus (c)(5) minus | |
| (d)(3), (188 nautical miles | |
| minus 52.6 nautical miles | |
| minus 52 nautical miles) | 83.4 nautical miles |
| (3) Cruise Torque | 1174 FT.-LB. |
| | maximum speed cruise |
| (4) Cruise Speed | 259 KTS TAS* |
| (5) Cruise Fuel Consumption | 255 pph* (115.7 kg/hr)* |
| (6) Cruise Time | |
| (e)(2) divided by (e)(4), | |
| (83.4 nautical miles | |
| divided by 259 KTS) | 0.32 hrs |
| (7) Cruise Fuel | |
| (e)(5) multiplied by (e)(6) | |
| (255 pph multiplied by 0.32 hrs) | 81.6 lb. |
| (115.7 kg/hr multiplied by 0.32 hrs) | (37.02 kg) |

(f) Total Flight Time

The total flight time is determined by adding the time to climb, the time to descend and the cruise time. Remember! The time values taken from the climb and descent graphs are in minutes and must be converted to hours before adding them to the cruise time.

*reference Figure 5-69 (Figure 5-203 for metric)

5.5 FLIGHT PLANNING EXAMPLE (continued)**(f) Total Flight Time (Continued)**

The flight time required for the flight planning example is shown below:

- | | |
|---|----------|
| (1) Total Flight Time | |
| (c)(4) plus (d)(2) plus (e)(6), | |
| (0.32 hrs plus 0.23 hrs plus 0.32 hrs) | |
| (19.3 min. plus 14 min. plus 19.2 min.) | 0.87 hrs |

(g) Total Fuel Required

Determine the total fuel required by adding the fuel to climb (includes fuel to start, taxi and runup), the fuel to descend, and the cruise fuel. When the total fuel (in pounds) (kilograms) is determined, divide this value by 6.7 lb/gal. (.80 kg/L) to determine the total fuel in gallons (liters) used for the flight.

The total fuel calculations for the example flight plan are shown below.

- | | |
|--|---------------------|
| (1) Total Fuel Required | |
| (c)(3) plus (d)(1) plus (e)(7), | |
| (15.5 gal. plus 5.9 gal. plus 12.2 gal.) | 33.6 gal./225.1 lb. |
| (58.7 L plus 22.3 L plus 46.2L) | 127.2 L (102.1 kg) |

**SECTION 5
PERFORMANCE**

PA-46-500TP



THIS PAGE INTENTIONALLY LEFT BLANK

5.7 PERFORMANCE GRAPHS

LIST OF FIGURES

Figure No.		Page No.
5-1	Conversion Table	5-18
5-2	Temperature Conversion	5-19
5-3	Volume Conversion.....	5-20
5-4	Feet to Meters Conversion (0 to 30,000 feet)	5-21
5-5	Feet to Meters Conversion (0 to 100 feet)	5-22
5-6	Pounds to Kilograms Conversion (3,800 to 5,100 pounds).....	5-23
5-7	Pounds to Kilograms Conversion (0 to 300 pounds).....	5-24
5-8	Inches of Mercury to Millibars Conversion.....	5-25
5-9	ISA Temperature Conversion.....	5-26
5-10	Wind Components	5-27
5-11	Alternate Static System Correction	5-28
5-12	Aviation Fuel Specific Weight	5-29
5-13	Airspeed Calibration, Primary Static (Flaps 0° and 10°).....	5-30
5-15	Airspeed Calibration, Primary Static (Flaps 20°, Gear Down)...	5-31
5-17	Airspeed Calibration, Primary Static (Flaps 36°, Gear Down)...	5-32
5-19	Airspeed Calibration, Alternate Static (Flaps 0° and 10°).....	5-33
5-21	Airspeed Calibration, Alternate Static (Flaps 20°, Gear Down).	5-34
5-23	Airspeed Calibration, Alternate Static (Flaps 36°, Gear Down).	5-35
5-25	Altitude Calibration, Primary Static (Flaps 0° and 10°).....	5-36
5-27	Altitude Calibration, Primary Static (Flaps 20°, Gear Down)....	5-37
5-29	Altitude Calibration, Primary Static (Flaps 36°, Gear Down)....	5-38
5-31	Altitude Calibration, Alternate Static (Flaps 0° and 10°).....	5-39
5-33	Altitude Calibration, Alternate Static (Flaps 20°, Gear Down)..	5-40
5-35	Altitude Calibration, Alternate Static (Flaps 36°, Gear Down)..	5-41
5-39	Angle of Bank vs. Stall Speed	5-43
5-41	Normal Takeoff Ground Roll, 0° Flaps.....	5-44
5-43	Normal Takeoff Performance over 50 ft. Obstacle, 0° Flaps.....	5-45
5-45	Maximum Effort Takeoff Ground Roll, 20° Flaps.....	5-46



5.7 PERFORMANCE GRAPHS (continued)

LIST OF FIGURES (continued)

Figure No.		Page No.
5-47	Maximum Effort Takeoff Performance over 50 ft. Obstacle, 20° Flaps.....	5-47
5-49	Enroute Climb Performance	5-48
5-51	Enroute Climb Gradient.....	5-49
5-53	Takeoff Climb Performance, 0° Flaps	5-50
5-54	Takeoff Climb Performance, 20° Flaps	5-51
5-55	Maximum Climb Time	5-52
5-57	Maximum Climb Fuel.....	5-53
5-59	Maximum Climb Distance.....	5-54
5-61	Cruise Climb Time.....	5-55
5-63	Cruise Climb Fuel.....	5-56
5-65	Cruise Climb Distance.....	5-57
5-67	Maximum Speed Cruise (ISA, ISA -10, ISA -20).....	5-58
5-69	Maximum Speed Cruise (ISA +10, ISA +20, ISA +35).....	5-59
5-75	Low Power Cruise, 500 FT-LB (ISA, ISA -10, ISA -20).....	5-60
5-77	Low Power Cruise, 500 FT-LB (ISA +10, ISA +20, ISA +35).....	5-61
5-79	Intermediate Cruise Power, 600 FT-LB (ISA, ISA -10, ISA -20).....	5-62
5-81	Intermediate Cruise Power, 600 FT-LB (ISA +10, ISA +20, ISA +35).....	5-63
5-83	Intermediate Cruise Power, 700 FT-LB (ISA, ISA -10, ISA -20).....	5-64
5-85	Intermediate Cruise Power, 700 FT-LB (ISA +10, ISA +20, ISA +35).....	5-65
5-87	Intermediate Cruise Power, 800 FT-LB (ISA, ISA -10, ISA -20).....	5-66

5.7 PERFORMANCE GRAPHS (continued)

LIST OF FIGURES (continued)

Figure No.		Page No.
5-89	Intermediate Cruise Power, 800 FT-LB (ISA +10, ISA +20, ISA +35).....	5-67
5-91	Intermediate Cruise Power, 900 FT-LB (ISA, ISA -10, ISA -20).....	5-68
5-93	Intermediate Cruise Power, 900 FT-LB (ISA +10, ISA +20, ISA +35).....	5-69
5-95	Intermediate Cruise Power, 1000 FT-LB (ISA, ISA -10, ISA -20).....	5-70
5-97	Intermediate Cruise Power, 1000 FT-LB (ISA +10, ISA +20, ISA +35).....	5-71
5-99	Intermediate Cruise Power, 1100 FT-LB (ISA, ISA -10, ISA -20).....	5-72
5-101	Intermediate Cruise Power, 1100 FT-LB (ISA +10, ISA +20, ISA +35).....	5-73
5-103	Intermediate Cruise Power, 1200 FT-LB (ISA, ISA -10, ISA -20).....	5-74
5-105	Intermediate Cruise Power, 1200 FT-LB (ISA +10, ISA +20, ISA +35).....	5-75
5-111	Specific Air Range.....	5-76
5-113	Holding Time vs. Fuel on Board.....	5-77
5-115	Time to Descend.....	5-78
5-117	Fuel to Descend.....	5-79
5-119	Distance to Descend.....	5-80
5-121	Glide Endurance.....	5-81
5-123	Glide Distance.....	5-82
5-125	Balked Landing Climb Performance.....	5-83
5-129	Landing Ground Roll, Flaps 36°, Without Reverse.....	5-84
5-131	Landing Distance, Flaps 36°, Without Reverse.....	5-85

THIS PAGE INTENTIONALLY LEFT BLANK

5.7 PERFORMANCE GRAPHS (continued)**LIST OF FIGURES (continued)****METRIC**

Figure No.		Page No.
5-145	Aviation Fuel Specific Weight	5-87
5-147	Airspeed Calibration, Primary Static (Flaps 0° and 10°).....	5-88
5-149	Airspeed Calibration, Primary Static (Flaps 20°, Gear Down)...	5-89
5-151	Airspeed Calibration, Primary Static (Flaps 36°, Gear Down)...	5-90
5-153	Airspeed Calibration, Alternate Static (Flaps 0° and 10°).....	5-91
5-155	Airspeed Calibration, Alternate Static (Flaps 20°, Gear Down).	5-92
5-157	Airspeed Calibration, Alternate Static (Flaps 36°, Gear Down).	5-93
5-159	Altitude Calibration, Primary Static (Flaps 0° and 10°).....	5-94
5-161	Altitude Calibration, Primary Static (Flaps 20°, Gear Down)....	5-95
5-163	Altitude Calibration, Primary Static (Flaps 36°, Gear Down)....	5-96
5-165	Altitude Calibration, Alternate Static (Flaps 0° and 10°).....	5-97
5-167	Altitude Calibration, Alternate Static (Flaps 20°, Gear Down)..	5-98
5-169	Altitude Calibration, Alternate Static (Flaps 36°, Gear Down)..	5-99
5-173	Angle of Bank vs. Stall Speed	5-101
5-175	Normal Takeoff Ground Roll, 0° Flaps.....	5-102
5-177	Normal Takeoff Performance over 50 ft. Obstacle, 0° Flaps.....	5-103
5-179	Maximum Effort Takeoff Ground Roll, 20° Flaps.....	5-104
5-181	Maximum Effort Takeoff Performance over 50 ft. Obstacle, 20° Flaps.....	5-105
5-183	Enroute Climb Performance	5-106
5-185	Enroute Climb Gradient.....	5-107
5-187	Takeoff Climb Performance, 0° Flaps	5-108
5-188	Takeoff Climb Performance, 20° Flaps	5-109
5-189	Maximum Climb Time	5-110

5.7 PERFORMANCE GRAPHS (continued)

LIST OF FIGURES (continued)

METRIC (continued)		
Figure No.		Page No.
5-191	Maximum Climb Fuel.....	5-111
5-193	Maximum Climb Distance.....	5-112
5-195	Cruise Climb Time.....	5-113
5-197	Cruise Climb Fuel.....	5-114
5-199	Cruise Climb Distance.....	5-115
5-201	Maximum Speed Cruise (ISA, ISA -10, ISA -20).....	5-116
5-203	Maximum Speed Cruise (ISA +10, ISA +20, ISA +35).....	5-117
5-209	Low Power Cruise, 500 FT-LB (ISA, ISA -10, ISA -20).....	5-118
5-211	Low Power Cruise, 500 FT-LB (ISA +10, ISA +20, ISA +35).....	5-119
5-213	Intermediate Cruise Power, 600 FT-LB (ISA, ISA -10, ISA -20).....	5-120
5-215	Intermediate Cruise Power, 600 FT-LB (ISA +10, ISA +20, ISA +35).....	5-121
5-217	Intermediate Cruise Power, 700 FT-LB (ISA, ISA -10, ISA -20).....	5-122
5-219	Intermediate Cruise Power, 700 FT-LB (ISA +10, ISA +20, ISA +35).....	5-123
5-221	Intermediate Cruise Power, 800 FT-LB (ISA, ISA -10, ISA -20).....	5-124
5-223	Intermediate Cruise Power, 800 FT-LB (ISA +10, ISA +20, ISA +35).....	5-125
5-225	Intermediate Cruise Power, 900 FT-LB (ISA, ISA -10, ISA -20).....	5-126
5-227	Intermediate Cruise Power, 900 FT-LB (ISA +10, ISA +20, ISA +35).....	5-127

5.7 PERFORMANCE GRAPHS (continued)

LIST OF FIGURES (continued)

Figure No.	METRIC (continued)	Page No.
5-229	Intermediate Cruise Power, 1000 FT-LB (ISA, ISA -10, ISA -20).....	5-128
5-231	Intermediate Cruise Power, 1000 FT-LB (ISA +10, ISA +20, ISA +35).....	5-129
5-233	Intermediate Cruise Power, 1100 FT-LB (ISA, ISA -10, ISA -20).....	5-130
5-235	Intermediate Cruise Power, 1100 FT-LB (ISA +10, ISA +20, ISA +35).....	5-131
5-237	Intermediate Cruise Power, 1200 FT-LB (ISA, ISA -10, ISA -20).....	5-132
5-239	Intermediate Cruise Power, 1200 FT-LB (ISA +10, ISA +20, ISA +35).....	5-133
5-245	Specific Air Range.....	5-134
5-247	Holding Time vs. Fuel on Board.....	5-135
5-249	Time to Descend.....	5-136
5-251	Fuel to Descend.....	5-137
5-253	Distance to Descend.....	5-138
5-255	Glide Endurance.....	5-139
5-257	Glide Distance.....	5-140
5-259	Balked Landing Climb Performance.....	5-141
5-263	Landing Ground Roll, Flaps 36°, Without Reverse.....	5-142
5-265	Landing Distance, Flaps 36°, Without Reverse.....	5-143

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK




CONVERSION TABLE



MULTIPLY	BY	TO OBTAIN
Feet	0.3048	Meters
Meters	3.2808	Feet
Gallons	3.7854	Liters
Liters	0.2642	Gallons
Pounds	0.4536	Kilograms
Kilograms	2.2046	Pounds
Inches of Mercury	33.8639	Millibars
Millibars	0.02953	Inches of Mercury

Example: 50 feet = 50 x 0.3048 meters = 15.24 meters
100 liters = 100 x 0.2642 gallons = 26.42 gallons


Conversion Table
Figure 5-1



Temperature Conversion
Figure 5-2




Volume Conversion
Figure 5-3




Feet to Meters Conversion (0 to 30,000 feet)


Figure 5-4



Feet to Meters Conversion (0 to 100 feet)
Figure 5-5




Pounds to Kilograms Conversion (3,800 to 5,100 pounds)
Figure 5-6





Pounds to Kilograms Conversion (0 to 300 pounds)


Figure 5-7



Inches of Mercury to Millibars Conversion
Figure 5-8




ISA Temperature Conversion
Figure 5-9




EXAMPLE:
 Wind Velocity: 30 Kt
 Angle between flight path and wind: 30°
 Headwind: 26 Kt
 Crosswind: 15 Kt

Demonstrated Crosswind:
17 KTAS




Wind Components

Figure 5-10



CORRECTION CARD ALTERNATE STATIC SOURCE		
<u>PRIMARY</u>		<u>ALTERNATE</u>
<u>ALTITUDE</u>		
1,000		<u>930</u>
2,000		<u>1,930</u>
3,000		<u>2,930</u>
4,000		<u>3,930</u>
5,000		<u>4,930</u>
6,000		<u>5,930</u>
7,000		<u>6,930</u>
8,000		<u>7,930</u>
9,000		<u>8,930</u>
10,000		<u>9,930</u>
11,000		<u>10,930</u>
12,000		<u>11,930</u>
13,000		<u>12,930</u>
<u>AIRSPEED</u>		
125	CLIMB	122
175	CRUISE	172
85	APPROACH	83

Alternate Static System Correction
Figure 5-11



Aviation Fuel Specific Weight
Figure 5-12


SECTION 5
PERFORMANCE

PA-46-500TP




EXAMPLE
Indicated Airspeed: 125 KT
Calibrated Airspeed: 124 KT

ASSOCIATED CONDITIONS
Flaps: 0° & 10°, Gear: RETRACTED




Airspeed Calibration
Primary Static (Flaps 0° and 10°)
Figure 5-13



Airspeed Calibration
Primary Static (Flaps 20°, Gear DOWN)
Figure 5-15

EXAMPLE	
Indicated Airspeed:	105 KT
Calibrated Airspeed:	102 KT


ASSOCIATED CONDITIONS	
Flaps: 36°, Gear: EXTENDED	




Airspeed Calibration

Primary Static (Flaps 36°, Gear DOWN)


Figure 5-17



Airspeed Calibration
Alternate Static (Flaps 0° and 10°)
Figure 5-19



Airspeed Calibration
 Alternate Static (Flaps 20°, Gear DOWN)
 Figure 5-21




Airspeed Calibration
Alternate Static (Flaps 36°, Gear DOWN)
Figure 5-23

EXAMPLE

Indicated Airspeed: 170 KT
 Pressure Altitude: 25,000 FT
 Altitude Correction: -22 FT
 Add Correction to Press. Alt. = 24,978 FT

ASSOCIATED CONDITIONS

Flaps: 0° & 10°
 Gear: RETRACTED



Altitude Calibration

Primary Static (Flaps 0° and 10°)


Figure 5-25

EXAMPLE

Indicated Airspeed: 105 KT
 Pressure Altitude: 4,500 FT
 Altitude Correction: -20 FT
 Add Correction to Press. Alt.: = 4,480 FT

ASSOCIATED CONDITIONS

Flaps: 20°
 Gear: EXTENDED




Altitude Calibration
 Primary Static (Flaps 20°, Gear DOWN)
 Figure 5-27

**EXAMPLE**

Indicated Airspeed: 90 KT
 Pressure Altitude: 5,000 FT
 Altitude Correction: 14 FT
 Add Correction to Press. Alt. = 4,986 FT

ASSOCIATED CONDITIONS

Flaps: 36°
 Gear: EXTENDED



Altitude Calibration

Primary Static (Flaps 36°, Gear DOWN)

Figure 5-29




EXAMPLE


Indicated Airspeed: 170 KT
 Pressure Altitude: 25,000 FT
 Altitude Correction: 19 FT
 Add Correction to Press. Alt. = 25,019 FT

ASSOCIATED CONDITIONS

Flaps: 0° & 10°
 Gear: RETRACTED




Altitude Calibration
 Alternate Static (Flaps 0° and 10°)
 Figure 5-31



EXAMPLE
 Indicated Airspeed: 105 KT
 Pressure Altitude: 4,500 FT
 Altitude Correction: 0 FT
 Add Correction to Press. Alt.: = 4,500 FT


ASSOCIATED CONDITIONS
 Flaps: 20°
 Gear: EXTENDED



Altitude Calibration
 Alternate Static (Flaps 20°, Gear DOWN)
 Figure 5-33

EXAMPLE	
Indicated Airspeed:	90 KT
Pressure Altitude:	5,000 FT
Altitude Correction:	-5 FT
Add Correction to Press. Alt.	= 4,995 FT


ASSOCIATED CONDITIONS	
Flaps:	36°
Gear:	EXTENDED



Altitude Calibration

Alternate Static (Flaps 36°, Gear DOWN)


Figure 5-35



THIS PAGE INTENTIONALLY LEFT BLANK


ASSOCIATED CONDITION
AIRCRAFT WEIGHT: 5,092 LB

EXAMPLE
FLAPS: RETRACTED BANK ANGLE: 54° FLT IDLE
GEAR: RETRACTED POWER: 102 KT
INDICATED STALL SPEED: 102 KT
PRIMARY STATIC SYSTEM




Angle of Bank vs. Stall Speed

Figure 5-39




EXAMPLE	
OAT:	29 °C
Runway Gradient:	2% UP
Pressure Altitude:	1,000 FT.
Takeoff Weight:	4,841 LB.
Headwind Component:	10 KT.
Ground Roll Distance:	1851 FT.

ASSOCIATED CONDITIONS	
Runway:	PAVED, DRY SURFACE
Power:	FULL PRIOR TO BRAKE RELEASE
ECS:	NORMAL
Flaps:	RETRACTED
Rotation Speed:	82 KIAS
Liftoff Speed:	85 KIAS



Normal Takeoff Ground Roll, 0° Flaps
Figure 5-41




Normal Takeoff Performance over 50 ft. Obstacle, 0° Flaps

Figure 5-43


SECTION 5
PERFORMANCE

PA-46-500TP




EXAMPLE	
OAT:	29 °C
Runway Gradient:	2% UP
Pressure Altitude:	1,000 FT.
Takeoff Weight:	4,841 LB.
Headwind Component:	10 KT.
Ground Roll Distance:	1,727 FT.

ASSOCIATED CONDITIONS	
Runway:	PAVED, DRY SURFACE
Power:	FULL PRIOR TO BRAKE RELEASE
ECS:	NORMAL
Flaps:	20°
Rotation Speed:	83 KIAS
Liftoff Speed:	85 KIAS



Maximum Effort Takeoff Ground Roll, 20° Flaps
Figure 5-45



Maximum Effort Takeoff Performance over 50 ft. Obstacle,
20° Flaps
Figure 5-47

SECTION 5
PERFORMANCE

PA-46-500TP




EXAMPLE


OAT: 7°C
 Pressure Altitude: 12,000 FT.
 Aircraft Weight: 4,800 LB.
 Climb Performance: 1,459 FPM

ASSOCIATED CONDITIONS

Power: MAX CONTINUOUS
 ECS: NORMAL
 Flaps: RETRACTED
 Gear: RETRACTED
 Climb Speed: 125 KIAS




Enroute Climb Performance
Figure 5-49



Enroute Climb Gradient
Figure 5-51

SECTION 5
PERFORMANCE

PA-46-500TP




EXAMPLE

OAT: 29°C
 Pressure Altitude: 1,000 FT.
 Aircraft Weight: 4,840 LB.
 Climb Performance: 1,141 FPM

ASSOCIATED CONDITIONS

Power: MAX CONTINUOUS
 ECS: NORMAL
 Flaps: RETRACTED
 Gear: EXTENDED
 Climb Speed: 125 KIAS




Takeoff Climb Performance, 0° Flaps
Figure 5-53

EXAMPLE

OAT: 29.0°C
 Pressure Altitude: 1,000 FT.
 Aircraft Weight: 4,840 LB.
 Climb Performance: 878 FPM

ASSOCIATED CONDITIONS


Power: MAX CONTINUOUS
 ECS: NORMAL
 Flaps: 20°
 Gear: EXTENDED
 Climb Speed: 125 KIAS



Takeoff Climb Performance, 20° Flaps
 Figure 5-54



EXAMPLE			
Departure OAT:	29 °C	Cruise OAT:	-20 °C
Departure Press. Alt.:	1,000 FT.	Cruise Press. Alt.:	25,000 FT.
Time To Departure Alt.:	0.7 Min.	Time To Cruise Alt.:	20 Min
Time During Climb:		$20 - 0.7 = 19.3$ Min	

ASSOCIATED CONDITIONS	
Weight:	MAX TAKEOFF
Power:	MAX CONTINUOUS
Flaps:	RETRACTED
Gear:	RETRACTED
Climb Speed:	125 KIAS



Maximum Climb Time

Figure 5-55





Maximum Climb Fuel

Figure 5-57


SECTION 5
PERFORMANCE

PA-46-500TP




EXAMPLE			
Departure OAT:	29°C	Cruise OAT:	-20°C
Departure Press. Alt:	1,000 FT.	Cruise Press. Alt.:	25,000 FT.
Time To Departure Alt:	1.3 Min.	Time To Cruise Alt.:	23.3 Min
Time During Climb:		23.3 - 1.3 = 22 Min	

ASSOCIATED CONDITIONS	
Weight:	MAX TAKEOFF
Power:	MAX CONTINUOUS
ECS:	NORMAL
Flaps:	RETRACTED
Gear:	RETRACTED
Climb Speed:	140 KIAS to 20,000 FT
	125 KIAS to 30,000 FT

Cruise Climb Time
Figure 5-61

EXAMPLE			
Departure OAT:	29° C	Cruise OAT:	-20° C
Departure Press. Alt.:	1,000 FT.	Cruise Press. Alt.:	25,000 FT.
Fuel To Departure Alt.:	48.1 LB.	Fuel To Cruise Alt.:	170LB.
Fuel Used During Climb: 170 - 48.1 = 121.9 LB.			

ASSOCIATED CONDITIONS	
Weight:	MAX TAKEOFF
Power	MAX CONTINUOUS
ECS	NORMAL
Flaps	RETRACTED
Gear:	RETRACTED
Climb Speed:	140 KIAS TO 20,000 FT
	125 KIAS TO 30,000 FT



Cruise Climb Fuel


Figure 5-63

EXAMPLE

Departure OAT: 29°C Cruise OAT: -20°C
 Departure Press Alt.: 1,000 FT. Cruise Press. Alt.: 25,000 FT.
 Dist. to Departure Alt.: 1.8 NM Dist. to Cruise Alt.: 67.5 NM
 Distance during Climb: 67.5 - 1.8 = 65.7 NM

ASSOCIATED CONDITIONS

Weight: MAX TAKEOFF
 Power: MAX CONTINUOUS
 ECS: NORMAL
 Flaps: RETRACTED
 Gear: RETRACTED
 Climb Speed: 140 KIAS to 20,000 FT
 125 KIAS to 30,000 FT



Cruise Climb Distance
 Figure 5-65



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	-5	943	350	177
5000	-15	998	318	190
10000	-25	1066	293	205
15000	-35	1153	280	222
20000	-45	1255	281	241
25000	-55	1313	282	257
30000	-64	1112	237	255
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	5	956	353	180
5000	-5	1014	322	194
10000	-15	1088	297	209
15000	-25	1177	285	226
20000	-35	1285	286	246
25000	-45	1298	278	260
30000	-54	1077	230	256
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	15	969	355	183
5000	5	1030	325	197
10000	-5	1106	301	213
15000	-15	1201	290	231
20000	-25	1313	291	251
25000	-35	1250	269	260
30000	-44	1040	222	255

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Maximum Speed Cruise
(ISA, ISA -10, ISA -20)

Figure 5-67

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	25	983	360	186
5000	15	1048	330	201
10000	5	1127	305	217
15000	-5	1224	295	235
20000	-15	1313	292	254
25000	-25	1200	260	259
30000	-34	997	214	254
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	35	996	363	189
5000	25	1064	334	204
10000	15	1148	310	221
15000	5	1248	299	240
20000	-5	1310	292	257
25000	-15	1147	250	258
30000	-24	955	207	253
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	50	1017	368	194
5000	40	1088	339	209
10000	30	1177	317	227
15000	20	1285	307	246
20000	10	1201	274	253
25000	0	1071	237	255
30000	-9	890	195	250

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Maximum Speed Cruise
(ISA +10, ISA +20, ISA +35)

Figure 5-69



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	-5		292	129
5000	-15		252	138
10000	-25		213	147
15000	-35	500	185	155
20000	-45		161	164
25000	-55		143	171
30000	-64		129	178
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	5		292	131
5000	-5		252	140
10000	-15		214	149
15000	-25	500	185	157
20000	-35		161	166
25000	-45		143	173
30000	-54		129	180
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	15		292	133
5000	5		253	142
10000	-5		215	151
15000	-15	500	185	159
20000	-25		162	167
25000	-35		143	175
30000	-44		129	182

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Low Power Cruise, 500 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-75

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	25	500	293	136
5000	15		254	144
10000	5		215	153
15000	-5		185	161
20000	-15		162	169
25000	-25		143	177
30000	-34		130	183
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	35	500	293	137
5000	25		254	146
10000	15		216	155
15000	5		186	163
20000	-5		162	171
25000	-15		143	178
30000	-24		130	184
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	50	500	294	141
5000	40		255	149
10000	30		217	157
15000	20		187	165
20000	10		164	173
25000	0		145	180
30000	-9		131	185

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Low Power Cruise, 500 FT-LB
(ISA +10, ISA +20, ISA +35)

Figure 5-77

SECTION 5
PERFORMANCE

PA-46-500TP



ISA -20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	-5	600	306	144
5000	-15		264	153
10000	-25		227	162
15000	-35		197	170
20000	-45		175	179
25000	-55		157	188
30000	-64		145	197
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	5	600	306	146
5000	-5		265	155
10000	-15		227	164
15000	-25		198	173
20000	-35		175	182
25000	-45		157	191
30000	-54		145	199
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	15	600	307	148
5000	5		266	157
10000	-5		227	166
15000	-15		199	175
20000	-25		176	184
25000	-35		158	193
30000	-44		145	202

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 600 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-79

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	25	600	308	150
5000	15		267	159
10000	5		228	168
15000	-5		199	177
20000	-15		176	186
25000	-25		158	195
30000	-34		145	204
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	35	600	308	152
5000	25		268	161
10000	15		228	170
15000	5		200	179
20000	-5		177	188
25000	-15		159	197
30000	-24		146	205
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	50	600	309	156
5000	40		269	164
10000	30		230	173
15000	20		201	182
20000	10		178	191
25000	0		159	200
30000	-9		146	208

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 600 FT-LB
(ISA +10, ISA +20, ISA +35)**

Figure 5-81

SECTION 5
PERFORMANCE

PA-46-500TP



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	-5	700	318	156
5000	-15		277	165
10000	-25		240	174
15000	-35		211	183
20000	-45		189	192
25000	-55		172	202
30000	-64		161	212
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	5	700	319	158
5000	-5		278	167
10000	-15		240	176
15000	-25		212	185
20000	-35		190	195
25000	-45		172	205
30000	-54		161	215
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	15	700	320	160
5000	5		278	169
10000	-5		241	178
15000	-15		212	187
20000	-25		190	197
25000	-35		172	207
30000	-44		161	217

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 700 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-83

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	25	700	321	162
5000	15		279	171
10000	5		242	180
15000	-5		213	190
20000	-15		191	199
25000	-25		173	210
30000	-34		162	220
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	35	700	322	164
5000	25		280	173
10000	15		243	182
15000	5		214	192
20000	-5		191	202
25000	-15		174	212
30000	-24		162	222
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	50	700	324	167
5000	40		282	176
10000	30		244	185
15000	20		215	195
20000	10		192	205
25000	0		175	215
30000	-9		163	225

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 700 FT-LB
(ISA +10, ISA +20, ISA +35)

Figure 5-85



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	-5	800	331	165
5000	-15		291	174
10000	-25		254	184
15000	-35		225	193
20000	-45		204	203
25000	-55		188	214
30000	-64		178	225
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	5	800	332	168
5000	-5		292	177
10000	-15		255	186
15000	-25		226	196
20000	-35		204	206
25000	-45		188	217
30000	-54		178	228
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	15	800	333	170
5000	5		293	179
10000	-5		255	188
15000	-15		227	198
20000	-25		205	209
25000	-35		189	219
30000	-44		178	230

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 800 FT-LB
(ISA, ISA -10, ISA -20)**

Figure 5-87

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	25		334	172
5000	15		294	181
10000	5		256	191
15000	-5	800	228	201
20000	-15		205	211
25000	-25		189	222
30000	-34		178	233
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	35		335	174
5000	25		295	183
10000	15		257	193
15000	5	800	228	203
20000	-5		206	213
25000	-15		190	224
30000	-24		179	235
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	50		337	177
5000	40		296	186
10000	30		259	196
15000	20	800	230	206
20000	10		208	217
25000	0		191	228
30000	-9		179	239

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 800 FT-LB
(ISA +10, ISA +20, ISA +35)

Figure 5-89

SECTION 5
PERFORMANCE

PA-46-500TP



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	-5	900	344	174
5000	-15		305	183
10000	-25		268	193
15000	-35		241	203
20000	-45		220	213
25000	-55		205	224
30000	-64		196	236
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	5	900	345	176
5000	-5		306	185
10000	-15		269	195
15000	-25		241	205
20000	-35		220	216
25000	-45		205	227
30000	-54		196	239
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	15	900	346	178
5000	5		307	188
10000	-5		270	198
15000	-15		242	208
20000	-25		220	219
25000	-35		206	230
30000	-44		196	242

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 900 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-91

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	25	900	348	180
5000	15		308	190
10000	5		271	200
15000	-5		243	210
20000	-15		221	221
25000	-25		206	233
30000	-34		196	245
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	35	900	349	182
5000	25		309	192
10000	15		272	202
15000	5		243	213
20000	-5		222	224
25000	-15		207	235
30000	-24		196	247
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	50	900	351	185
5000	40		311	195
10000	30		274	205
15000	20		245	216
20000	10		223	227
25000	0		207	239
30000	-		197	251

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 900 FT-LB
(ISA +10, ISA +20, ISA +35)**

Figure 5-93



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	-5		-	-
5000	-15		319	191
10000	-25		283	201
15000	-35	1000	255	211
20000	-45		236	222
25000	-55		222	233
30000	-64		215	246
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	5		360	184
5000	-5		320	193
10000	-15		284	203
15000	-25	1000	256	214
20000	-35		237	225
25000	-45		222	237
30000	-54		215	249
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	15		361	186
5000	5		321	196
10000	-5		285	206
15000	-15	1000	257	216
20000	-25		237	228
25000	-35		223	240
30000	-44		214	252

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 1000 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-95

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	25	1000	362	188
5000	15		323	198
10000	5		286	208
15000	-5		258	219
20000	-15		238	230
25000	-25		223	242
30000	-34		215	255
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	35	1000	364	190
5000	25		324	200
10000	15		287	210
15000	5		259	221
20000	-5		239	233
25000	-15		223	245
30000	-24		212	258
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	50	1000	366	193
5000	40		327	203
10000	30		288	214
15000	20		261	225
20000	10		239	237
25000	0		224	249
30000	-9		199	262

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 1000 FT-LB
(ISA +10, ISA +20, ISA +35)**

Figure 5-97



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	-5		-	-
5000	-15		-	-
10000	-25		298	208
15000	-35	1100	271	219
20000	-45		253	230
25000	-55		241	242
30000	-64		234	255
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	5		-	-
5000	-5		-	-
10000	-15		299	211
15000	-25	1100	271	221
20000	-35		254	233
25000	-45		241	245
30000	-54		234	258
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	15		-	-
5000	5		-	-
10000	-5		300	213
15000	-15	1100	273	224
20000	-25		254	236
25000	-35		241	248
30000	-44		229	261

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 1100 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-99

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	25		-	-
5000	15		-	-
10000	5	1100	301	216
15000	-5	1100	274	227
20000	-15	1100	255	239
25000	-25	1100	241	251
30000	-34	1100	221	264
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	35		-	-
5000	25		339	207
10000	15	1100	302	218
15000	5	1100	275	229
20000	-5	1100	256	241
25000	-15	1100	241	254
30000	-24	1100	-	-
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	50		-	-
5000	40		341	211
10000	30	1100	304	222
15000	20	1100	276	233
20000	10	1100	256	245
25000	0	1100	238	258
30000	-9	1100	-	-

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 1100 FT-LB
(ISA +10, ISA +20, ISA +35)**

Figure 5-101



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	-5		-	-
5000	-15		-	-
10000	-25		-	-
15000	-35	1200	-	-
20000	-45		270	237
25000	-55		259	250
30000	-64		-	-
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	5		-	-
5000	-5		-	-
10000	-15		-	-
15000	-25	1200	289	229
20000	-35		271	240
25000	-45		259	253
30000	-54		239	266
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	15		-	-
5000	5		-	-
10000	-5		-	-
15000	-15	1200	290	231
20000	-25		271	243
25000	-35		259	256
30000	-44		-	-

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 1200 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-103


ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	25		-	-
5000	15		-	-
10000	5		-	-
15000	-5	1200	290	234
20000	-15		272	246
25000	-25		260	259
30000	-34		-	-
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	35		-	-
5000	25		-	-
10000	15		-	-
15000	5	1200	291	237
20000	-5		272	249
25000	-15		254	262
30000	-24		-	-
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (PPH)*	TAS (KT)
0	50		-	-
5000	40		-	-
10000	30		321	229
15000	20	1200	292	241
20000	10		273	253
25000	0		238	267
30000	-9		-	-

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 1200 FT-LB
(ISA +10, ISA +20, ISA +35)**

Figure 5-105



MAXIMUM SPEED CRUISE

Altitude FT	Cruise Nautical Miles / 100 Lbs. Fuel					
	ISA - 20° C	ISA - 10° C	ISA	ISA + 10° C	ISA + 20° C	ISA + 35° C
0	50.6	51.0	51.5	51.7	52.1	52.7
5000	59.7	60.2	60.6	60.9	61.1	61.7
10000	70.0	70.4	70.8	71.1	71.3	71.6
15000	79.4	79.3	79.7	79.7	80.3	80.1
20000	85.8	86.0	86.3	87.0	88.0	92.3
25000	91.1	93.5	96.7	99.6	103.2	107.6
30000	107.8	111.3	114.9	118.7	122.2	128.2

INTERMEDIATE POWER CRUISE - 1000 FT-LB

Altitude FT	Cruise Nautical Miles / 100 Lbs. Fuel					
	ISA - 20° C	ISA - 10° C	ISA	ISA + 10° C	ISA + 20° C	ISA + 35° C
0	-	51.1	51.5	51.9	52.3	52.9
5000	59.8	60.4	60.9	61.3	61.7	62.3
10000	70.9	71.6	72.2	72.8	73.4	74.2
15000	82.6	83.5	84.3	84.9	85.5	86.3
20000	93.9	94.9	95.9	96.9	97.7	98.9
25000	104.9	108.4	107.6	108.6	109.7	111.1
30000	114.4	116.1	117.6	118.9	121.9	131.8

LOW POWER CRUISE-500 FT-LB

Altitude FT	Cruise Nautical Miles / 100 Lbs. Fuel					
	ISA - 20° C	ISA - 10° C	ISA	ISA + 10° C	ISA + 20° C	ISA + 35° C
0	44.3	44.9	45.6	46.4	46.9	47.9
5000	54.9	55.6	56.3	56.8	57.4	58.3
10000	68.9	69.7	70.4	71.0	71.6	72.5
15000	84.1	85.1	86.1	87.0	87.7	88.5
20000	101.8	102.8	103.6	104.3	105.4	105.9
25000	119.9	121.2	122.3	123.1	124.2	124.5
30000	138.5	139.4	140.3	140.9	141.2	141.6

Note:


ECS: NORMAL

Shaded areas are beyond aircraft OAT limit. See paragraph 2.28.

Does not include 45 minute reserve, 26 gal. (174.2 Lb).

To obtain 45 minute reserve endurance set power to Low Power Cruise @ 5,000'.


Specific Air Range
Figure 5-111



Holding Time vs. Fuel On Board
Figure 5-113

SECTION 5
PERFORMANCE

PA-46-500TP




EXAMPLE

Cruise OAT: -20 °C Destination OAT: 25 °C
 Cruise Press. Alt.: 25,000 FT. Destination Press. Alt.: 3,500 FT.
 Time To Descend.: 16.6 Min Time To Descend: 2.6 Min.
 Time During Descent: 16.6 - 2.6 = 14.0 Min

ASSOCIATED CONDITIONS

Power: 350 FT-LB
 ECS: NORMAL
 Flaps & Gear: RETRACTED
 Descent Speed: 170 KIAS at 3,000 LB
 174 KIAS at 4,400 LB
 179 KIAS at 5,092 LB




Time to Descend
Figure 5-115

EXAMPLE

Cruise OAT: -20 °C Destination OAT: 25 °C
 Cruise Press. Alt.: 25,000 FT. Destination Press. Alt.: 3,500 FT.
 Fuel To Descend: 50.1 LB. Fuel To Descend: 10.7 LB.
 Fuel Used During Descent: 50.1 - 10.7 = 39.4 LB.

ASSOCIATED CONDITIONS

Power 350 FT-LB
 Flaps & Gear RETRACTED
 Descent Speed: 170 KIAS AT 3,800 LB
 174 KIAS AT 4,400 LB
 179 KIAS AT 5,092 LB



Fuel to Descend

Figure 5-117

SECTION 5
PERFORMANCE

PA-46-500TP




EXAMPLE

Cruise OAT: -20 °C Destination OAT: 26 °C
 Cruise Press. Alt.: 25,000 FT. Destination Press Alt.: 3,500 FT.
 Dist. to Descend: 60.2 NM Dist. to Descend: 8.2 NM
 Distance during Climb: 80.2 - 8.2 = 52 NM

ASSOCIATED CONDITIONS

Power: 350 FT-LB
 ECS: NORMAL
 Flaps & Gear: RETRACTED
 Descent Speed: 170 KIAS AT 3,800 LB
 179 KIAS AT 4,400 LB
 179 KIAS AT 5,092 LB




Distance to Descend
Figure 5-119

EXAMPLE

Weight: 4,350 LB Airspeed: 100 KIAS
 Cruise OAT: -20° C Destination OAT: 25° C
 Cruise Press. Alt.: 25,000 FT. Destination Press. Alt.: 3,500 FT.
 Glide Time: 36.02 Min Glide Time: 5.92 Min.
 Glide Endurance: 36 - 6 = 30 Min

ASSOCIATED CONDITIONS

Power: OUT
 Flaps And Gear: RETRACTED
 Propeller: FEATHERED




Glide Endurance
Figure 5-121



EXAMPLE
Cruise Press. Alt.: 25,000 Ft. Dest. Press. Alt.: 3,500 Ft.
Cruise Glide Range: 72.4 N.M. Dest. Glide Range: 9.8 N.M.
Glide Range: 72.4 + 9.8 = 62.6 N.M.

ASSOCIATED CONDITIONS
Flaps And Gear: RETRACTED
Propeller: FEATHERED
Power: OFF




Glide Distance
Figure 5-123

EXAMPLE

OAT: 25 °C
 Pressure Altitude: 3500 FT.
 Aircraft Weight: 4,500 LB.
 Climb Performance: 1,113 FPM


ASSOCIATED CONDITIONS

Power: MAX CONTINUOUS
 ECS: NORMAL
 Flaps: 36°
 Gear: EXTENDED
 Climb Speed: 85 KIAS



Balked Landing Climb Performance

Figure 5-125



Landing Ground Roll, Flaps 36°, without Reverse


Figure 5-129

EXAMPLE

OAT: 25 °C
 Runway Gradient: 2% UP
 Pressure Altitude: 3,600 FT.
 Headwind Component: 5 KT.
 Landing Distance: 2,205 FT.

ASSOCIATED CONDITIONS


Runway: PAVED, LEVEL, DRY SURFACE
 Weight: 4,860 LB.
 Approach Power: 280 FT-LB.
 Flaps: 36°
 Approach Speed: 85 KIAS
 Touch Down Speed: 78 KIAS
 Braking: MODERATE WITH BETA



Landing Distance, Flaps 36°, without Reverse
 Figure 5-131



THIS PAGE INTENTIONALLY LEFT BLANK




Aviation Fuel Specific Weight

Figure 5-145



EXAMPLE	
Indicated Airspeed:	125 KT
Calibrated Airspeed:	124 KT


ASSOCIATED CONDITIONS
Flaps: 0° & 10°, Gear: RETRACTED



Airspeed Calibration

Primary Static (Flaps 0° and 10°)

Figure 5-147




Airspeed Calibration
Primary Static (Flaps 20°, Gear DOWN)
Figure 5-149




EXAMPLE
Indicated Airspeed: 106 KT
Calibrated Airspeed: 102 KT

ASSOCIATED CONDITIONS
Flaps: 36°, Gear: EXTENDED




Airspeed Calibration
Primary Static (Flaps 36°, Gear DOWN)
Figure 5-151




EXAMPLE
Indicated Airspeed: 125 KT
Calibrated Airspeed: 126 KT

ASSOCIATED CONDITIONS
Flaps: 0° & 10°, Gear: RETRACTED




Airspeed Calibration
Alternate Static (Flaps 0° and 10°)
Figure 5-153



Airspeed Calibration
Alternate Static (Flaps 20°, Gear DOWN)
Figure 5-155

EXAMPLE
Indicated Airspeed: 105 KT
Calibrated Airspeed: 104 KT

ASSOCIATED CONDITIONS
Flaps: 36° Gear: EXTENDED




Airspeed Calibration
Alternate Static (Flaps 36°, Gear DOWN)
Figure 5-157



EXAMPLE
 Indicated Airspeed: 170 KT
 Pressure Altitude: 25,000 FT
 Altitude Correction: -22 FT
 Add Correction to Press. Alt. = 24,978 FT


ASSOCIATED CONDITIONS
 Flaps: 0° & 10°
 Gear: RETRACTED




Altitude Calibration
 Primary Static (Flaps 0° and 10°)
 Figure 5-159

EXAMPLE	
Indicated Airspeed:	105 KT
Pressure Altitude:	4,500 FT
Altitude Correction:	-20 FT
Add Correction to Press. Alt. =	4,480 FT

ASSOCIATED CONDITIONS	
Flaps:	20°
Gear:	EXTENDED




Altitude Calibration
Primary Static (Flaps 20°, Gear DOWN)
Figure 5-161



EXAMPLE
 Indicated Airspeed: 90 KT
 Pressure Altitude: 5,000 FT
 Altitude Correction: 14 FT
 Add Correction to Press. Alt. = 4,986 FT


ASSOCIATED CONDITIONS
 Flaps: 36°
 Gear: EXTENDED



Altitude Calibration
 Primary Static (Flaps 36°, Gear DOWN)
 Figure 5-163

EXAMPLE
 Indicated Airspeed: 170 KT
 Pressure Altitude: 25,000 FT
 Altitude Correction: 19 FT
 Add Correction to Press. Alt. = 25,019 FT


ASSOCIATED CONDITIONS
 Flaps: 0° & 10°
 Gear: RETRACTED



Altitude Calibration
 Alternate Static (Flaps 0° and 10°)
 Figure 5-165

EXAMPLE	
Indicated Airspeed:	105 KT
Pressure Altitude:	4,500 FT
Altitude Correction:	0 FT
Add Correction to Press. Alt. =	4,500 FT

ASSOCIATED CONDITIONS	
Flaps:	20°
Gear:	EXTENDED




Altitude Calibration
Alternate Static (Flaps 20°, Gear DOWN)
Figure 5-167

EXAMPLE

Indicated Airspeed: 90 KT
 Pressure Altitude: 5,000 FT
 Altitude Correction: -5 FT
 Add Correction to Press. Alt. = 4,995 FT

ASSOCIATED CONDITIONS


Flaps: 36°
 Gear: EXTENDED



Altitude Calibration
 Alternate Static (Flaps 36°, Gear DOWN)
 Figure 5-169




THIS PAGE INTENTIONALLY LEFT BLANK




Angle of Bank vs. Stall Speed

Figure 5-173



EXAMPLE	
OAT:	29 °C
Runway Gradient:	2% UP
Pressure Altitude:	1,000 FT.
Takeoff Weight:	2,196 Kg.
Headwind Component:	10 KT.
Ground Roll Distance:	564 M.

ASSOCIATED CONDITIONS	
Runway:	PAVED, DRY SURFACE
Power:	FULL PRIOR TO BRAKE RELEASE
ECS:	NORMAL
Flaps:	RETRACTED
Rotation Speed :	82 KIAS
Liftoff Speed:	85 KIAS




Normal Takeoff Ground Roll, 0° Flaps
Figure 5-175



EXAMPLE	
OAT:	29 °C
Runway Gradient:	2% UP
Pressure Altitude:	1,000 FT.
Takeoff Weight:	2,196 Kg.
Headwind Component:	10 KT
Takeoff Distance:	885 FT.

ASSOCIATED CONDITIONS	
Runway:	PAVED, DRY SURFACE
Power:	FULL PRIOR TO BRAKE RELEASE
ECS:	NORMAL
Flaps:	RETRACTED
Rotation Speed:	82 KIAS
Liftoff Speed:	85 KIAS
Obstacle Speed:	100 KIAS
Gear:	Down



Normal Takeoff Performance over 50 ft. Obstacle, 0° Flaps

Figure 5-177




EXAMPLE


OAT: 28 °C
 Runway Gradient: 2% UP
 Pressure Altitude: 1,000 FT.
 Takeoff Weight: 2,186 Kg.
 Headwind Component: 10 KT.
 Ground Roll Distance: 526 M.

ASSOCIATED CONDITIONS

Runway: PAVED, DRY SURFACE
 Power: FULL PRIOR TO BRAKE RELEASE
 ECS: NORMAL
 Flaps: 20°
 Rotation Speed: 83 KIAS
 Liftoff Speed: 86 KIAS




Maximum Effort Takeoff Ground Roll, 20° Flaps
Figure 5-179





Maximum Effort Takeoff Performance over 50 ft. Obstacle,
 20° Flaps

Figure 5-181



Enroute Climb Performance

Figure 5-183






EXAMPLE

OAT: 29°C
 Pressure Altitude: 1,000 FT.
 Aircraft Weight: 2,195 KG.
 Climb Performance: 1,141 FPM

ASSOCIATED CONDITIONS


Power: MAX CONTINUOUS
 ECS: NORMAL
 Flaps: RETRACTED
 Gear: EXTENDED
 Climb Speed: 125 KIAS



Takeoff Climb Performance, 0° Flaps
Figure 5-187

EXAMPLE	
OAT:	29.0°C
Pressure Altitude:	1,000 FT.
Aircraft Weight:	2195 KG.
Climb Performance:	878 FPM

ASSOCIATED CONDITIONS	
Power:	MAX CONTINUOUS
ECS:	NORMAL
Flaps:	20°
Gear:	EXTENDED
Climb Speed:	125 KIAS



Takeoff Climb Performance, 20° Flaps
Figure 5-188




EXAMPLE

Departure OAT: 29 °C Cruise OAT: -20 °C
 Departure Press. Alt.: 1,000 FT. Cruise Press. Alt.: 25,000 FT.
 Time To Departure Alt.: 0.7 Min. Time To Cruise Alt.: 20 Min
 Time During Climb: 20 - 0.7 = 19.3 Min

ASSOCIATED CONDITIONS

Weight: MAX TAKEOFF
 Power: MAX CONTINUOUS
 Flaps: RETRACTED
 Gear: RETRACTED
 Climb Speed: 125 KIAS




Maximum Climb Time
Figure 5-189

ASSOCIATED CONDITIONS

Weight: MAX TAKEOFF
 Power: MAX CONTINUOUS
 Flaps: RETRACTED
 Gear: RETRACTED
 Climb Speed: 125 KIAS



EXAMPLE

Departure OAT: 29 °C Cruise OAT: -20 °C
 Departure Press. Alt.: 1,000 FT. Cruise Press. Alt.: 25,000 FT.
 Fuel To Departure Alt.: 22 KG. Fuel To Cruise Alt.: 69 KG.
 Fuel Used During Climb: 69 - 22 = 47 KG.



Maximum Climb Fuel

Figure 5-191



Maximum Climb Distance


Figure 5-193

EXAMPLE



Departure OAT: 29° C Cruise OAT: -20° C
 Departure Press. Alt.: 1,000 FT. Cruise Press. Alt.: 25,000 FT.
 Time To Departure Alt.: 1.3 Min. Time To Cruise Alt.: 23.3 Min
 Time During Climb: 23.3 - 1.3 = 22 Min

ASSOCIATED CONDITIONS

Weight: MAX TAKEOFF
 Power: MAX CONTINUOUS
 ECS: NORMAL
 Flaps: RETRACTED
 Gear: RETRACTED
 Climb Speed: 140 KIAS to 20,000 FT
 125 KIAS to 30,000 FT



Cruise Climb Time
 Figure 5-195




Cruise Climb Fuel
Figure 5-197

EXAMPLE

Departure OAT: 29°C Cruise OAT: -20°C
 Departure Press Alt.: 1,000 FT. Cruise Press. Alt.: 25,000 FT.
 Dist. to Departure Alt.: 1.8 NM Dist. to Cruise Alt.: 67.5 NM
 Distance during Climb: 67.5 • 1.8 = 65.7 NM

ASSOCIATED CONDITIONS

Weight: MAX TAKEOFF
 Power: MAX CONTINUOUS
 ECS: NORMAL
 Flaps: RETRACTED
 Gear: RETRACTED
 Climb Speed: 140 KIAS to 20,000 FT
 125 KIAS to 30,000 FT



Cruise Climb Distance

Figure 5-199

ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	-5	943	158.6	177
5000	-15	998	144.2	190
10000	-25	1066	132.9	205
15000	-35	1153	126.8	222
20000	-45	1255	127.5	241
25000	-55	1313	127.9	257
30000	-64	1112	107.3	255
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	5	956	160.1	180
5000	-5	1014	146.1	194
10000	-15	1088	134.7	209
15000	-25	1177	129.3	226
20000	-35	1285	129.7	246
25000	-45	1298	126.1	260
30000	-54	1077	104.3	256
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	15	969	161.0	183
5000	5	1030	147.4	197
10000	-5	1106	136.5	213
15000	-15	1201	131.5	231
20000	-25	1313	132.0	251
25000	-35	1250	122.0	260
30000	-44	1040	100.7	255

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Maximum Speed Cruise
(ISA, ISA -10, ISA -20)

Figure 5-201

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	25	983	163.3	186
5000	15	1048	149.7	201
10000	5	1127	138.3	217
15000	-5	1224	133.8	235
20000	-15	1313	132.4	254
25000	-25	1200	117.9	259
30000	-34	997	97.1	254
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	35	996	164.7	189
5000	25	1064	151.5	204
10000	15	1148	140.6	221
15000	5	1248	135.6	240
20000	-5	1310	132.4	257
25000	-15	1147	113.4	258
30000	-24	955	93.9	253
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	50	1017	166.9	194
5000	40	1088	153.8	209
10000	30	1177	143.8	227
15000	20	1285	139.3	246
20000	10	1201	124.3	253
25000	0	1071	107.5	255
30000	-9	890	88.5	250

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Maximum Speed Cruise
(ISA +10, ISA +20, ISA +35)

Figure 5-203

SECTION 5 • METRIC
PERFORMANCE

PA-46-500TP



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	-5	500	132.2	129
5000	-15		114.2	138
10000	-25		96.8	147
15000	-35		83.8	155
20000	-45		72.8	164
25000	-55		64.8	171
30000	-64		58.4	178
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	5	500	132.4	131
5000	-5		114.5	140
10000	-15		97.0	149
15000	-25		83.8	157
20000	-35		73.0	166
25000	-45		64.8	173
30000	-54		58.6	180
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	15	500	132.6	133
5000	5		114.8	142
10000	-5		97.3	151
15000	-15		83.9	159
20000	-25		73.3	167
25000	-35		64.9	175
30000	-44		58.7	182

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Low Power Cruise, 500 FT-LB
(ISA, ISA -10, ISA -20)
Figure 5-209

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	25		132.8	136
5000	15		115.2	144
10000	5		97.6	153
15000	-5	500	84.0	161
20000	-15		73.5	169
25000	-25		65.1	177
30000	-34		58.9	183
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	35		133.1	137
5000	25		115.4	146
10000	15		97.9	155
15000	5	500	84.3	163
20000	-5		73.5	171
25000	-15		65.1	178
30000	-24		59.1	184
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	50		133.5	141
5000	40		115.7	149
10000	30		98.4	157
15000	20	500	84.7	165
20000	10		74.2	173
25000	0		65.7	180
30000	-9		59.4	185

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Low Power Cruise, 500 FT-LB
(ISA +10, ISA +20, ISA +35)

Figure 5-211



ISA -20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	-5		138.6	144
5000	-15		119.9	153
10000	-25		102.8	162
15000	-35	600	89.5	170
20000	-45		79.4	179
25000	-55		71.1	188
30000	-64		65.6	197
ISA -10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	5		139.0	146
5000	-5		120.2	155
10000	-15		102.9	164
15000	-25	600	89.7	173
20000	-35		79.5	182
25000	-45		71.3	191
30000	-54		65.6	199
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	15		139.4	148
5000	5		120.6	157
10000	-5		103.0	166
15000	-15	600	90.1	175
20000	-25		79.6	184
25000	-35		71.5	193
30000	-44		65.6	202

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 600 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-213


ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	25	600	139.7	150
5000	15		121.0	159
10000	5		103.2	168
15000	-5		90.4	177
20000	-15		79.8	186
25000	-25		71.7	195
30000	-34		65.8	204
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	35	600	139.9	152
5000	25		121.4	161
10000	15		103.6	170
15000	5		90.7	179
20000	-5		80.1	188
25000	-15		71.9	197
30000	-24		66.0	205
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	50	600	140.3	156
5000	40		122.0	164
10000	30		104.3	173
15000	20		91.2	182
20000	10		80.6	191
25000	0		72.3	200
30000	-9		66.3	208

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 600 FT-LB
(ISA +10, ISA +20, ISA +35)**

Figure 5-215



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	-5	700	144.4	156
5000	-15		125.8	165
10000	-25		108.7	174
15000	-35		95.9	183
20000	-45		85.8	192
25000	-55		78.1	202
30000	-64		72.8	212
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	5	700	144.9	158
5000	-5		125.9	167
10000	-15		109.1	176
15000	-25		96.0	185
20000	-35		86.0	195
25000	-45		78.1	205
30000	-54		73.0	215
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	15	700	145.3	160
5000	5		126.2	169
10000	-5		109.5	178
15000	-15		96.3	187
20000	-25		86.3	197
25000	-35		78.1	207
30000	-44		73.1	217

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 700 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-217

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	25	700	145.8	162
5000	15		126.5	171
10000	5		109.9	180
15000	-5		96.6	190
20000	-15		86.6	199
25000	-25		78.4	210
30000	-34		73.3	220
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	35	700	146.3	164
5000	25		127.1	173
10000	15		110.3	182
15000	5		97.0	192
20000	-5		86.8	202
25000	-15		78.7	212
30000	-24		73.5	222
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	50	700	147.0	167
5000	40		128.0	176
10000	30		110.9	185
15000	20		97.7	195
20000	10		87.2	205
25000	0		79.2	215
30000	-9		73.8	225

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 700 FT-LB
(ISA +10, ISA +20, ISA +35)**

Figure 5-219



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	-5	800	150.0	165
5000	-15		131.8	174
10000	-25		115.1	184
15000	-35		102.2	193
20000	-45		92.5	203
25000	-55		85.3	214
30000	-64		80.7	225
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	5	800	150.4	168
5000	-5		132.3	177
10000	-15		115.4	186
15000	-25		102.6	196
20000	-35		92.7	206
25000	-45		85.5	217
30000	-54		80.8	228
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	15	800	150.8	170
5000	5		132.7	179
10000	-5		115.8	188
15000	-15		103.0	198
20000	-25		92.9	209
25000	-35		85.7	219
30000	-44		80.8	230

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 800 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-221

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	25	800	151.4	172
5000	15		133.3	181
10000	5		116.2	191
15000	-5		103.3	201
20000	-15		93.1	211
25000	-25		85.9	222
30000	-34		80.9	233
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	35	800	151.9	174
5000	25		133.7	183
10000	15		116.7	193
15000	5		103.6	203
20000	-5		93.6	213
25000	-15		86.1	224
30000	-24		81.0	235
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	50	800	153.1	177
5000	40		134.4	186
10000	30		117.5	196
15000	20		104.2	206
20000	10		94.2	217
25000	0		86.5	228
30000	-9		81.2	239

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 800 FT-LB
(ISA +10, ISA +20, ISA +35)**

Figure 5-223



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	-5	900	156.0	174
5000	-15		138.3	183
10000	-25		121.5	193
15000	-35		109.1	203
20000	-45		99.6	213
25000	-55		92.9	224
30000	-64		89.1	236
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	5	900	156.4	176
5000	-5		138.8	185
10000	-15		121.8	195
15000	-25		109.4	205
20000	-35		99.6	216
25000	-45		93.1	227
30000	-54		89.1	239
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	15	900	157.0	178
5000	5		139.3	188
10000	-5		122.3	198
15000	-15		109.7	208
20000	-25		99.9	219
25000	-35		93.3	230
30000	-44		89.0	242

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 900 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-225

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	25	900	157.7	180
5000	15		139.8	190
10000	5		122.7	200
15000	-5		110.0	210
20000	-15		100.3	221
25000	-25		93.5	233
30000	-34		89.1	245
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	35	900	158.3	182
5000	25		140.3	192
10000	15		123.3	202
15000	5		110.4	213
20000	-5		100.7	224
25000	-15		93.8	235
30000	-24		89.1	247
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	50	900	159.4	185
5000	40		141.3	195
10000	30		124.2	205
15000	20		111.1	216
20000	10		101.2	227
25000	0		94.1	239
30000	-		89.2	251

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 900 FT-LB
(ISA +10, ISA +20, ISA +35)

Figure 5-227

ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	-5	1000	-	-
5000	-15		144.6	191
10000	-25		128.4	201
15000	-35		115.8	211
20000	-45		107.1	222
25000	-55		100.9	233
30000	-64		97.4	246
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	5	1000	163.2	184
5000	-5		145.1	193
10000	-15		128.8	203
15000	-25		116.1	214
20000	-35		107.4	225
25000	-45		100.9	237
30000	-54		97.3	249
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	15	1000	163.8	186
5000	5		145.7	196
10000	-5		129.2	206
15000	-15		116.4	216
20000	-25		107.7	228
25000	-35		101.0	240
30000	-44		97.2	252

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 1000 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-229

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	25	1000	164.3	188
5000	15		146.4	198
10000	5		129.7	208
15000	-5		116.9	219
20000	-15		107.8	230
25000	-25		101.2	242
30000	-34		97.3	255
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	35	1000	165.0	190
5000	25		147.1	200
10000	15		130.1	210
15000	5		117.5	221
20000	-5		108.2	233
25000	-15		101.3	245
30000	-24		96.0	258
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	50	1000	165.9	193
5000	40		148.1	203
10000	30		130.8	214
15000	20		118.2	225
20000	10		108.6	237
25000	0		101.7	249
30000	-9		90.2	262

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 1000 FT-LB
(ISA +10, ISA +20, ISA +35)**

Figure 5-231



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	-5		-	-
5000	-15		-	-
10000	-25		135.4	208
15000	-35	1100	122.9	219
20000	-45		114.9	230
25000	-55		109.3	242
30000	-64		106.3	255
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	5		-	-
5000	-5		-	-
10000	-15		135.7	211
15000	-25	1100	123.1	221
20000	-35		115.2	233
25000	-45		109.3	245
30000	-54		106.3	258
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	15		-	-
5000	5		-	-
10000	-5		136.1	213
15000	-15	1100	123.6	224
20000	-25		115.4	236
25000	-35		109.3	248
30000	-44		103.8	261

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 1100 FT-LB
(ISA, ISA -10, ISA -20)

Figure 5-233

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	25		-	-
5000	15		-	-
10000	5		136.5	216
15000	-5	1100	124.1	227
20000	-15		115.7	239
25000	-25		109.2	251
30000	-34		100.0	264
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	35		-	-
5000	25		153.7	207
10000	15		137.1	218
15000	5	1100	124.6	229
20000	-5		115.9	241
25000	-15		109.3	254
30000	-24		-	-
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	50		-	-
5000	40		154.8	211
10000	30		138.0	222
15000	20	1100	125.3	233
20000	10		116.3	245
25000	0		107.9	258
30000	-9		-	-

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 1100 FT-LB
(ISA +10, ISA +20, ISA +35)**

Figure 5-235



ISA - 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	-5		-	-
5000	-15		-	-
10000	-25		-	-
15000	-35	1200	-	-
20000	-45		122.7	237
25000	-55		117.6	250
30000	-64		-	-
ISA - 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	5		-	-
5000	-5		-	-
10000	-15		-	-
15000	-25	1200	131.0	229
20000	-35		122.9	240
25000	-45		117.5	253
30000	-54		108.2	266
ISA (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	15		-	-
5000	5		-	-
10000	-5		-	-
15000	-15	1200	131.3	231
20000	-25		123.1	243
25000	-35		117.6	256
30000	-44		-	-

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

Intermediate Cruise Power, 1200 FT-LB

(ISA, ISA -10, ISA -20)

Figure 5-237

ISA + 10 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	25		-	-
5000	15		-	-
10000	5		-	-
15000	-5	1200	131.6	234
20000	-15		123.3	246
25000	-25		117.7	259
30000	-34		-	-
ISA + 20 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	35		-	-
5000	25		-	-
10000	15		-	-
15000	5	1200	132.0	237
20000	-5		123.5	249
25000	-15		115.3	262
30000	-24		-	-
ISA + 35 (°C)				
Altitude (FT)	OAT (°C)	Torque (FT-LB)	Fuel Flow (Kg/Hr)*	TAS (KT)
0	50		-	-
5000	40		-	-
10000	30		145.4	229
15000	20	1200	132.5	241
20000	10		123.9	253
25000	0		108.1	267
30000	-9		-	-

NOTE: Shaded areas are beyond aircraft OAT limit
See paragraph 2.28

* ECS: NORMAL

**Intermediate Cruise Power, 1200 FT-LB
(ISA +10, ISA +20, ISA +35)**

Figure 5-239



MAXIMUM SPEED CRUISE

Altitude	Cruise Nautical Miles / 100 Kg. Fuel					
	ISA - 20° C	ISA - 10° C	ISA	ISA + 10° C	ISA + 20° C	ISA + 35° C
0	111.8	112.4	113.6	113.9	114.8	116.2
5000	131.7	132.8	133.6	134.3	134.7	135.9
10000	154.2	155.1	156.0	156.9	157.2	157.9
15000	175.0	174.8	175.6	175.6	177.0	176.7
20000	189.1	188.6	190.2	191.8	194.0	203.6
25000	200.9	206.2	213.1	219.6	227.5	237.2
30000	237.6	245.4	253.2	261.7	269.5	282.6

INTERMEDIATE POWER CRUISE - 1000 FT-LB

Altitude	Cruise Nautical Miles / 100 Kg. Fuel					
	ISA - 20° C	ISA - 10° C	ISA	ISA + 10° C	ISA + 20° C	ISA + 35° C
0	-	112.8	113.5	114.5	115.3	116.6
5000	131.9	133.2	134.3	135.1	136.0	137.2
10000	156.2	157.8	159.2	160.5	161.7	163.5
15000	182.1	184.1	185.9	187.2	188.4	190.3
20000	207.0	209.3	211.5	213.5	215.3	218.0
25000	231.3	234.5	237.2	239.5	241.9	245.0
30000	252.2	255.8	259.2	262.1	268.7	290.6

LOW POWER CRUISE - 500 FT-LB

Altitude	Cruise Nautical Miles / 100 Kg. Fuel					
	ISA - 20° C	ISA - 10° C	ISA	ISA + 10° C	ISA + 20° C	ISA + 35° C
0	97.6	99.1	100.6	102.2	103.3	105.7
5000	121.1	122.6	124.1	125.3	126.6	128.6
10000	151.8	153.6	155.2	156.6	158.0	159.8
15000	185.5	187.7	189.9	191.9	193.4	195.2
20000	224.5	226.6	228.3	229.9	232.4	233.4
25000	264.4	267.3	269.7	271.4	273.8	274.4
30000	305.2	307.4	309.3	310.7	311.4	312.3

Note:

ECS: NORMAL

Shaded areas are beyond aircraft OAT limit. See paragraph 2.28.


Does not include 45 minute reserve, 26 gal. (174.2 Lb).

To obtain 45 minute reserve endurance set power to Low Power Cruise @ 5,000'.

Specific Air Range
Figure 5-245

Example #1		Example #2	
HOLDING TIME:	35 Min	FUEL AVAILABLE:	100 KG
ALTITUDE:	5,000 ft	ALTITUDE:	5,000 ft
FUEL REQUIRED:	68 KG	HOLDING TIME:	52 Min

**AIRSPPEED- 130 KIAS
WEIGHT- 2,041 KG
GEAR/FLAPS RETRACTED**



Holding Time vs. Fuel On Board
Figure S-247




EXAMPLE

Cruise OAT: -20 C° Destination OAT: 25 C°
 Cruise Press. Alt.: 25,000 FT. Destination Press. Alt.: 3,500 FT.
 Time To Descend.: 16.6 Min Time To Descend: 2.6 Min.
 Time During Descent: 16.6 - 2.6 = 14.0 Min

ASSOCIATED CONDITIONS

Power: 350 FT-LB
 ECS: NORMAL
 Flaps & Gear: RETRACTED
 Descent Speed: 170 KIAS at 1,724 KG
 174 KIAS at 1,996 KG
 179 KIAS at 2,309.7 KG




Time to Descend
Figure 5-249

EXAMPLE


Cruise OAT: -20 °C Destination OAT: 25 °C
 Cruise Press. Alt.: 25,000 FT. Destination Press. Alt.: 3,500 FT.
 Fuel To Descend: 22.7 KG Fuel To Descend: 4.8 KG
 Fuel Used During Descent: 22.7 - 4.8 = 17.9 KG

ASSOCIATED CONDITIONS

Power 350 FT-LB
 Flaps & Gear RETRACTED
 Descent Speed: 170 KIAS AT 1,724 KG
 174 KIAS AT 1,996 KG
 179 KIAS AT 2309.7 KG



Fuel to Descend
 Figure 5-251




EXAMPLE

Cruise OAT: -29 °C Destination OAT: 25 °C
 Cruise Press. Alt.: 25,000 FT. Destination Press Alt.: 3,500 FT.
 Dist. to Descend: 60.2 NM Dist. to Descend: 8.2 NM
 Distance during Climb: 60.2 - 8.2 = 52 NM

ASSOCIATED CONDITIONS

Power: 350 FT-LB
 ECS: NORMAL
 Flaps & Gear: RETRACTED
 Descent Speed: 170 KIAS AT 1,724 KG
 174 KIAS AT 1,998 KG
 179 KIAS AT 2,309.7 KG




Distance to Descend
Figure 5-253

EXAMPLE

Weight:	1973 KG	Airspeed:	100 KIAS
Cruise OAT:	-20 °C	Destination OAT:	25° C
Cruise Press. Alt.:	25,000 FT.	Destination Press. Alt.:	3,500 FT.
Glide Time:	36 Min	Glide Time:	6 Min.
Glide Endurance:		36 - 6 = 30 Min	


ASSOCIATED CONDITIONS

Power: **OUT**
 Flaps And Gear: **RETRACTED**
 Propeller: **FEATHERED**




Glide Endurance

Figure 5-255




EXAMPLE
Cruise Press. Alt.: 25,000 Ft. Dest. Press. Alt.: 3,500 Ft.
Cruise Glide Range: 72.4 N.M. Dest. Glide Range: 9.8 N.M.
Glide Range: 72.4 - 9.8 = 62.6 N.M.

ASSOCIATED CONDITIONS
Flaps And Gear: **RETRACTED**
Propeller: **FEATHERED**
Power: **OFF**



Glide Distance
Figure 5-257




Balked Landing Climb Performance

Figure 5-259

EXAMPLE	
OAT:	25 °C
RUNWAY GRADIENT:	2% UP
Pressure Altitude:	3,500 FT.
Headwind Component:	5 KT.
Landing Ground Roll:	318 MTR


ASSOCIATED CONDITIONS	
Runway:	PAVED, LEVEL, DRY SURFACE
Weight:	2,200 KG
Flaps:	36°
Touch Down Speed:	78 KIAS
Braking:	MODERATE WITH BETA




Landing Ground Roll, Flaps 36°, without Reverse
Figure 5-263

EXAMPLE	
OAT:	25 C°
Runway Gradient:	2% UP
Pressure Altitude:	3,500 FT.
Headwind Component:	5 KT.
Landing Distance:	672 MTR

ASSOCIATED CONDITIONS	
Runway:	PAVED, LEVEL, DRY SURFACE
Weight:	2,200 KG
Approach Power:	280 FT-LB.
Flaps:	36°
Approach Speed:	85 KIAS
Touch Down Speed:	78 KIAS
Braking:	MODERATE WITH BETA



Landing Distance, Flaps 36°, without Reverse
Figure 5-265



THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SECTION 6


WEIGHT AND BALANCE

Paragraph No.		Page No.
6.1	General	6-1
6.3	Airplane Weighing Procedure	6-2
6.5	Weight and Balance Data and Record	6-5
6.7	General Loading Recommendations	6-9
6.9	Weight and Balance Determination for Flight	6-10

METRIC

6.1	General - Metric	6-31
6.3	Airplane Weighing Procedure - Metric	6-32
6.5	Weight and Balance Data and Record - Metric	6-35
6.7	General Loading Recommendations - Metric	6-39
6.9	Weight and Balance Determination for Flight - Metric	6-40

Equipment List Supplied with aircraft paperwork



THIS PAGE INTENTIONALLY LEFT BLANK

SECTION 6

WEIGHT AND BALANCE

6.1 GENERAL

In order to achieve design performance and flying characteristics, the airplane must be operated and flown within the approved weight vs. center of gravity (C.G.) envelope. (Refer to Figure 6-33.) The airplane offers flexibility of loading, however, it cannot be flown with the maximum number of passengers, full fuel tanks and maximum baggage.

Before the airplane is licensed, a basic empty weight and C.G. location is computed (basic empty weight consists of the standard empty weight of the airplane plus the optional equipment). Using the basic empty weight and C.G. location, the pilot can determine the weight and C.G. position for the loaded airplane. It is the responsibility of the pilot in command to ensure that the airplane is loaded within approved weight vs. C.G. envelope limits prior to each flight.

6.1 GENERAL (Continued)

The basic empty weight and C.G. location is recorded in the Weight and Balance Data Form (Figure 6-5) and the Weight and Balance Record (Figure 6-7). If modification work is performed or new equipment is added to the airplane, a revised basic empty weight and C.G. must be computed and recorded in the Weight and Balance Data Form and the Weight and Balance Record. The current values for weight and C.G. should be used to calculate the quantity of fuel, baggage, and passengers that can be boarded so as to remain within the approved weight and C.G. limitations.

The following pages contain procedures and forms used when weighing an airplane and computing basic empty weight, C.G. position, and useful load. Note that the useful load includes usable fuel, baggage, cargo and passengers.

6.3 AIRPLANE WEIGHING PROCEDURE

At the time of licensing, Piper provides each airplane with the basic empty weight and center of gravity location. This data is supplied in the Weight and Balance Data Form (Figure 6-5).

The removal or addition of equipment or airplane modifications can affect the basic empty weight and center of gravity. The following is a weighing procedure to determine this basic empty weight and center of gravity location:

(a) Preparation

- (1) Verify that all items checked in the airplane equipment list are installed in the proper location in the airplane.
- (2) Remove excessive dirt, grease, moisture, and foreign items such as rags and tools, from the airplane before weighing.
- (3) Defuel airplane. Then open all fuel drains until all remaining fuel is drained. Then add the unusable fuel, 20 pounds (3 gallons total, 1.5 gallons each wing).
- (4) Fill oil to full capacity.

6.3 AIRPLANE WEIGHING PROCEDURE (Continued)**(a) Preparation (continued)**

- (5) Place pilot and copilot seats in fifth (5th) notch, aft of forward position. Put flaps in the fully retracted position and all control surfaces in the neutral position. All entrance and baggage doors should be closed.
- (6) Weigh the airplane inside a closed building to prevent errors in scale readings due to wind.

(b) Leveling

- (1) With the airplane on scales, insert a 3.4 inch spacer on each of the main gear struts and a 3.0 inch spacer on the nose gear strut.
- (2) Level airplane (refer to Figure 6-3) deflating (or inflating as required) nose wheel tire, to center bubble on level.

(c) Weighing - Airplane Basic Empty Weight

- (1) With the airplane level and brakes released, record the weight shown on each scale. Deduct the tare, if any, from each reading. (Refer to Figure 6-1.)

6.3 AIRPLANE WEIGHING PROCEDURE (Continued)


Scale Position and Symbol	Scale Reading	Tare	Net Weight
Nose Wheel (N)			
Right Main Wheel (R)			
Left Main Wheel (L)			
Basic Empty Weight, as Weighed (T)			

WEIGHING FORM

Figure 6-1

(d) Basic Empty Weight Center of Gravity

- (1) The following geometry applies to the airplane when it is level. Refer to Leveling paragraph 6.3 (b).



LEVELING DIAGRAM

Figure 6-3

6.3 AIRPLANE WEIGHING PROCEDURE (Continued)

- (2) The basic empty weight center of gravity (as weighed including optional equipment, full oil and unusable fuel) can be determined by the following formula:

$$\text{C.G. Arm} = \frac{(N)(A) + (R + L)(B)}{T} \text{ inches}$$

Where: $T = N + R + L$

6.5 WEIGHT AND BALANCE DATA AND RECORD

The Basic Empty Weight, Center of Gravity Location and Useful Load listed in Figure 6-5 are for the airplane as licensed at the factory. These figures apply only to the specific airplane serial number and registration number shown.

The basic empty weight of the airplane as licensed at the factory has been entered in the Weight and Balance Record (Figure 6-7). This form is provided to present the current status of the airplane basic empty weight and a complete history of previous modifications. Any change to the permanently installed equipment or modification which affects weight or moment must be entered in the Weight and Balance Record.

6.5 WEIGHT AND BALANCE DATA AND RECORD (Continued)

MODEL PA-46-500TP MERIDIAN

Airplane Serial Number _____

Registration Number _____

Date _____

AIRPLANE BASIC EMPTY WEIGHT

Item	Weight (Lbs)	x C.G. Arm (Inches Aft of Datum)	= Moment (In-Lbs)
Standard Empty Weight*			
Optional Equipment			
Basic Empty Weight			

*The standard empty weight includes full oil capacity and 3.0 gallons of unusable fuel.

AIRPLANE USEFUL LOAD - NORMAL CATEGORY OPERATION

(Ramp Weight) - (Basic Empty Weight) = Useful Load

(5134 lbs) - (lbs) = lbs.

THIS BASIC EMPTY WEIGHT, C.G. AND USEFUL LOAD ARE FOR THE AIRPLANE AS LICENSED AT THE FACTORY. REFER TO APPROPRIATE AIRCRAFT RECORD WHEN ALTERATIONS HAVE BEEN MADE.

WEIGHT AND BALANCE DATA FORM

Figure 6-5

HEARDIAN

WEIGHT AND BALANCE

PA-46-500TP		Serial Number		Registration Number			Page Number	
Date	Item No.	Description of Article or Modification	Added (+) Removed (-)	Weight Change			Running Basic Empty Weight	
				Wt. (Lb.)	Arm (In.)	Moment /100	Wt. (Lb.)	Moment /100
		As licensed						

WEIGHT AND BALANCE RECORD

Figure 6-7

WEIGHT AND BALANCE



PA-46-500TP		Serial Number		Registration Number			Page Number	
Date	Item No.	Description of Article or Modification	Added (+) Removed (-)	Weight Change			Running Basic Empty Weight	
				Wt. (Lb.)	Arm (In.)	Moment /100	Wt. (Lb.)	Moment /100

WEIGHT AND BALANCE RECORD (continued)

Figure 6-7 (continued)

6.7 GENERAL LOADING RECOMMENDATIONS

For all airplane configurations, it is the responsibility of the pilot in command to make sure that the airplane always remains within the allowable weight vs. center of gravity limits while in flight.

The following general loading recommendation is intended only as a guide. The charts, graphs, tables and instructions should be checked to assure that the airplane is within the allowable weight vs. center of gravity envelope.

- (a) Pilot Only
Load rear baggage compartment first. Investigation is required to determine the amount of fuel. Fuel load may be limited by forward envelope.
- (b) 2 Occupants - Pilot and Passenger in Front
Load rear baggage compartment first. Investigation is required to determine the amount of fuel. Fuel load may be limited by forward envelope.
- (c) 3 Occupants - 2 in front, 1 in rear
Investigation is required to determine the amount of fuel. Fuel load may be limited by forward envelope.
- (d) 4 Occupants - 2 in front, 2 in rear
With 4 occupants, aft passengers' weight, fuel and baggage may be limited by envelope. Investigation is required to determine optimum fuel and baggage load.
- (e) 5 Occupants - 2 in front, 1 in middle, 2 in rear
With 5 occupants, aft passengers' weight, fuel and baggage may be limited by envelope. Investigation is required to determine optimum fuel and baggage load.
- (f) 6 Occupants - 2 in front, 2 in middle, 2 in rear
With 6 occupants, aft passengers weight, fuel and baggage may be limited by envelope. Investigation is required to determine optimum fuel and baggage load.

WARNING

Do not attempt to fly this airplane under any conditions when it is loaded outside the limits of the approved weight and center of gravity envelope.



6.7 GENERAL LOADING RECOMMENDATIONS (continued)

NOTE

With configuration loadings falling near the envelope limits, it is important to check anticipated landing loadings since fuel burn could result in a final loading outside of the approved weight vs. C.G. envelope.

NOTE

For all airplane configurations, it is the responsibility of the pilot in command to make sure that the airplane always remains within the allowable weight vs. center of gravity envelope while in flight.

NOTE

Always load the fuel equally between the right and left tanks.

6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT

- (a) Record the airplane basic empty weight and moment from the Weight and Balance Data form or from the latest superseding form (Weight and Balance Record) onto the Weight and Balance computation form (figure 6-13).
- (b) Record the weight and corresponding moment of each item using the loading tables (figures 6-19 through 6-29).
- (c) Add the weight and moment of all items to the basic empty weight and moment to determine the zero fuel weight and moment.
- (d) Divide the zero fuel weight moment by the zero fuel weight to determine the zero fuel weight arm (C.G.).
- (e) Check the zero fuel weight and C.G. by locating the weight and arm on the Center of Gravity Limits graph (figure 6-33). Approved points are located within the C.G. envelope. This then meets the weight and balance requirements.

6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

- (f) Use the loading table for fuel (figure 6-27) to determine the moment for the fuel being loaded. Record the weight and moment of the fuel in the Weight and Balance Computation Form.
- (g) Total the zero fuel weight and moment with the fuel loading weight and moment to obtain ramp weight.
- (h) Divide the ramp weight moment by the ramp weight to determine the ramp weight arm (C.G.). Check the ramp weight and C.G. by locating the weight and arm on the Center of Gravity Limits graph (figure 6-33). Approved points are located within the C.G. envelope. This then meets the weight and balance requirements.
- (i) Subtract the weight and moment of the fuel allowance for engine start, taxi, and runup to determine takeoff weight and moment. A standard 42.61 pound fuel allowance for taxi and runup is assumed. The moment for the fuel allowance is determined by the difference in moments of the total fuel loaded and the fuel remaining on board after taxi and runup. Enter the fuel allowance weight and moment in the Weight and Balance Computation form.
- (j) Divide the takeoff weight moment by the takeoff weight to determine the takeoff weight arm (C.G.). Check the takeoff weight and C.G. by locating the weight and arm on the Center of Gravity Limits graph (figure 6-33). Approved points are located within the C.G. envelope. This then meets the weight and balance requirements.
- (k) Determine the estimated weight of the fuel to be used during the flight to the appropriate destination. The weight and moment for this fuel is determined by the difference of the total fuel remaining after the fuel allowance is removed and the fuel remaining after reaching destination. Use the loading table for fuel (figure 6-27) to determine the moments. Enter the weight and moment of the fuel used during the flight in the Weight and Balance Computation form.
- (l) Subtract the weight and moment of the fuel used during the flight to determine landing weight and moment. Divide the landing weight moment by the landing weight to determine the landing weight arm (C.G.). Check the landing weight and C.G. by locating the weight and arm on the Center of Gravity Limits graph (figure 6-33). Approved points are located within the C.G. envelope. This then meets the weight and balance requirements.

SECTION 6

PA-46-500TP

WEIGHT AND BALANCE



6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

THIS PAGE INTENTIONALLY LEFT BLANK

MERIDIAN**WEIGHT AND BALANCE****6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)**

Moment (inch-pounds)	Arm Aft of Datum (inches)	Weight (pounds)	
459713.8	136.01	3380.0	Basic Empty Weight
23035.0	170.0	170.0	Pilot (Seat 1)
23035.0	135.50	170.0	Copilot (Seat 2)
31860.0	177.00	180.0	Center Passenger L/H (Seat 3)
177.00	177.00		Center Passenger R/H (Seat 4)
218.75	218.75		Rear Passenger L/H (Seat 5)
218.75	218.75		Rear Passenger R/H (Seat 6)
			Radar pod stowage compartment-Standard (maximum 5 pounds-soft items only)
152.85			Radar pod stowage compartment-EFTS equipped (maximum 5 pounds-soft items only)
157.475			Air Golf Baggage net (105 lbs. maximum -3 bags)-optional net option)
19858.4	248.23	80.0	Air Baggage (100 lbs. max.) (50 lbs. maximum with golf bag net option)
	286.50		Air oil stowage compartment (maximum - 5 pounds)
557502.2	140.08	3980.0	Zero Fuel Weight (maximum - 4850 pounds)
134188.7	148.36	904.5	Fuel (170 gals. maximum) @ 6.70 pounds per gallon
691690.9	141.61	4884.5	Maximum Ramp Weight (5134 pounds)
-63866.63	149.89	-42.61	Fuel allowance for Engine Start, Taxi and Run up
685304.23	141.54	4841.89	Maximum Takeoff Weight (5092 pounds)

Locate the arm (Center of Gravity, C.G.) of the takeoff weight on the Center of Gravity Limits graph (figure 6-33). If this point falls within the Weight/C.G. envelope, the loading is acceptable for takeoff.

Example of Weight and Balance Computation Form
Standard Configuration (Sample Loading)

Figure 6-9

WEIGHT AND BALANCE

6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT^(cont)

Weight Calculation	Weight (pounds)
Total Fuel	904.50
Fuel allowance for Engine Start, Taxi and Run up	-42.61
Fuel Remaining on board	861.89
Moment Calculation	Moment (inch-pounds)
Total Fuel	134188.66
Fuel Remaining on board	-127802.03
Fuel allowance for Engine Start, Taxi and Run up	6386.63

Notes:

1. Use the fuel loading table (figure 6-27) to determine the moment for the amount of fuel being loaded for the flight. If fuel is to be added to existing fuel, determine the total fuel weight and use the fuel loading table to determine the fuel moment. (Arm = Moment/Weight).
2. A standard 42.61 pound fuel allowance for taxi and runup is assumed. The moment for the fuel allowance is determined by the difference in moments of the total fuel loaded and the fuel remaining on board after taxi and runup. See example, figure 6-11.

Example of Moment Calculation for Fuel Allowance
Standard Configuration (Sample Loading)

Figure 6-11

6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

The moment for the fuel burned during the mission is determined by the difference in moments of the takeoff fuel loaded and the fuel remaining on board after landing. See example below.

Weight Calculation	
Takeoff Fuel	861.89
Mission Fuel used (Fuel burned during Climb, Cruise and Descent)	-633.3
Post Mission Fuel (Fuel remaining at Landing)	228.64
Moment Calculation	
Takeoff Fuel	127802.03
Mission Fuel used (Fuel burned during Climb, Cruise and Descent)	-33122.14
Post Mission Fuel (Fuel remaining at Landing)	94679.89

Item	Weight (pounds)	Arm Aft of Datum (inches)	Moment (inch-pounds)
Maximum Takeoff Weight (5092 pounds)	4841.89	141.54	685304.23
Minus Estimated Fuel Burn-off (Climb & Cruise) @ 6.70 pounds per gallon	-633.3	149.51	-94679.89
Maximum Landing Weight (4850 pounds)	4208.59	140.34	590624.34

Locate the arm (Center of Gravity, C.G.) of the landing weight on the Center of Gravity Limits graph (figure 6-33). If this point falls within the Weight/C.G. envelope, the loading is acceptable for landing.

IT IS THE SOLE RESPONSIBILITY OF THE PILOT IN COMMAND TO ENSURE THAT THE AIRPLANE IS LOADED PROPERLY AT ALL TIMES.

Example of Moment Calculation for Fuel Burned During the Mission
Figure 6-12

WEIGHT AND BALANCE



6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

	Weight (pounds)	Arm Aft of Datum (inches)	Moment (inch-pounds)
Basic Empty Weight			
Pilot (Seat 1)		135.50	
Copilot (Seat 2)		135.50	
Center Passenger L/H (Seat 3)		177.00	
Center Passenger R/H (Seat 4)		177.00	
Rear Passenger L/H (Seat 5)		218.75	
Rear Passenger R/H (Seat 6)		218.75	
Radar pod stowage compartment-Standard (maximum 5 pounds-soft items only)		152.85	
Radar pod stowage compartment- EFIS equipped (maximum 5 pounds-soft items only)		157.475	
Aft Golf Baggage net (105 lbs. maximum -3 bags)-optional		222.31	
Aft Baggage (100 lbs. max. (50 lbs. maximum with golf bag net option))		248.23	
Aft oil stowage compartment (maximum - 5 pounds)		286.50	
Zero Fuel Weight (maximum - 4850 pounds)			
Fuel (170 gals. maximum) ¹ @ 6.70 pounds per gallon			
Maximum Ramp Weight (5134 pounds)			
Fuel allowance for Engine Start, Taxi and Run up ²	-42.61		
Maximum Takeoff Weight (5092 pounds)			

Notes:

1. Use the fuel loading table (figure 6-27) to determine the moment for the amount of fuel being loaded for the flight. If fuel is to be added to existing fuel, determine the total fuel weight and use the fuel loading table to determine the fuel moment. (Arm = Moment/Weight).
2. A standard 42.61 pound fuel allowance for taxi and runup is assumed. The moment for the fuel allowance is determined by the difference in moments of the total fuel loaded and the fuel remaining on board after taxi and runup.

Locate the arm (Center of Gravity, C.G.) of the takeoff weight on the Center of Gravity Limits graph (figure 6-33). If this point falls within the Weight/C.G. envelope, the loading is acceptable for takeoff.

Weight and Balance Computation Form
Standard Configuration (Normal Category)

Figure 6-13A

6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

	Weight (pounds)	Arm Aft of Datum (inches)	Moment (inch-pounds)
Basic Empty Weight			
Pilot (Seat 1)		135.50	
Copilot (Seat 2)		135.50	
Stowage Area #1 (Maximum 5 pounds) (see Figure 6-31)		158.45	
Stowage Area #2 (Maximum 5 pounds) (see Figure 6-31)		158.45	
Stowage Area #3 (Maximum 5 pounds) (see Figure 6-31)		158.45	
Stowage Area #4 (Maximum 5 pounds) (see Figure 6-31)		171.25	
Ice Chest drawer (Maximum 20 pounds) (see Figure 6-31)		183.85	
Center Passenger R/H (Seat 4)		177.00	
Rear Passenger L/H (Seat 5)		218.75	
Rear Passenger R/H (Seat 6)		218.75	
Radar pod stowage compartment-Standard (maximum 5 pounds-soft items only)		152.85	
Radar pod stowage compartment- EFIS equipped (maximum 5 pounds-soft items only)		157.475	
Air Golf Baggage net (105 lbs. maximum -3 bags)-optional net option))		222.31	
Air Baggage (100 lbs. max. (50 lbs. maximum with golf bag net option))		248.23	
Aft oil stowage compartment (maximum - 5 pounds)		286.50	
Zero Fuel Weight (maximum - 4850 pounds)			
Fuel (170 gals. maximum) @ 6.70 pounds per gallon			
Maximum Ramp Weight (5134 pounds)			
Fuel allowance for Engine Start, Taxi and Run up*	-42.61		
Maximum Takeoff Weight (5092 pounds)			

Notes:

- Use the fuel loading table (figure 6-27) to determine the moment for the amount of fuel being loaded for the flight. If fuel is to be added to existing fuel, determine the total fuel weight and use the fuel loading table to determine the fuel moment. (Arm = Moment/Weight).
 - A standard 42.61 pound fuel allowance for taxi and runup is assumed. The moment for the fuel allowance is determined by the difference in moments of the total fuel loaded and the fuel remaining on board after taxi and runup.
- Locate the arm (Center of Gravity, C.G.) of the takeoff weight on the Center of Gravity Limits graph (figure 6-33). If this point falls within the Weight/C.G. envelope, the loading is acceptable for takeoff.

Weight and Balance Computation Form
Executive/Entertainment Configuration (Normal Category)

Figure 6-13B



Weight Calculation	Weight (pounds)
Total Fuel	
Fuel allowance for Engine Start, Taxi and Run up*	
Fuel Remaining on board	
Moment Calculation	Moment (inch-pounds)
Total Fuel	
Fuel Remaining on board	
Fuel allowance for Engine Start, Taxi and Run up	

Notes:

1. Use the fuel loading table (figure 6-27) to determine the moment for the amount of fuel being loaded for the flight. If fuel is to be added to existing fuel, determine the total fuel weight and use the fuel loading table to determine the fuel moment. (Arm = Moment/Weight).
2. A standard 42.61 pound fuel allowance for taxi and runup is assumed. The moment for the fuel allowance is determined by the difference in moments of the total fuel loaded and the fuel remaining on board after taxi and runup. See example, figure 6-11.

Moment Calculation for Fuel Allowance
Figure 6-14

6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

The moment for the fuel burned during the mission is determined by the difference in moments of the takeoff fuel loaded and the fuel remaining on board after landing. See example below.

Weight Calculation	Weight (pounds)
Takeoff Fuel	
Mission Fuel used (Fuel burned during Climb, Cruise and Descent)	
Post Mission Fuel (Fuel remaining at Landing)	
Moment Calculation	Moment (inch-pounds)
Takeoff Fuel	
Mission Fuel used (Fuel burned during Climb, Cruise and Descent)	
Post Mission Fuel (Fuel remaining at Landing)	

Item	Weight (pounds)	Arm Aft of Datum (inches)	Moment (inch-pounds)
Maximum Takeoff Weight (5092 pounds)			
Minus Estimated Fuel Burn-off (Climb & Cruise) @ 6.70 pounds per gallon			
Maximum Landing Weight (4850 pounds)			

Locate the arm (Center of Gravity, C.G.) of the landing weight on the Center of Gravity Limits graph (figure 6-33). If this point falls within the Weight/C.G. envelope, the loading is acceptable for landing.

IT IS THE SOLE RESPONSIBILITY OF THE PILOT IN COMMAND TO ENSURE THAT THE AIRPLANE IS LOADED PROPERLY AT ALL TIMES.


Moment Calculation for Fuel Burned During the Mission

Figure 6-15

SECTION 6

PA-46-500TP

WEIGHT AND BALANCE




6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)


THIS PAGE INTENTIONALLY LEFT BLANK

6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

Standard Configuration



Executive/Entertainment Configuration




Seating Configurations
Figure 6-17

SECTION 6

PA-46-500TP

WEIGHT AND BALANCE



6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

THIS PAGE INTENTIONALLY LEFT BLANK

6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

Weight (pounds)	Pilot	Copilot (Seat 2)	Seat 3	Seat 4	Seat 5	Seat 6
	Arm FS 135.5	Arm FS 135.5	Arm FS 177.0	Arm FS 177.0	Arm FS 218.75	Arm FS 218.75
Moment (inch - Pounds)						
20	2710.0	2710.0	3540.0	3540.0	4375.0	4375.0
30	4065.0	4065.0	5310.0	5310.0	6562.5	6562.5
40	5420.0	5420.0	7080.0	7080.0	8750.0	8750.0
50	6775.0	6775.0	8850.0	8850.0	10937.5	10937.5
60	8130.0	8130.0	10620.0	10620.0	13125.0	13125.0
70	9485.0	9485.0	12390.0	12390.0	15312.5	15312.5
80	10840.0	10840.0	14160.0	14160.0	17500.0	17500.0
90	12195.0	12195.0	15930.0	15930.0	19687.5	19687.5
100	13550.0	13550.0	17700.0	17700.0	21875.0	21875.0
110	14905.0	14905.0	19470.0	19470.0	24062.5	24062.5
120	16260.0	16260.0	21240.0	21240.0	26250.0	26250.0
130	17615.0	17615.0	23010.0	23010.0	28437.5	28437.5
140	18970.0	18970.0	24780.0	24780.0	30625.0	30625.0
150	20325.0	20325.0	26550.0	26550.0	32812.5	32812.5
160	21680.0	21680.0	28320.0	28320.0	35000.0	35000.0
170	23035.0	23035.0	30090.0	30090.0	37187.5	37187.5

Loading Table
Occupants (Standard Configuration)

Figure 6-19

WEIGHT AND BALANCE

MERIDIAN

6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

Weight (pounds)	Pilot Arm FS 135.5	Copilot (Seat 2) Arm FS 135.5	Moment (inch - pounds)		
			Seat 4 Arm FS 177.0	Seat 5 Arm FS 218.75	Seat 6 Arm FS 218.75
20	2710.0	2710.0	3540.0	4375.0	4375.0
30	4065.0	4065.0	5310.0	6562.5	6562.5
40	5420.0	5420.0	7080.0	8750.0	8750.0
50	6775.0	6775.0	8850.0	10937.5	10937.5
60	8130.0	8130.0	10620.0	13125.0	13125.0
70	9485.0	9485.0	12390.0	15312.5	15312.5
80	10840.0	10840.0	14160.0	17500.0	17500.0
90	12195.0	12195.0	15930.0	19687.5	19687.5
100	13550.0	13550.0	17700.0	21875.0	21875.0
110	14905.0	14905.0	19470.0	24062.5	24062.5
120	16260.0	16260.0	21240.0	26250.0	26250.0
130	17615.0	17615.0	23010.0	28437.5	28437.5
140	18970.0	18970.0	24780.0	30625.0	30625.0
150	20325.0	20325.0	26550.0	32812.5	32812.5
160	21680.0	21680.0	28320.0	35000.0	35000.0
170	23035.0	23035.0	30090.0	37187.5	37187.5

Loading Table

Occupants (Executive/Entertainment Configuration)

Figure 6-21

MERIDIAN ~~_____~~ :

WEIGHT AND BALANCE

6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

Standard Baggage net configuration	
Weight	Standard baggage
(pounds)	Arm FS 248.23
	Moment (inch -pounds)
10	2482.3
20	4964.6
30	7446.9
40	9929.2
50	12411.5
60	14893.8
70	17376.1
80	19858.4
90	22340.7
100	24823.0

Loading Table
Standard Baggage
 Figure 6-23


WEIGHT AND BALANCE




6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

Golf baggage net configuration		
Weight (pounds)	Golf baggage location Arm FS 222.31 Moment (inch -pounds)	Aft location Arm FS 248.23 Moment (inch -pounds)
10.0	2223.1	2482.3
20.0	4446.2	4964.6
30.0	6669.3	7446.9
40.0	8892.4	9929.2
50.0	11115.5	12411.5
60.0	13338.6	
70.0	15561.7	
80.0	17784.8	
90.0	20007.9	
100.0	22231.0	
105.0	23342.6	

Loading Table
Golf Baggage - Optional
Figure 6-25



Golf Baggage Loading Configuration
Figure 6-26



6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

Gallons	Fuel Weight (pounds)	Fuel Moment (inch pounds)
(unusable fuel not included)	(pounds)	(inch pounds)
20	134.00	19144.68
25	167.50	24079.93
30	201.00	29030.69
35	234.50	33990.65
40	268.00	38957.46
45	301.50	43930.87
50	335.00	48911.41
55	368.50	53899.63
60	402.00	58895.65
65	435.50	63899.05
70	469.00	68908.87
75	502.50	73923.83
80	536.00	78942.46
85	569.50	83963.42
90	603.00	88985.58
95	636.50	94008.15
100	670.00	99030.76
105	703.50	104053.34
110	737.00	109076.01
115	770.50	114098.96
120	804.00	119122.17
125	837.50	124145.36
130	871.00	129167.84
135	904.50	134188.66
140	938.00	139206.95
145	971.50	144222.62
150	1005.00	149237.50
155	1038.50	154257.05
160	1072.00	159292.80
165	1105.50	164365.64
170	1139.00	169510.07

Three (3) gallons of unusable fuel (20.10 pounds, 2901.84 inch pounds) included in basic empty weight. The above weights are based on a fuel specific gravity of 0.02899 pounds per cubic inch at 59 degrees F for Jet A and Jet A-1, which yields a fuel density of 6.7 pounds per gallon.


Loading Table
Fuel
Figure 6-27

6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)

Weight (pounds)	Stowage area 1-3	Stowage area 4	Ice chest
	Arm FS 158.45 Moment (inch - pounds)	Arm FS 171.25 Moment (inch - pounds)	Arm FS 183.85 Moment (inch - pounds)
1	158.5	171.3	183.9
2	316.9	342.5	367.7
3	475.4	513.8	551.6
4	633.8	685.0	735.4
5	792.3	856.3	919.3
6			1103.1
7			1287.0
8			1470.8
9			1654.7
10			1838.5
11			2022.4
12			2206.2
13			2390.1
14			2573.9
15			2757.8
16			2941.6
17			3125.5
18			3309.3
19			3493.2
20			3677.0

Loading Table
Executive/Entertainment Stowage Compartment
Figure 6-29


6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)



Stowage Configuration
Figure 6-31



6.9 WEIGHT AND BALANCE DETERMINATION FOR FLIGHT (cont)



Center of Gravity Limits Graph

Figure 6-33

SECTION 6 - METRIC

WEIGHT AND BALANCE

6.1 General - Metric

In order to achieve design performance and flying characteristics, the airplane must be operated and flown within the approved weight vs. center of gravity (C.G.) envelope. (Refer to Figure 6-69.) The airplane offers flexibility of loading, however, it cannot be flown with the maximum number of passengers, full fuel tanks and maximum baggage.

Before the airplane is licensed, a basic empty weight and C.G. location is computed (basic empty weight consists of the standard empty weight of the airplane plus the optional equipment). Using the basic empty weight and C.G. location, the pilot can determine the weight and C.G. position for the loaded airplane. It is the responsibility of the pilot in command to ensure that the airplane is loaded within approved weight vs. C.G. envelope limits prior to each flight.

The basic empty weight and C.G. location is recorded in the Weight and Balance Data Form (Figure 6-39) and the Weight and Balance Record (Figure 6-41). If modification work is performed or new equipment is added to the airplane, a revised basic empty weight and C.G. must be computed and recorded in the Weight and Balance Data Form and the Weight and Balance Record. The current values for weight and C.G. should be used to calculate the quantity of fuel, baggage, and passengers that can be boarded so as to remain within the approved weight and C.G. limitations.

The following pages contain procedures and forms used when weighing an airplane and computing basic empty weight, C.G. position, and useful load. Note that the useful load includes usable fuel, baggage, cargo and passengers.

6.3 Airplane Weighing Procedure - Metric

At the time of licensing, Piper provides each airplane with the basic empty weight and center of gravity location. This data is supplied in the Weight and Balance Data Form (Figure 6-39).

The removal or addition of equipment or airplane modifications can affect the basic empty weight and center of gravity. The following is a weighing procedure to determine this basic empty weight and center of gravity location:

(a) Preparation

- (1) Verify that all items checked in the airplane equipment list are installed in the proper location in the airplane.
- (2) Remove excessive dirt, grease, moisture, and foreign items such as rags and tools, from the airplane before weighing.
- (3) Defuel airplane. Then open all fuel drains until all remaining fuel is drained. Then add the unusable fuel, 5.6 liters in each wing.
- (4) Fill oil to full capacity.
- (5) Place pilot and copilot seats in fifth (5th) notch, aft of forward position. Put flaps in the fully retracted position and all control surfaces in the neutral position. All entrance and baggage doors should be closed.
- (6) Weigh the airplane inside a closed building to prevent errors in scale readings due to wind.

6.3 Airplane Weighing Procedure - Metric (continued)**(b) Leveling**

- (1) With the airplane on scales, insert an 8.6 centimeter spacer on each of the main gear struts and a 7.6 centimeter spacer on the nose gear strut.
- (2) Level airplane (refer to Figure 6-37) deflating (or inflating as required) nose wheel tire, to center bubble on level.

(c) Weighing - Airplane Basic Empty Weight

With the airplane level and brakes released, record the weight shown on each scale. Deduct the tare, if any, from each reading. (Refer to Figure 6-35.)


Scale Position and Symbol	Scale Reading	Tare	Net Weight
Nose Wheel (N)			
Right Main Wheel (R)			
Left Main Wheel (L)			
Basic Empty Weight, as Weighed (T)			

Weighing Form
Figure 6-35

6.3 Airplane Weighing Procedure - Metric (continued)

(d) Basic Empty Weight Center of Gravity

- (1) The following geometry applies to the airplane when it is level. Refer to Leveling, paragraph 6.3 (b).



Leveling Diagram
Figure 6-37

6.3 Airplane Weighing Procedure - Metric (continued)

(d) Basic Empty Weight Center of Gravity

- (2) The basic empty weight center of gravity (as weighed including optional equipment, full oil and unusable fuel) can be determined by the following formula:

$$\text{C.G. Arm} = \frac{(N)(A) + (R + L)(B)}{T} \quad \text{centimeters}$$

Where: $T = N + R + L$

6.5 Weight and Balance Data and Record - Metric

The Basic Empty Weight, Center of Gravity Location and Useful Load listed in Figure 6-39 are for the airplane as licensed at the factory. These figures apply only to the specific airplane serial number and registration number shown.

The basic empty weight of the airplane as licensed at the factory has been entered in the Weight and Balance Record (Figure 6-41). This form is provided to present the current status of the airplane basic empty weight and a complete history of previous modifications. Any change to the permanently installed equipment or modification which affects weight or moment must be entered in the Weight and Balance Record.



6.5 Weight and Balance Data and Record - Metric (Continued)

MODEL PA-46-500TP MERIDIAN

Airplane Serial Number _____

Registration Number _____

Date _____

AIRPLANE BASIC EMPTY WEIGHT

Item	Weight x (kg)	C.G. Arm (cm Aft of Datum)	= Moment (cm-kg)
Standard Empty Weight* Actual Computed			
Optional Equipment			
Basic Empty Weight			

*The standard empty weight includes full oil capacity and 11.4 liters of unusable fuel.

AIRPLANE USEFUL LOAD - NORMAL CATEGORY OPERATION


$(\text{Ramp Weight}) - (\text{Basic Empty Weight}) = \text{Useful Load}$

$(2328.7 \text{ kg}) - (\quad \text{kg}) = \quad \text{kg}$

THIS BASIC EMPTY WEIGHT, C.G. AND USEFUL LOAD ARE FOR THE AIRPLANE AS LICENSED AT THE FACTORY. REFER TO APPROPRIATE AIRCRAFT RECORD WHEN ALTERATIONS HAVE BEEN MADE.

Weight and Balance Data Form

Figure 6-39



6.5 Weight and Balance Data and Record - Metric (Continued)

PA-46-500TP		Serial Number		Registration Number			Page Number	
Date	Item No.	Description of Article or Modification	Weight Change			Running Basic Empty Weight		
			Added (+) Removed (-)	Wt. (kg)	Arm (cm)	Moment /100	Wt. (kg)	Moment /100
		As licensed						

Weight and Balance Record
Figure 6-41



6.5 Weight and Balance Data and Record - Metric (Continued)

PA-46-500TP	Serial Number		Registration Number			Page Number	
	Date	Item No.	Description of Article or Modification	Added (+) Removed (-)	Wt. (kg)	Arm (cm)	Moment /100
			Weight Change			Running Basic Empty Weight	Moment /100
					Wt. (kg)	Arm (cm)	Moment /100

Weight and Balance Record
Figure 6-41 (continued)

6.7 General Loading Recommendations - Metric

For all airplane configurations, it is the responsibility of the pilot in command to make sure that the airplane always remains within the allowable weight vs. center of gravity limits while in flight.

The following general loading recommendation is intended only as a guide. The charts, graphs, tables and instructions should be checked to assure that the airplane is within the allowable weight vs. center of gravity envelope.

- (a) Pilot Only
Load rear baggage compartment first. Investigation is required to determine the amount of fuel. Fuel load may be limited by forward envelope.
- (b) 2 Occupants - Pilot and Passenger in Front
Load rear baggage compartment first. Investigation is required to determine the amount of fuel. Fuel load may be limited by forward envelope.
- (c) 3 Occupants - 2 in front, 1 in rear
Investigation is required to determine the amount of fuel. Fuel load may be limited by forward envelope.
- (d) 4 Occupants - 2 in front, 2 in rear
With 4 occupants, aft passengers' weight, fuel and baggage may be limited by envelope. Investigation is required to determine optimum fuel and baggage load.
- (e) 5 Occupants - 2 in front, 1 in middle, 2 in rear
With 5 occupants, aft passengers' weight, fuel and baggage may be limited by envelope. Investigation is required to determine optimum fuel and baggage load.
- (f) 6 Occupants - 2 in front, 2 in middle, 2 in rear
With 6 occupants, aft passengers weight, fuel and baggage may be limited by envelope. Investigation is required to determine optimum fuel and baggage load.

WARNING

Do not attempt to fly this airplane under any conditions when it is loaded outside the limits of the approved weight and center of gravity envelope.

6.7 General Loading Recommendations - Metric (continued)

NOTE

With configuration loadings falling near the envelope limits, it is important to check anticipated landing loadings since fuel burn could result in a final loading outside of the approved weight vs. C.G. envelope.

NOTE

For all airplane configurations, it is the responsibility of the pilot in command to make sure that the airplane always remains within the allowable weight vs. center of gravity envelope while in flight.

NOTE

Always load the fuel equally between the right and left tanks.

6.9 Weight and Balance Determination for Flight - Metric

- (a) Record the airplane basic empty weight and moment from the Weight and Balance Data form or from the latest superseding form (Weight and Balance Record) onto the Weight and Balance computation form (figure 6-47).
- (b) Record the weight and corresponding moment of each item using the loading tables (figures 6-53 through 6-65).
- (c) Add the weight and moment of all items to the basic empty weight and moment to determine the zero fuel weight and moment.
- (d) Divide the zero fuel weight moment by the zero fuel weight to determine the zero fuel weight arm (C.G.).
- (e) Check the zero fuel weight and C.G. by locating the weight and arm on the Center of Gravity Limits graph (figure 6-69). Approved points are located within the C.G. envelope. This then meets the weight and balance requirements.

6.9 Weight and Balance Determination for Flight - Metric (cont)

- (f) Use the loading table for fuel (figure 6-63) to determine the moment for the fuel being loaded. Record the weight and moment of the fuel in the Weight and Balance Computation Form.
- (g) Total the zero fuel weight and moment with the fuel loading weight and moment to obtain ramp weight.
- (h) Divide the ramp weight moment by the ramp weight to determine the ramp weight arm (C.G.). Check the ramp weight and C.G. by locating the weight and arm on the Center of Gravity Limits graph (figure 6-69). Approved points are located within the C.G. envelope. This then meets the weight and balance requirements.
- (i) Subtract the weight and moment of the fuel allowance for engine start, taxi, and runup to determine takeoff weight and moment. A standard 19.33 kilogram fuel allowance for taxi and runup is assumed. The moment for the fuel allowance is determined by the difference in moments of the total fuel loaded and the fuel remaining on board after taxi and runup. Enter the fuel allowance weight and moment in the Weight and Balance Computation form.
- (j) Divide the takeoff weight moment by the takeoff weight to determine the takeoff weight arm (C.G.). Check the takeoff weight and C.G. by locating the weight and arm on the Center of Gravity Limits graph (figure 6-69). Approved points are located within the C.G. envelope. This then meets the weight and balance requirements.
- (k) Determine the estimated weight of the fuel to be used during the flight to the appropriate destination. The weight and moment for this fuel is determined by the difference of the total fuel remaining after the fuel allowance is removed and the fuel remaining after reaching destination. Use the loading table for fuel (figure 6-63) to determine the moments. Enter the weight and moment of the fuel used during the flight in the Weight and Balance Computation form.
- (l) Subtract the weight and moment of the fuel used during the flight to determine landing weight and moment. Divide the landing weight moment by the landing weight to determine the landing weight arm (C.G.). Check the landing weight and C.G. by locating the weight and arm on the Center of Gravity Limits graph (figure 6-69). Approved points are located within the C.G. envelope. This then meets the weight and balance requirements.

6.9 Weight and Balance Determination for Flight - Metric (cont)

THIS PAGE INTENTIONALLY LEFT BLANK

6.9 Weight and Balance Determination for Flight - Metric (cont)

Item	Weight (kilograms)	Arm Aft of Datum (centimeter)	Moment (centimeter- kilograms)
Basic Empty Weight	1533.1	345.47	529644.8
Pilot (Seat 1)	77.1	344.17	26539.1
Copilot (Seat 2)	77.1	344.17	26539.1
Center Passenger L/H (Seat 3)	81.6	449.58	36706.5
Center Passenger R/H (Seat 4)		449.58	
Rear Passenger L/H (Seat 5)		555.63	
Rear Passenger R/H (Seat 6)		555.63	
Radar pod stowage compartment-Standard (maximum 2.2 kilograms-soft items only)		388.24	
Radar pod stowage compartment- EFIS equipped (maximum 2.2 kilograms-soft items only)		399.99	
Aft Golf Baggage net (47.6 kilograms max. -3 bags)-optional		564.67	
Aft Baggage (45.3 kilograms max.) (22.6 kilograms max with golf bag)	36.3	630.50	22879.2
Aft oil stowage compartment (maximum - 2.2 kilograms)		727.71	
Zero fuel Weight (maximum - 2199.9 kilograms)	1805.3	355.79	642308.65
Fuel (643.45 litres maximum) ¹ @ 0.80 kilograms per litre	410.3	376.83	154601.3
Maximum Ramp Weight (2328.7 kilograms)	2215.6	359.69	796909.9
Fuel allowance for Engine Start, Taxi and Run up ²	-19.33	380.71	-7358.2
Maximum Takeoff Weight (2309.7 kilograms)	2196.2	359.50	789551.75

Locate the arm (Center of Gravity, C.G.) of the takeoff weight on the Center of Gravity Limits graph (figure 6-69). If this point falls within the Weight/C.G. envelope, the loading is acceptable for takeoff.

Example of Weight and Balance Computation
Standard Configuration (Sample Loading)
Figure 6-43



6.9 Weight and Balance Determination for Flight - Metric (cont)

Weight Calculation	Weight (kilograms)
Total Fuel	410.27
Fuel allowance for Engine Start, Taxi and Run up*	-19.33
Fuel Remaining on board	390.94
Moment Calculation	Moment (centimeter-kilograms)
Total Fuel	154601.3
Fuel Remaining on board	-147243.1
Fuel allowance for Engine Start, Taxi and Run up	7358.2

Notes:

1. Use the fuel loading table (figure 6-63) to determine the moment for the amount of fuel being loaded for the flight. If fuel is to be added to existing fuel, determine the total fuel weight and use the fuel loading table to determine the fuel moment. ($\text{Arm} = \text{Moment}/\text{Weight}$).
2. A standard 19.33 kilograms fuel allowance for taxi and runup is assumed. The moment for the fuel allowance is determined by the difference in moments of the total fuel loaded and the fuel remaining on board after taxi and runup. See example, figure 6-45.

Example of Moment Calculation for Fuel Allowance
Standard Configuration (Sample Loading)
Figure 6-45

6.9 Weight and Balance Determination for Flight - Metric (cont)

The moment for the fuel burned during the mission is determined by the difference in moments of the takeoff fuel loaded and the fuel remaining on board after landing. See example below.

Weight Calculation	Weight (kilograms)
Takeoff Fuel	390.94
Mission Fuel used (Fuel burned during Climb, Cruise and Descent)	-287.2
Post Mission Fuel (Fuel remaining at Landing)	103.74
Moment Calculation	Moment (centimeter-kilograms)
Takeoff Fuel	147243.10
Mission Fuel used (Fuel burned during Climb, Cruise and Descent)	-38160.6
Post Mission Fuel (Fuel remaining at Landing)	109082.5


Maximum Takeoff Weight (2309.7 kilograms)	2196.23	359.50	789551.75
Minus Estimated Fuel Burn-off (Climb & Cruise) @ 0.80 kilograms per litre	-287.2	379.76	-109082.5
Maximum Landing Weight (2199.91 kilograms)	1909.00	356.45	680469.28

Locate the arm (Center of Gravity, C.G.) of the landing weight on the Center of Gravity Limits graph (figure 6-69). If this point falls within the Weight/C.G. envelope, the loading is acceptable for landing.

IT IS THE SOLE RESPONSIBILITY OF THE PILOT IN COMMAND TO ENSURE THAT THE AIRPLANE IS LOADED PROPERLY AT ALL TIMES.

Example of Moment Calculation for Fuel Burned During the Mission

Figure 6-46



6.9 Weight and Balance Determination for Flight - Metric (cont)


Item	Weight (kilograms)	Arm Aft of Datum (centimeter)	Moment (centimeter-kilograms)
Basic Empty Weight		345.47	
Pilot (Seat 1)		344.17	
Copilot (Seat 2)		344.17	
Center Passenger L/H (Seat 3)		449.58	
Center Passenger R/H (Seat 4)		449.58	
Rear Passenger L/H (Seat 5)		555.63	
Rear Passenger R/H (Seat 6)		555.63	
Radar pod stowage compartment-Standard (maximum 2.27 kilograms-soft items only)		388.24	
Radar pod stowage compartment-EFIS equipped (maximum 2.27 kilograms-soft items only)		399.99	
Aft Golf Baggage net (47.63 kilograms max. -3 bags)-optional		564.67	
Aft Baggage (45.36 kilograms max. (22.68 kilograms max with golf bag)		630.50	
Aft oil stowage compartment (maximum - 2.27 kilograms)			
Zero fuel Weight (maximum - 2199.9 kilograms)			
Fuel (643.45 litres maximum) @ 0.80 kilograms per litre			
Maximum Ramp Weight (2328.7 kilograms)			
Fuel allowance for Engine Start, Taxi and Run up	-19.33		
Maximum Takeoff Weight (2309.7 kilograms)			

Notes:

- Use the fuel loading table (figure 6-63) to determine the moment for the amount of fuel being loaded for the flight. If fuel is to be added to existing fuel, determine the total fuel weight and use the fuel loading table to determine the fuel moment. (Arm = Moment/Weight).
- A standard 19.33 kilograms fuel allowance for taxi and runup is assumed. The moment for the fuel allowance is determined by the difference in moments of the total fuel loaded and the fuel remaining on board after taxi and runup. Locate the arm (Center of Gravity, C.G.) of the takeoff weight on the Center of Gravity Limits graph (figure 6-69). If this point falls within the Weight/C.G. envelope, the loading is acceptable for takeoff.

Weight and Balance Computation Form
Standard Configuration (Normal Category)

Figure 6-47A



6.9 Weight and Balance Determination for Flight - Metric (cont)

Item	Weight (kilograms)	Arm AR of Datum (centimeter)	Moment (centimeter-kilograms)
Basic Empty Weight			
Pilot (Seat 1)		344.17	
Copilot (Seat 2)		344.17	
Stowage Area #1 (Maximum 2.27 kilograms) (See Figure 6-67)		402.46	
Stowage Area #2 (Maximum 2.27 kilograms) (See Figure 6-67)		402.46	
Stowage Area #3 (Maximum 2.27 kilograms) (See Figure 6-67)		402.46	
Stowage Area #4 (Maximum 2.27 kilograms) (See Figure 6-67)		434.98	
Ice Chest drawer (Maximum 9.07 kilograms) (See Figure 6-67)		466.98	
Center Passenger R/H (Seat 4)		449.58	
Rear Passenger L/H (Seat 5)		555.63	
Rear Passenger R/H (Seat 6)		555.63	
Radar pod stowage compartment-Standard (maximum 2.2 kilograms-soft items only)		388.24	
Radar pod stowage compartment- EFTS equipped (maximum 2.2 kilograms-soft items only)		399.99	
AR Golf Baggage net (47.6 kilograms max. -3 bags)-optional		564.67	
AR Baggiegs (45.3 kilograms max) (22.6 kilograms max with golf bag)		630.50	
AR oil stowage compartment (maximum - 2.2 kilograms)			
Zero fuel Weight (maximum - 2199.9 kilograms)		727.71	
Fuel (643.45 litres maximum) @ 0.80 kilograms per litre			
Maximum Ramp Weight (2328.7 kilograms)			
Fuel allowance for Engine Start, Taxi and Run up	-19.33		
Maximum Takeoff Weight (2309.7 kilograms)			

Notes:

1. Use the fuel loading table (figure 6-63) to determine the moment for the amount of fuel being loaded for the flight. If fuel is to be added to existing fuel, determine the total fuel weight and use the fuel loading table to determine the fuel moment. (Arm = Moment/Weight).
 2. A standard 19.33 kilograms fuel allowance for taxi and runup is assumed. The moment for the fuel allowance is determined by the difference in moments of the total fuel loaded and the fuel remaining on board after taxi and runup.
- Locate the arm (Center of Gravity, C.G.) of the takeoff weight on the Center of Gravity Limits graph (figure 6-69). If this point falls within the Weight/C.G. envelope, the loading is acceptable for takeoff.

Weight and Balance Computation Form
 Executive/Entertainment Configuration (Normal Category)
 Figure 6-47B

Locate the arm (Center of Gravity, C.G.) of the landing weight on the Center of Gravity Limits graph (figure 6-69). If this point falls within the Weight/C.G. envelope, the loading is acceptable for landing.

Weight Calculation	Weight (kilograms)
Total Fuel	
Fuel allowance for Engine Start, Taxi and Run up*	
Fuel Remaining on board	
Moment Calculation	Moment (centimeter-kilograms)
Total Fuel	
Fuel Remaining on board	
Fuel allowance for Engine Start, Taxi and Run up	

Notes:

1. Use the fuel loading table (figure 6-63) to determine the moment for the amount of fuel being loaded for the flight. If fuel is to be added to existing fuel, determine the total fuel weight and use the fuel loading table to determine the fuel moment. (Arm = Moment/Weight).
2. A standard 19.33 kilograms fuel allowance for taxi and runup is assumed. The moment for the fuel allowance is determined by the difference in moments of the total fuel loaded and the fuel remaining on board after taxi and runup. See example, figure 6-45.

Moment Calculation for Fuel Allowance
Figure 6-48

6.9 Weight and Balance Determination for Flight - Metric (cont)

Weight Calculation	Weight (kilograms)
Takeoff Fuel	
Mission Fuel used (Fuel burned during Climb, Cruise and Descent)	
Post Mission Fuel (Fuel remaining at Landing)	
Moment Calculation	Moment (centimeter-kilograms)
Takeoff Fuel	
Mission Fuel used (Fuel burned during Climb, Cruise and Descent)	
Post Mission Fuel (Fuel remaining at Landing)	

Maximum Takeoff Weight (2309.7 kilograms)			
Minus Estimated Fuel Burn-off (Climb & Cruise) @ 0.80 kilograms per litre			
Maximum Landing Weight (2199.91 kilograms)			

Locate the arm (Center of Gravity, C.G.) of the landing weight on the Center of Gravity Limits graph (figure 6-69). If this point falls within the Weight/C.G. envelope, the loading is acceptable for landing.


IT IS THE SOLE RESPONSIBILITY OF THE PILOT IN COMMAND TO ENSURE THAT THE AIRPLANE IS LOADED PROPERLY AT ALL TIMES.

Moment Calculation for Fuel Burned During the Mission
Figure 6-49




6.9 Weight and Balance Determination for Flight - Metric (cont)

Standard Configuration



Executive/Entertainment Configuration



Seating Configurations
Figure 6-51

6.9 Weight and Balance Determination for Flight - Metric (cont)

THIS PAGE INTENTIONALLY LEFT BLANK

6.9 Weight and Balance Determination for Flight - Metric (cont)

THIS PAGE INTENTIONALLY LEFT BLANK

MEMORANDUM**WEIGHT AND BALANCE****6.9 Weight and Balance Determination for Flight - Metric (cont)**

Weight (kilograms)	Pilot Arm FS 344.17	Copilot (Seat 2) Arm FS 344.17	Seat 3 Arm FS 449.48	Seat 4 Arm FS 449.48	Seat 5 Arm FS 555.63	Seat 6 Arm FS 555.63
			Moment (centimeters-kilograms)			
9.1	3122.2	3122.2	4078.5	4078.5	5040.5	5040.5
13.6	4683.4	4683.4	6117.7	6117.7	7560.8	7560.8
18.1	6244.5	6244.5	8157.0	8157.0	10081.0	10081.0
22.7	7805.6	7805.6	10196.2	10196.2	12601.3	12601.3
27.2	9366.7	9366.7	12235.5	12235.5	15121.6	15121.6
31.8	10927.8	10927.8	14274.7	14274.7	17641.8	17641.8
36.3	12489.0	12489.0	16314.0	16314.0	20162.1	20162.1
40.8	14050.1	14050.1	18353.2	18353.2	22682.3	22682.3
45.4	15611.2	15611.2	20392.5	20392.5	25202.6	25202.6
49.9	17172.3	17172.3	22431.7	22431.7	27722.9	27722.9
54.4	18733.4	18733.4	24471.0	24471.0	30243.1	30243.1
59.0	20294.6	20294.6	26510.2	26510.2	32763.4	32763.4
63.5	21855.7	21855.7	28549.5	28549.5	35283.6	35283.6
68.0	23416.8	23416.8	30588.7	30588.7	37803.9	37803.9
72.6	24977.9	24977.9	32628.0	32628.0	40324.2	40324.2
77.1	26539.1	26539.1	34667.2	34667.2	42844.4	42844.4

Loading Table
Occupants (Standard Configuration)
Figure 6-53

6.9 Weight and Balance Determination for Flight - Metric (cont)

Seat 6	Arm FS 555.63	Weight (kilograms)	Arm FS 344.17	Copilot (Seat 2)	Arm FS 449.48	Moment (centimeters - kilograms)	Arm FS 555.63	Weight (kilograms)	Arm FS 344.17	Copilot (Seat 2)	Arm FS 449.48	Moment (centimeters - kilograms)	Arm FS 555.63	Weight (kilograms)	Arm FS 344.17	Copilot (Seat 2)	Arm FS 449.48	Moment (centimeters - kilograms)														
		9.1	3122.2	4078.5	5040.5	3122.2	5040.5	13.6	4683.4	6117.7	4683.4	6117.7	7560.8	5040.5	17641.8	15121.6	10081.0	12601.3	15121.6	17641.8	20162.1	22682.3	25202.6	27722.9	30243.1	32763.4	35283.6	37803.9	40324.2	42844.4		
		18.1	6244.5	8157.0	10081.0	6244.5	10081.0	22.7	7805.6	10196.2	7805.6	10196.2	12601.3	15121.6	17641.8	15121.6	10081.0	12601.3	15121.6	17641.8	20162.1	22682.3	25202.6	27722.9	30243.1	32763.4	35283.6	37803.9	40324.2	42844.4		
		13.6	4683.4	6117.7	7560.8	4683.4	7560.8	31.8	10927.8	14274.7	10927.8	14274.7	17641.8	20162.1	22682.3	25202.6	27722.9	30243.1	32763.4	35283.6	37803.9	40324.2	42844.4	454	59.0	63.5	68.0	72.6	77.1			
		3122.2	3122.2	4078.5	5040.5	3122.2	5040.5	4683.4	4683.4	6117.7	4683.4	6117.7	7560.8	5040.5	13.6	4683.4	6117.7	4683.4	6117.7	4683.4	6117.7	4683.4	6117.7	4683.4	6117.7	4683.4	6117.7	4683.4	6117.7	4683.4	6117.7	
		6244.5	6244.5	8157.0	10081.0	6244.5	10081.0	7805.6	7805.6	10196.2	7805.6	10196.2	12601.3	15121.6	17641.8	15121.6	10081.0	12601.3	15121.6	17641.8	20162.1	22682.3	25202.6	27722.9	30243.1	32763.4	35283.6	37803.9	40324.2	42844.4		
		10927.8	10927.8	14274.7	17641.8	10927.8	14274.7	14050.1	14050.1	18353.2	14050.1	18353.2	20392.5	20392.5	22431.7	20392.5	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	
		14050.1	14050.1	18353.2	20392.5	14050.1	18353.2	12489.0	12489.0	16314.0	12489.0	16314.0	20392.5	20392.5	22431.7	20392.5	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	
		12489.0	12489.0	16314.0	20392.5	12489.0	16314.0	9366.7	9366.7	12235.5	9366.7	12235.5	10196.2	10196.2	12601.3	10196.2	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	
		10927.8	10927.8	14274.7	17641.8	10927.8	14274.7	7805.6	7805.6	10196.2	7805.6	10196.2	12601.3	12601.3	15121.6	12601.3	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	
		9366.7	9366.7	12235.5	15121.6	9366.7	12235.5	6244.5	6244.5	8157.0	6244.5	8157.0	10081.0	10081.0	12601.3	10081.0	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	
		7805.6	7805.6	10196.2	12601.3	7805.6	10196.2	6244.5	6244.5	8157.0	6244.5	8157.0	10081.0	10081.0	12601.3	10081.0	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3
		6244.5	6244.5	8157.0	10081.0	6244.5	10081.0	4683.4	4683.4	6117.7	4683.4	6117.7	7560.8	7560.8	10081.0	7560.8	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	
		4683.4	4683.4	6117.7	7560.8	4683.4	7560.8	3122.2	3122.2	4078.5	3122.2	4078.5	5040.5	5040.5	7560.8	5040.5	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	
		3122.2	3122.2	4078.5	5040.5	3122.2	5040.5	26539.1	26539.1	34667.2	26539.1	34667.2	42844.4	42844.4	5040.5	42844.4	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5
		26539.1	26539.1	34667.2	42844.4	26539.1	34667.2	24977.9	24977.9	32628.0	24977.9	32628.0	30588.7	30588.7	37803.9	30588.7	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9
		24977.9	24977.9	32628.0	40324.2	24977.9	32628.0	21855.7	21855.7	28549.5	21855.7	28549.5	35283.6	35283.6	40324.2	35283.6	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2
		21855.7	21855.7	28549.5	35283.6	21855.7	28549.5	18733.4	18733.4	24471.0	18733.4	24471.0	30243.1	30243.1	37803.9	30243.1	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9
		18733.4	18733.4	24471.0	30243.1	18733.4	24471.0	15611.2	15611.2	20392.5	15611.2	20392.5	22431.7	22431.7	27722.9	22431.7	27722.9	27722.9	27722.9	27722.9	27722.9	27722.9	27722.9	27722.9	27722.9	27722.9	27722.9	27722.9	27722.9	27722.9	27722.9	27722.9
		15611.2	15611.2	20392.5	22431.7	15611.2	20392.5	14050.1	14050.1	18353.2	14050.1	18353.2	20392.5	20392.5	22431.7	20392.5	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7
		14050.1	14050.1	18353.2	20392.5	14050.1	18353.2	12489.0	12489.0	16314.0	12489.0	16314.0	20392.5	20392.5	22431.7	20392.5	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7	22431.7
		12489.0	12489.0	16314.0	20392.5	12489.0	16314.0	9366.7	9366.7	12235.5	9366.7	12235.5	10196.2	10196.2	12601.3	10196.2	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3
		9366.7	9366.7	12235.5	15121.6	9366.7	12235.5	7805.6	7805.6	10196.2	7805.6	10196.2	12601.3	12601.3	15121.6	12601.3	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6	15121.6
		7805.6	7805.6	10196.2	12601.3	7805.6	10196.2	6244.5	6244.5	8157.0	6244.5	8157.0	10081.0	10081.0	12601.3	10081.0	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3	12601.3
		6244.5	6244.5	8157.0	10081.0	6244.5	10081.0	4683.4	4683.4	6117.7	4683.4	6117.7	7560.8	7560.8	10081.0	7560.8	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0	10081.0
		4683.4	4683.4	6117.7	7560.8	4683.4	7560.8	3122.2	3122.2	4078.5	3122.2	4078.5	5040.5	5040.5	7560.8	5040.5	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8	7560.8
		3122.2	3122.2	4078.5	5040.5	3122.2	5040.5	26539.1	26539.1	34667.2	26539.1	34667.2	42844.4	42844.4	5040.5	42844.4	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5	5040.5
		26539.1	26539.1	34667.2	42844.4	26539.1	34667.2	24977.9	24977.9	32628.0	24977.9	32628.0	30588.7	30588.7	37803.9	30588.7	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9
		24977.9	24977.9	32628.0	40324.2	24977.9	32628.0	21855.7	21855.7	28549.5	21855.7	28549.5	35283.6	35283.6	40324.2	35283.6	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2	40324.2
		21855.7	21855.7	28549.5	35283.6	21855.7	28549.5	18733.4	18733.4	24471.0	18733.4	24471.0	30243.1	30243.1	37803.9	30243.1	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9	37803.9
		18733.4	18733.4	24471.0	30243.1	18733.4	24471.0	15611.2	15611.2	20392.5	15611.2	20392.5	22431.7	22431.7	27722.9	22431																

MERIDIAN **6.9 Weight and Balance Determination for Flight - Metric (cont)**


Weight (kilograms)	Standard baggage Arm FS 630.50 Moment (centimeter-kilograms)
4.5	2859.9
9.1	5719.8
13.6	8579.7
18.1	11439.6
22.7	14299.5
27.2	17159.4
31.8	20019.3
36.3	22879.2
40.8	25739.1
45.4	28599.0

**Loading Table
Standard Baggage
Figure 6-57**

6.9 Weight and Balance Determination for Flight - Metric (cont)

Weight (kilograms)	Golf baggage location Arm FS 564.67	Aft location Arm FS 630.50
	Moment (centimeter- kilograms)	Moment (centimeter- kilograms)
4.5	2561.3	2859.9
9.1	5122.5	5719.8
13.6	7683.8	8579.7
18.1	10245.1	11439.6
22.7	12806.4	14299.5
27.2	15367.6	
31.8	17928.9	
36.3	20490.2	
40.8	23051.5	
45.4	25612.7	
47.6	26893.4	

Loading Table
Golf Baggage - Optional
Figure 6-59



Golf Baggage Loading Configuration
Figure 6-61

6.9 Weight and Balance Determination for Flight - Metric (cont)

Litres (unusable fuel not included)	Fuel Weight (kilograms)	Fuel Moment Arm Varies (centimeter - kilograms)
75.7	60.8	22056.9
94.6	76.0	27742.9
113.6	91.2	33446.8
132.5	106.4	39161.3
151.4	121.6	44883.6
170.3	136.8	50613.6
189.3	152.0	56351.7
208.2	167.1	62098.8
227.1	182.3	67854.8
246.0	197.5	73619.3
265.0	212.7	79391.2
283.9	227.9	85169.0
302.8	243.1	90951.1
321.7	258.3	96735.8
340.7	273.5	102521.9
359.6	288.7	108308.5
378.5	303.9	114095.2
397.4	319.1	119881.8
416.4	334.3	125668.5
435.3	349.5	131455.5
454.2	364.7	137242.9
473.1	379.9	143030.2
492.1	395.1	148816.7
511.0	410.3	154601.3
529.9	425.5	160382.9
548.8	440.7	166161.6
567.8	455.9	171939.3
586.7	471.1	177722.4
605.6	486.2	183524.2
624.5	501.4	189368.7
643.45	516.6	195295.7

11.3 litres of unusable fuel (9.12 kilograms, 3343.26 centimeters-kilograms) included in basic empty weight. The above weights are based on a fuel specific gravity of 802.6732 kilograms per cubic meters at 15 degrees C for Jet A and Jet A-1, which yields a fuel density of 0.8027 kilograms per litre.

Loading Table
Fuel
Figure 6-63

WEIGHT AND BALANCE




6.9 Weight and Balance Determination for Flight - Metric (cont)

Weight (kilograms)	Stowage area 1-3	Stowage area 4	Ice chest
	Arm FS 402.463	Arm FS 434.975	Arm FS 466.979
Moment (centimeters-kilograms)			
0.5	182.6	197.3	211.8
0.9	365.1	394.6	423.6
1.4	547.7	591.9	635.5
1.8	730.2	789.2	847.3
2.3	912.8	986.5	1059.1
2.7			1270.9
3.2			1482.7
3.6			1694.5
4.1			1906.4
4.5			2118.2
5.0			2330.0
5.4			2541.8
5.9			2753.6
6.4			2965.4
6.8			3177.3
7.3			3389.1
7.7			3600.9
8.2			3812.7
8.6			4024.5
9.1			4236.3


Loading Table
Executive/Entertainment Stowage Compartment
Figure 6-65

6.9 Weight and Balance Determination for Flight - Metric (cont)




Stowage Configuration

Figure 6-67



6.9 Weight and Balance Determination for Flight - Metric (cont)



Center of Gravity Limits Graph
Figure 6-69

TABLE OF CONTENTS


SECTION 7

DESCRIPTION AND OPERATION
OF THE AIRPLANE AND ITS SYSTEMS

Paragraph No.		Page No.
7.1	The Airplane	7-1
7.3	The Airframe	7-1
7.5	Engine and Propeller	7-3
7.7	Engine Controls	7-6
7.8	Garmin G1000 Avionics System	7-8
	Primary Flight Display	7-8
	Autopilot Integration	7-11
	Multi-Function Display	7-14
	Keypad	7-40
	Audio Panels	7-40
7.9	Standby Instruments	7-41
7.10	Hydraulic System	7-43
7.11	Landing Gear	7-45
7.13	Brake System	7-48
7.15	Flight Control System	7-49
7.17	Fuel System	7-51
7.19	Electrical System	7-54
7.21	Instrument Panel	7-62
7.23	Pitot Static System	7-65
7.25	Environmental System	7-66
7.27	Bleed Air, Conditioning And Pressurization System	7-68
7.28	Emergency Oxygen System	7-70
7.29	Vacuum System	7-73
7.31	Stall Warning System	7-73
7.33	Emergency Locator Transmitter	7-74

**SECTION 7
DESCRIPTION
AND OPERATION**

PA-46-500TP



THIS PAGE INTENTIONALLY LEFT BLANK

SECTION 7
DESCRIPTION AND OPERATION
OF THE AIRPLANE AND ITS SYSTEMS

7.1 THE AIRPLANE

The PA-46-500TP Meridian is a single engine, all metal, retractable landing gear, low wing, turbo-propeller airplane. It has a pressurized cabin with seating for six occupants and a luggage compartment located behind the aft cabin seats.

7.3 THE AIRFRAME

The primary airframe is of aluminum alloy construction, with a steel combination engine mount - nose gear support structure. The nose cowling is made of aluminum and fiberglass.

The fuselage is an all metal, semi-monocoque structure with flush riveted skin. The skin has internally bonded doublers and is butt jointed at all seams not in the airflow direction. There are two basic fuselage sections: the pressurized cabin section and the tail cone section. The cabin section is sealed to maintain pressurization.

The seating arrangement includes two crew seats and four passenger seats. The forward passenger seats face aft, and all passenger seats have adjustable backs with built-in headrests. An inside baggage area is provided aft of the rear passenger seats.

Cabin access is through the main cabin door, located on the left side, aft of the wing. The main door is a horizontally split door with retractable steps in the lower half. The upper half is held open by a gas spring. A plug type, inward releasing, emergency egress door is located on the right side adjacent to the aft facing seat.

Windows include a two-piece windshield, pilot and copilot windows, a storm window in the pilot's window, and three passenger windows on each side.

7.3 THE AIRFRAME (Continued)

The wing is a three section structure. The center section built-up main spar extends through the lower fuselage and outboard of each main landing gear. This section has two forward spars and a rear spar which are pin jointed at the fuselage sides. The main landing gear retracts inward into recesses located aft of the main spar. The outboard section of each wing, to within approximately 18 in. (46 cm) of the tip, is a sealed integral fuel cell. Portions of the wing structure are adhesively bonded, and skins are butt jointed and flush riveted for a smooth airfoil surface.

The all-metal flaps are electrically actuated through a mechanical linkage. The flaps extend aft and down on three tracks and have four preselect positions (up, 10°, 20°, and 36°).

The all-metal ailerons are mass balanced and operated by a cable system mounted on the aft wing spar.

The empennage is of conventional fin and rudder, stabilizer and elevator design with aerodynamic and mass balanced control surfaces. Surfaces are all-metal construction. The single-piece elevator assembly incorporates a center-mounted anti-servo trim tab. The rudder trim tab is operated by an electrically driven actuator.

Various access panels on the fuselage, wings and empennage are removable for service or inspection purposes.

Electrical bonding is provided to ensure good electrical continuity between components. Lightning strike protection is provided in accordance with presently accepted practices. Anti-static wicks are provided on trailing edges of ailerons, elevator and rudder to discharge static electricity that might cause avionics interference.

7.5 ENGINE AND PROPELLER

Engine

The Meridian is powered by a Pratt & Whitney PT6A-42A turbo-propeller engine, with a flat rated power of 500 shp and maximum propeller speed of 2000 RPM. This engine is a reverse flow, free turbine arrangement. Accessories include a starter/generator and a belt driven alternator and air conditioning compressor.

Engine intake air is provided through dual, symmetric air inlets located on the forward portion of the cowling at the four and eight o'clock positions. The inlets are of fixed geometry such that no moving ice vanes or doors are utilized. The inlets are designed such that the dynamics of icing conditions do not allow the inlet to ice closed. Both inlets supply air to an inertial separator, which in turn supplies a common engine inlet plenum and intake screen.

The inertial separator functions by preventing foreign objects from making an abrupt turn into the plenum and instead exit through the bypass outlet. As air enters through the intake screen, it is ducted into a three-stage axial and single-stage centrifugal compressor driven by a single-stage reaction turbine. A dual turbine, counter-rotating with the first, drives the propeller through a two-stage reduction gear box. Exhaust is provided through dual exhaust stacks located on either side of the engine just behind the propeller.

A single annular combustion chamber, containing 14 removable fuel nozzles and two igniter plugs, comprises the combustion system. Seven of the fuel nozzles are used for starting; the remaining nozzles activate as the engine accelerates. A hydropneumatic fuel control schedules fuel flow to maintain engine power.

The ignition system consists of one exciter box, two ignition leads and two spark igniters. Both igniters are engaged simultaneously. DC power is delivered to the exciter box from the essential bus through an ignition mode selector switch in the overhead switch panel and a torque pressure switch. When in the automatic ignition mode, the ignition system will activate when the torque is less than or equal to approximately 275 ft. lbs., and deactivate when the torque is greater than or equal to approximately 375 ft. lbs. Continuous ignition, at any torque setting, is provided in the manual ignition mode.

7.5 ENGINE AND PROPELLER (continued)

Engine (continued)

The engine incorporates an integral oil lubrication system with an oil tank of approximately 12 quarts (11.35 liters) total capacity including propeller, integral engine oil system, and oil cooler. The oil tank is an integral part of the compressor inlet case in front of the accessory gearbox and contains a filler neck with calibrated dipstick. The filler neck incorporates a ball check valve to ensure oil does not migrate out of the filler neck in the event the dipstick is not properly secured. In addition, an oil level sight glass is provided to indicate the oil level in the gearbox without having to remove the dipstick. Adequate oil level for engine operation is indicated by an oil level within the green area of the sight glass.

Engine instruments are displayed on the MFD in normal and reversionary modes and on the PFD in reversionary mode only.

Fire detection is provided by a heat sensitive fire cable, which passes a current at approximately 540° F (282.2° C). This current alerts the fire detection computer, which then activates the red ENGINE FIRE message on the CAS display with repeating aural chime. When switched to test mode, an electrical current is passed to the fire detection computer, which should sense the current and illuminate the red ENGINE FIRE message with repeating aural chime.

7.5 ENGINE AND PROPELLER (continued)

Propeller

The propeller is a Hartzell model number HC-E4N-3Q/E8501K-3.5, 82.5 inch diameter, four blade, metal, constant speed unit with reversing and full feathering capabilities. Each propeller blade incorporates an electric deice boot.

The propeller governor pressurizes and regulates the flow of the propeller gearbox oil to a piston in the propeller dome. The piston is linked by a sliding rod and fork arrangement to the propeller blades. Governor oil pressure against the piston works to decrease propeller blade pitch. Centrifugal twisting moments on the propeller blades work to decrease propeller blade pitch and increase rpm. Governing of the interaction of these and other forces to maintain a constant rpm is provided by the propeller governor.

The propeller governor maintains a constant propeller speed and is not pilot controlled, but rather fixed at a maximum propeller speed of 2000 RPM. Propeller feather is selected by moving the condition lever to the cutoff position. Beta and reverse blade angles are controlled by power lever movement. Movement of the power lever into the beta and reverse range of operation is only possible on the ground via a squat switch controlled solenoid. An additional overspeed governor is also provided to protect against propeller and power turbine overspeed.

Propeller feathering is controlled electrically by switches in the throttle quadrant and a torque sensing switch. The battery switch must be ON to feather the propeller.



7.7 ENGINE CONTROLS

The engine is controlled by power, condition, and manual override (MOR) levers, located on the control quadrant of the lower central instrument panel. The power lever is used to actuate the engine fuel control unit as well as propeller beta and reverse settings. The power lever is connected through linkage to the fuel control unit at the rear of the engine, and controls engine power through the full range from maximum takeoff power back to idle and further aft to the beta detent and the reverse detent. When the power lever is at the idle stop, the gas generator (N_g) is at idle and the propeller (N_p) is at minimum pitch. A lifting action is required to raise the power lever over the idle detent to the beta and reverse detents. When the power lever is selected to the beta position, the gas generator is at idle and the propeller blade pitch is controlled by the power lever from idle thrust back through a zero or a no thrust condition. The beta position may be used after landing during ground roll and to control taxi speed. Further lifting and aft movement of the power lever to the reverse detent increases engine power and provides negative thrust (reverse).

WARNING

To prevent damage to the control linkage, do not move the power lever aft of the idle stop when the engine is not operating.

WARNING

Positioning the power lever aft of the flight idle stop in flight is prohibited. Such positioning may cause loss of airplane control or may result in an engine overspeed condition and consequent loss of engine power.

The landing gear warning horn is activated by an idle power setting or flap extension beyond 10 degrees combined with the landing gear not in a down and locked position. The horn will continue to sound until the gear is down and locked, the power setting is increased, or the flaps are retracted to less than 10 degrees. This is a safety feature to warn the pilot of an inadvertent gear-up landing.

The condition lever controls the run and cut-off function of the fuel control unit as well as propeller feather. The full forward position sets the run fuel flow, and full aft position cuts off fuel flow and feathers the propeller.

7.7 ENGINE CONTROLS (continued)

The manual override (MOR) lever is located in the center console to the left of the power lever. The MOR is used to directly control fuel flow to the engine if a pneumatic malfunction occurs in the engine fuel control unit. When the engine is operating, a failure of any pneumatic signal input to the fuel control unit will result in the fuel flow decreasing to minimum idle (approximately 48% Ng at sea level and increasing with altitude). Power may be regained by using the manual override (MOR) lever. The normal position for the MOR is the OFF position. The normal position is used for all normal engine operation when the fuel control unit is operating normally and engine power is selected by the power lever. Rapid movement of the MOR lever could cause compressor surges and excessive ITT overtemperature.

To operate the MOR, lift up on the lever and slowly move it forward toward the MAX position. Monitor gas generator speed (Ng) and ITT.

The friction adjustment lever, located in the middle of the control quadrant, may be adjusted to increase or decrease the friction holding the power lever.

7.8 GARMIN G1000 AVIONICS SYSTEM

NOTE

Refer to the Garmin G1000 Cockpit Reference Guide for the Piper PA-46 Meridian, Garmin p/n 190-00764-XX, latest revision, for complete descriptions of the G1000 system and operating procedures.

The Garmin G1000 Integrated Avionics System consists of dual Primary Flight Displays (PFD), a Multi-Function Display (MFD), dual Audio Panels, dual Attitude and Heading Reference Systems (AHRS), dual Air Data Computers (ADC), and the sensors and computers to process flight and engine information for display to the pilot. The system contains dual GPS WAAS receivers, dual VOR/ILS receivers, dual VHF communications transceivers, dual transponders, and an integrated crew alerting system (CAS) to alert the pilot of status annunciations, caution annunciations and warning annunciations. The G1000 system provides system messages which alert the pilot to abnormalities associated with the G1000 system. The G1000 system also has an integrated Class B TAWS system, traffic system, and an integrated weather radar.

Primary Flight Display

The Primary Flight Display (PFD) typically displays airspeed, attitude, altitude, and heading information in a traditional format. Slip information is shown as a trapezoid under the bank pointer. One width of the trapezoid is equal to a one ball width slip. Rate of turn information is shown on the scale above the rotating compass card; a standard rate turn is accomplished when the turn rate trend vector stops at the second tick mark (standard rate tick mark). OAT information is presented in the lower left corner of the PFD. The measured value of OAT is adjusted for probe recovery factor and ram air effects to indicate static air temperature.

The primary function of the PFD's is to provide attitude and heading data from the Attitude and Heading Reference System, air data from the Air Data Computer, and navigation and alerting information. The PFDs may also be used for flight planning.

Primary Flight Display (continued)

The following controls are available on the PFD (clockwise from top right):

- Communications frequency volume and squelch knob
- Communications frequency set knobs
- Communications frequency transfer button
- Altimeter setting knob (BARO)
- Course knob
- Map range knob and cursor control
- FMS control buttons and knob
- PFD softkey buttons, including master warning/caution acknowledgement
- Altitude reference set knob
- Heading bug control
- Navigation frequency transfer button
- Navigation frequency set knobs
- Navigation frequency volume and Identifier knob

Attitude and Heading Reference System (AHRS)

The AHRS uses GPS, rate sensors, air data, and magnetic variation to provide pitch and roll attitude, sideslip and heading to the display system. The AHRS incorporates internal monitors to determine validity of its parameters. If a parameter is suspect but still within tolerance of the internal monitors, the appropriate MISCOMPARE annunciation will be posted and the pilot, considering similar parameters for comparison, must determine the suspect parameter. If the parameter is determined invalid by the internal monitors, a red-X is displayed over the invalid parameter and a NO COMPARE annunciation is posted. If the entire AHRS becomes invalid while in flight, the G1000 system will automatically select the other AHRS, as indicated by a BOTH ON AHRS1 or BOTH ON AHRS2 annunciation, depending on which AHRS is functioning, and post the appropriate NO COMPARE annunciations. In this situation, the autopilot will become inoperative. If the AHRS becomes valid again, the pilot must manually re-select that AHRS if desired. Selection of which AHRS should be used or is being used is made via the SENSOR softkey on the PFD. If both AHRS become invalid, a red-X and amber ATTITUDE FAIL will be displayed on the attitude indicator and a red-X and amber HDG will be displayed on the heading display. The course pointer on the HSI will indicate straight up and the course may be set using the digital window. The AHRS will align while the aircraft is in motion, but will align quicker if the wings are kept level during the alignment process.

**Primary Flight Display (continued)****Air Data Computer (ADC)**

The ADC provides airspeed, altitude, vertical speed, and air temperature to the display system. In addition to the primary displays, this information is used by the FMS and Traffic systems.

The ADC incorporates internal monitors to determine validity of its parameters. If a parameter is suspect but still within tolerance of the internal monitors, the appropriate MISCOMPARE annunciation will be posted and the pilot, considering similar parameters for comparison, must determine the suspect parameter. If the parameter is determined invalid by the internal monitors, a red-X is displayed over the invalid parameter and a NO COMPARE annunciation is posted. If the entire ADC becomes invalid while in flight, the G1000 system will automatically select the other ADC, as indicated by a BOTH ON ADC1 or BOTH ON ADC2 annunciation, depending on which ADC is functioning, and post the appropriate NO COMPARE annunciations. If the ADC becomes valid again, the pilot must manually re-select that ADC if desired via the SENSOR softkey on the PFD. If both ADC's become invalid, a red-X and amber AIRSPEED FAIL, ALTITUDE FAIL and VERTICAL SPEED FAIL will be displayed on the appropriate display.

The primary function of the VHF Communication portion of the G1000 is to enable external radio communication. The primary function of the VOR/ILS Receiver portion of the equipment is to receive VOR, Localizer, and Glide Slope signals. The primary function of the GPS portion of the system is to acquire signals from the GPS and WAAS satellites and process this information in real-time to obtain the user's position, velocity, and time. This GPS WAAS is certified under TSO C146a and therefore is qualified as a primary navigation system. The PFD also displays all autopilot annunciations, including mode annunciations at the top, center of the display and system and preflight test status annunciations near the top of the altitude tape.

Reversionary Mode

The PFDs will automatically be displayed in a composite format (Reversionary mode) for emergency use if the MFD display fails. The DISPLAY BACKUP button on the associated audio panel should also be pressed. In the composite mode, the PFD will display the engine parameters typically reserved for the MFD, including the full crew alerting system and autopilot annunciations, and only limited map functions are available via the inset map.

Primary Flight Display (continued)**Autopilot Integration**

The GFC 700 Automatic Flight Control System (AFCS) is a 2-axis autopilot with integrated yaw damper and flight director system, controlled through a dedicated autopilot controller mounted below the MFD, which provides the pilot with the following features:

- One autopilot controller (GMC) which contains the following mode control buttons: AP (autopilot engage/disengage); FD (Flight Director On/Off); HDG (Heading mode On/Off); NAV (Nav mode On/Off); APR (Approach mode On/Off); ALT (Altitude Hold mode On/Off); VS (Vertical Speed mode On/Off); FLC (Flight Level Change mode On/Off); NOSE UP and NOSE DN (vertical mode reference change).
- Servos with autopilot processing logic in the pitch, roll and pitch trim control systems
- Servo mounts and brackets
- Flight Director processing logic in the GIAs
- Control wheel-mounted elevator electric pitch trim switch (split switch)
- Control wheel-mounted trim interrupt and autopilot disconnect switches
- Control wheel-mounted CWS (Control Wheel Steering) switch
- Remote-mounted go-around switch on the throttle
- PFD/MFD mounted altitude preselect knobs
- Yaw Damper system with "YD" switch on the mode controller

The GFC 700 autopilot contains an electric pitch trim system which is used by the autopilot for automatic pitch trim during autopilot operation and manual electric pitch trim when the autopilot is not engaged. The electric pitch trim system is operated by a split switch on the pilot's and copilot's control wheels. The GFC 700 autopilot and manual electric trim will not operate if the system has not satisfactorily completed a preflight test as indicated by a PFT annunciation or if a red AFCS annunciation is present.

Upon initial system power-up and verification of required sensor inputs, the autopilot/flight director system undergoes preflight test. At the end of the test, a two-tone aural sounds and the PFT and AFCS annunciations are removed. Successful completion of the preflight test is required for the electric pitch trim and autopilot to engage.

SECTION 7
DESCRIPTION
AND OPERATION

PA-46-500TP



Autopilot Integration (continued)

Annunciation of the flight director and autopilot modes is shown in the autopilot status field of the PFD. In general, green indicates active modes and white indicates armed modes. When a mode is directly selected by the pilot, no flashing of the mode will occur. When automatic mode changes occur, they will be annunciated with a flashing annunciation of the new mode for ten seconds in green. If a mode becomes unavailable for any reason, the mode will flash for ten seconds in yellow and be replaced by the default ROL mode in green.

Autopilot operation below 90 KIAS and above 175 KIAS in any mode is not authorized. Autopilot coupled approaches below 100 KIAS is not authorized.

The autopilot features an overspeed recovery submode which becomes active when the aircraft actual or projected airspeed exceeds V_{MO} . Presence of this submode is indicated by an amber MAXSPD above the airspeed tape on the PFD. It becomes active at approximately 175 KIAS and it remains active until the airspeed is reduced below approximately 175 KIAS and V_{MO} exceedance is no longer a factor. The overspeed recovery mode provides a pitch up command to a maximum level flight attitude to lessen the descent rate and to decelerate the airplane below V_{MO} . Since the airplane does not climb in overspeed recovery mode, the pilot may have to reduce power to avoid exceeding V_{MO} while in level flight. Overspeed recovery is not active in altitude hold (ALT) or glideslope (GS) modes. The airspeed reference (FLC), which is adjustable through a speed range of 90 to 175 KIAS, cannot be adjusted while in overspeed recovery mode.

Normal autopilot disconnects are annunciated with a yellow flashing AP on the PFD accompanied by a two second autopilot disconnect tone. Normal disconnects are those initiated by the pilot with the A/P DISC switch on the control yoke, the manual pitch trim switch, or the GA button. Abnormal disconnects will be accompanied by a red flashing AP on the PFD accompanied by a continuous autopilot disconnect tone. Abnormal disconnects are those detected by the system, such as total AHRS failure and stall warning horn activation. The disconnect tone may be silenced by pressing the A/P DISC switch or the manual pitch trim switch.

NOTE

Specific fault annunciations and associated emergency procedures are discussed in the Emergency Procedures, Section 3.

Autopilot Integration (continued)

The following conditions will cause the autopilot and yaw damper to disengage:

- Electrical power failure, including pulling the AUTOPILOT and/or GMC circuit breakers
- Internal autopilot system failure
- Total AHRS malfunction
- Depressing the red A/P DISC switch on the pilot's control wheel
- Actuating either half or both halves of the manual electric pitch trim split switch
- Pushing the AP button on the autopilot mode controller when the autopilot is engaged
- Pushing the GA button on the throttle handle
- Stall warning horn activation
- Depressing the CWS (Control Wheel Steering) will disconnect the servos from the flight controls as long as the switch is depressed, and re-engage upon release. Upon release the system will synchronize to the existing airspeed/pitch, or roll angle depending upon the mode selected. Review the Cockpit Reference Guide for additional information.
- Activating the EMER switch (with Battery, Alternator and Generator OFF).

Power to the pitch, roll and yaw servos is supplied through the AUTOPILOT circuit breaker. The pitch trim servo is powered through the PITCH TRIM circuit breaker and the Garmin Mode Controller (GMC) is powered through the GMC circuit breaker. The AVIONICS master switch can also function as an emergency autopilot disconnect switch should the red disconnect switch on the control yoke fail.

The autopilot mode controller contains a button labeled "SPD", which allows the airplane to hold a constant Mach number. This button is deactivated for the Meridian and should the pilot depress the button a system message, "SPD KEY DISABLED – The SPD key is disabled for this model aircraft", will be displayed.

Multi-Function Display

The Multi-Function Display (MFD) is the primary display for engine

Autopilot Integration (continued)

parameters, map information (including dedicated map pages for navigation, traffic, weather radar, stormscope, weather datalink and TAWS), waypoint information, nearest functions, charts, flight plan information, approach procedures, and the Crew Alerting System (CAS).

Crew Alerting System (CAS) Messages

The Crew Alerting System (CAS) consists of Master Warning and Master Caution Indicators operating in conjunction with CAS text messages. The Master Warning and Master Caution indicators are illuminated push-button switches centered above the pilot's PFD. CAS text messages appear in the lower left area of the MFD during normal operations and in the right side area of the PFD's during reversionary mode operation. CAS messages are posted in order of priority with warnings appearing above cautions and cautions appearing above advisories. The CAS message window is capable of displaying a total of 14 CAS messages in both normal and reversionary display modes. Should the total CAS message count exceed 14, the oldest of the lowest priority messages can only be seen by scrolling through the list. Scrolling through caution and advisory CAS messages is possible via the CAS ↑ or CAS ↓ softkeys. Warning CAS messages are not scrollable. The severity of CAS messages are categorized as Warning, Caution and Advisory as follows:

Red Warning Messages

Warning messages consist of a flashing red Master Warning indicator, located above the pilot's PFD, and a flashing (inversely red on white) CAS Warning text message located in the lower left corner of the MFD. Warnings are accompanied by a continuous aural chime, which can be silenced by pressing (acknowledging) the MASTER WARN RESET switch. When acknowledged, the MASTER WARN RESET switch will extinguish, the CAS Warning text message will stop flashing and will revert to normal (red on black) annunciation, and the aural chime will silence. CAS Warning text messages will persist until the initiating condition is removed. If the warning was initiated by an engine parameter, that parameter's indication will continue to flash until the condition is removed.

Amber Caution Messages

Multi-Function Display (continued)**Crew Alerting System (CAS) Messages (continued)**

Caution messages consist of an amber Master Caution indicator, located above the pilot's PFD, and a flashing (inversely black on amber) CAS Caution text message located in the lower left corner of the MFD. Cautions are accompanied by a single aural chime. Caution messages can be acknowledged by pressing the MASTER CAUTION RESET switch. When acknowledged, the MASTER CAUTION RESET switch will extinguish and the CAS Caution text message will revert to a normal (amber on black) annunciation. CAS Caution text messages will persist until the initiating condition is removed.

White Advisory Messages

CAS Advisory text messages appear in the CAS window in white text. Advisory messages do not require acknowledgment and are not accompanied by aural chimes. CAS Advisory Messages persist until the initiating condition is removed.

Multi-Function Display (continued)

Crew Alerting System (CAS) Messages (continued)

NOTE

The Garmin G1000 Cockpit Reference Guide for the Piper PA-46 Meridian, Garmin p/n 190-00764-XX, latest revision and the Garmin G1000 Pilot's Guide for the Piper PA-46-500TP, Garmin p/n 190-00763-XX, latest revision, contain detailed descriptions of the annunciator system (CAS and Non-CAS) and all warnings, cautions and advisories.

Reversionary Mode

Should the PFD in front of the pilot become inoperative, the MFD can be selected into reversionary mode by pressing the DISPLAY BACKUP button on the pilot's audio panel. The MFD will then show typical PFD information, including the pilot selectable data fields, autopilot annunciators, transponder information and G1000 system messages. Information retained from the MFD will also be available, including CAS messages, engine parameters, flight planning information with DTK and DIS fields, and an inset map with all features except radar.

Navigation

Provided the Garmin G1000 navigation receivers are receiving adequate and usable GPS and/or VHF navigation signals, it has been demonstrated capable of and meets the accuracy specifications for the following types of flight operations:

- VFR/IFR enroute, oceanic, and terminal operations, non-precision instrument approach (GPS, Loran-C, VOR, VOR-DME, TACAN, NDB, NDB-DME, RNAV, LOC, LOC Backcourse), and precision approach (ILS, LPV) operations within the U.S. National Airspace System in accordance with AC 20-138A.
- Navigation in the North Atlantic Minimum Navigation Performance Specification (MNPS) Airspace, in accordance with AC 91-49 and AC 120-33.
- The system is approved for use for RNAV Enroute and Terminal operations in accordance with AC 90-100.
- The systems meets RNP5 airspace (BRNAV) requirements of AC 90-96

Multi-Function Display (continued)**Navigation (continued)**

- The systems meets RNP5 airspace (BRNAV) requirements of AC 90-96 and in accordance with AC 20-138A, JAA AMJ 20X2 Leaflet 2 Revision 1, and FAA Order 8110.60 for oceanic and remote airspace operations, provided it is receiving usable navigation information from the GPS receiver. (A separate prediction software application may be required for oceanic and remote operations in the absence of WAAS corrections.)

Navigation is accomplished using the WGS-84 (NAD 83) coordinate reference datum. GPS navigation data is based upon use of only the Global Positioning System (GPS) operated by the United States of America.

Traffic Information Service (TIS)**NOTE**

If the G1000 system is configured to use the optional Traffic Advisory System (TAS), TIS will not be available for use.

Traffic Information Service (TIS) provides a graphic display of traffic advisory information to the pilot. The G1000 system performs an automatic test of the TIS system upon power-up. If the TIS power-up test is passed, it will enter STANDBY mode while on the ground. If the TIS power-up test is failed, a failure annunciation will be indicated in the center of the Traffic Map page. The traffic mode of operation is indicated in the upper-left corner of the Traffic Map page. The TIS will automatically switch to OPERATING mode once the aircraft is airborne and provide a voice or tone audio output and a graphic display of traffic.

TIS uses the Mode S transponder for the traffic data link and is available only when the aircraft is within the service volume of a TIS-capable, ground based, terminal radar site. Updates are available to the pilot in 5-second intervals. Aircraft without a transponder are invisible to TIS and aircraft without altitude reporting capability are shown without altitude separation data or climb/descent indication.

Multi-Function Display (continued)

Traffic Information Service (TIS) (continued)

Traffic Map Page

The Traffic Map page, located in the Map Group on the MFD, is selectable from 2 nm to 12 nm. The G1000 system can display up to eight traffic targets within a 7.5 nm radius, from 3000 feet below to 3500 feet above the requesting aircraft. The altitude difference between the requesting aircraft and other aircraft is displayed above/below the traffic symbol in hundreds of feet. If the traffic target is above the requesting aircraft, the altitude separation text appears above the traffic symbol; if below, the altitude separation text appears below the traffic symbol. An altitude trend up/down arrow is displayed to the right of the traffic target symbol when the relative climb or descent speeds are greater than 500 ft/min in either direction. TIS also provides a vector line showing the direction in which the traffic is moving, to the nearest 45°.

Traffic is overlaid on the following pages:

- * Navigation Map Page
- * Traffic Map Page
- * Trip Planning Page
- * Nearest Pages
- * Active Flight Plan Page
- * PFD Inset Map

TIS Alerts

Traffic is displayed according to TCAS symbology using four different symbols:

1. Non-Threat Traffic – An open white diamond with black center that indicates traffic is beyond a 5 nm range and greater than ± 1200 feet from the requesting aircraft.

Multi-Function Display (continued)**Traffic Information Service (TIS) (continued)***TIS Alerts (continued)*

2. Traffic Advisory (TA) – A solid yellow circle that indicates that traffic has met the criteria for a traffic advisory and is considered to be potentially hazardous. A yellow TRAFFIC annunciation is displayed at the top left of the attitude indicator on the PFD and an alert is heard in the cockpit, advising “Traffic”.
3. Traffic Advisory Off Scale - On the Traffic Map page a half TA symbol indicating a traffic advisory (TA), which is detected but is outside the range of the map will be displayed at the edge of the scale on the azimuth of the detected traffic. On the map page the off-scale traffic advisory is provided in a text box located on the lower left corner of the map.

Traffic information for which TIS is unable to determine the bearing (non-bearing traffic) is displayed in the center of the Traffic Map Page or in a banner at the lower left corner of map pages other than the Traffic Map Page on which traffic can be displayed.

TIS customization options are available to the pilot by depressing the MENU key while on the Navigation Map Page, and then selecting “Map Setup” then “Traffic” Group. TIS traffic may also be displayed on the Navigation Map page by selecting the MAP softkey and then selecting the TRAFFIC softkey.

Additional details on the Traffic Information Service (TIS) are contained in the latest revisions of the Garmin Cockpit Reference Guide for the Piper PA-46 Meridian P/N: 190-00764-XX and/or the Garmin G1000 Pilot’s Guide for the Piper PA-46 Meridian P/N: 190-00763-XX.



Multi-Function Display (continued)
Traffic Advisory System (TAS) – Optional

NOTE

If the G1000 system is configured to use the optional Traffic Advisory System (TAS), TIS will not be available for use.

The KTA-810 Traffic Advisory System (TAS) is used to assist in the detection and avoidance of other aircraft. TAS uses an onboard processor and antennas to detect and track other aircraft by interrogating their transponders. TAS analyzes the transponder replies to determine range, bearing and relative altitude, if the other aircraft is equipped with an altitude reporting transponder. Aircraft without a transponder are invisible to TAS and aircraft without altitude reporting capabilities are displayed with only range and bearing information.

After a normal power-up of the TAS, the unit will automatically enter its normal operating mode as indicated by the word OPERATING in the upper-left corner of the Traffic Map page and the NORMAL softkey will be highlighted. If the self-test does not pass, the word FAIL will be indicated in the upper left corner of the Traffic Map page and the STANDBY softkey will be highlighted. During ground operations, traffic targets will be depicted but aural alerts will be suppressed. Once airborne, TAS will remain in its normal operating mode and will depict traffic targets and provide aural alerts. If the pilot selects the STANDBY softkey at any time, the TAS will be forced out of its normal operating mode and will switch to STANDBY mode as indicated by the word STANDBY in the upper-left corner of the Traffic Map page and highlighting of the STANDBY softkey. In STANDBY mode, traffic targets are not depicted and aural traffic alerts are suppressed. The NORMAL softkey must be reselected to return to OPERATING mode.

The pilot may perform a TAS test by setting the range on the Traffic Map page to 2/6 nm (for optimum display) and then selecting the TEST softkey. If the TAS test is passed, it will display traffic symbols and the voice alert "TAS System Test Passed" will be heard. If the TAS test is failed, it will revert to STANDBY mode and a voice alert "TAS System Test Failed" will be heard. Use of the TAS self-test function in flight will inhibit normal TAS operation for up to 8 seconds. For this reason, the pilot should use caution when initiating the test in flight.

Multi-Function Display (continued)**Traffic Advisory System (TAS) – Optional (continued)***Traffic Map Page*

The Traffic Map page, located in the Map Group on the MFD, range is selectable from 2 nm to 40 nm. The TAS can track up to 45 aircraft and display up to 30 of them. TAS can track aircraft with relative altitudes from 10,000 feet below to 10,000 feet above the requesting aircraft. The altitude difference between the requesting aircraft and other (intruder) aircraft is displayed above/below the traffic symbol in hundreds of feet. If the traffic target is above the requesting aircraft, the altitude separation text appears above the traffic symbol; if below, the altitude separation text appears below the traffic symbol. An altitude trend up/down arrow is displayed to the right of the traffic target symbol when the relative climb or descent speeds are greater than 500 ft/min in either direction.

Traffic is overlaid on the following pages:

- * Navigation Map Page
- * Traffic Map Page
- * Trip Planning Page
- * Nearest Pages
- * Active Flight Plan Page
- * PFD Inset Map

TAS Alerts:

Traffic is displayed according to TCAS symbology using four different symbols.

1. Non-Threat Traffic – An open white diamond with black center that indicates traffic is beyond a 5 nm range and greater than ± 1200 feet from the requesting aircraft.
2. Proximity Advisory – A solid white diamond that indicates traffic is within a 5 nm range and within ± 1200 feet of the requesting aircraft. They are not considered traffic advisories (TA), which alert the crew to intruding aircraft.
3. Traffic Advisory (TA) – A solid yellow circle that indicates that traffic has met the criteria for a traffic advisory and is considered to be potentially hazardous. An aural alert is heard in the cockpit, advising: “Traffic, Traffic”

Multi-Function Display (continued)

Traffic Advisory System (TAS) – Optional (continued)

TAS Alerts (continued)

4. **Traffic Advisory Off Scale** – On the Traffic Map page a half TA symbol indicating a traffic advisory (TA), which is detected but is outside the range of the map will be displayed at the edge of the scale on the azimuth of the detected traffic. On the map page the off-scale traffic advisory is provided in a text box located on the lower left corner of the map.

Traffic information for which TAS is unable to determine the bearing (non-bearing traffic) is displayed in the center of the Traffic Map Page or in a banner at the lower left corner of maps other than the Traffic Map Page on which traffic can be displayed.

TAS customization options are available to the pilot by depressing the MENU key while on the Navigation Map Page, and then selecting “Map Setup” then “Traffic” Group. TAS traffic may also be displayed on the Navigation Map by selecting the MAP softkey and then selecting TRAFFIC softkey.

Additional details on the Traffic Advisory System (TAS) are contained in the latest revisions of the Garmin Cockpit Reference Guide for the Piper PA-46 Meridian P/N: 190-00764-XX and/or the Garmin G1000 Pilot’s Guide for the Piper PA-46 Meridian P/N: 190-00763-XX.

Terrain Proximity

NOTE

If the G1000 system is configured to use the optional Terrain Awareness and Warning System (TAWS), Terrain Proximity will not be available for use.

G1000 Terrain Proximity is a terrain awareness system that increases situational awareness and aids in reducing controlled flight into terrain (CFIT). It is similar to the Terrain Awareness and Warning System (TAWS) but does not comply with TSO-C151b certification standards. Terrain Proximity does not provide warning annunciations or voice alerts but it does provide color indications on map displays when terrain and obstacles are within a certain altitude threshold from the aircraft. Although the terrain and obstacle color map displays are the same, TAWS uses a more extensive database and more sophisticated algorithms

Multi-Function Display (continued)**Terrain Proximity (continued)**

to assess aircraft distance from terrain and obstacles. The terrain and obstacles database may not contain all obstructions, so the information provided should be used as an aid to situational awareness and should never be used to navigate or maneuver around terrain.

GPS altitude, which is derived from satellite position and therefore may differ from baro-corrected altitude read from the altimeter, is converted to mean sea level (MSL)-based altitude (GPS-MSL altitude) and is used in conjunction with GPS position to calculate and predict the aircraft's flight path in relation to the surrounding terrain and obstacles, whose altitudes are also referenced to MSL.

System Status:

Terrain Proximity requires the following components to operate properly:

- * valid 3-D GPS position
- * valid terrain/obstacle database

If Terrain Proximity does not have a valid 3-D GPS position a yellow "No GPS Position" text will be displayed at the center of the Terrain Proximity Page and on the PFD inset map if terrain is selected. If there is not a valid terrain/obstacle database, the system will not display the yellow and red colors associated with the offending obstacles and terrain.

Operation of Terrain Proximity:

Terrain is displayed on the following pages:

- * Navigation Map Page
- * Terrain Proximity Page
- * Trip Planning Page
- * Flight Plan Page
- * PFD Inset Map

To display terrain data on maps other than the Terrain Proximity page, select the MAP softkey (select INSET softkey for the PFD inset map) on the Navigation Map Page and then select the TERRAIN softkey. When Terrain Proximity is selected on maps other than the Terrain Proximity Page, an icon to indicate the feature is enabled for display and a legend for Terrain Proximity colors are shown.

Terrain customization options are available by pressing the MENU key

Multi-Function Display (continued)

Terrain Proximity (continued)

while on the Navigation Map Page, and then selecting "Map Setup" then "Map" group. Options selected on the Navigation Map page will be used on other map pages (less the Terrain Proximity Page itself) that display terrain information. Additional information about obstacles can be displayed by panning over the display on the map. The panning feature is enabled by depressing the RANGE knob on the keypad then pushing the knob in the desired direction until it is over the obstacle of interest. There is no inhibit function associated with Terrain Proximity, as there are no aural or visual alerts to inhibit.

Terrain Proximity Page:

The Terrain Proximity Page is specialized to show terrain and obstacle data in relation to the aircraft's current altitude, without clutter from the basemap. Aviation data (airports, VORs, and other NAVAIDs) can be displayed for reference.

Aircraft orientation on this map is always heading up unless there is no valid heading. Two views are available relative to the position of the aircraft: the 360° default display and the radar-like ARC (120°) display. Map range is adjustable with the RANGE Knob from 1 to 200 nm, as indicated by the map range rings (or arcs).

Operation of Terrain Proximity:

The Terrain Proximity Page is located in the Map Page Group on the MFD.

On all pages that display terrain data, obstacles and terrain are depicted with the following colors:

- * Red - above or within 100 feet below the aircraft altitude.
- * Yellow - between 100 feet and 1000 feet below the aircraft altitude.
- * Black - more than 1000 feet below the aircraft altitude.

Terrain Proximity Alerts:

Terrain Proximity does not provide warning annunciations or voice alerts associated with obstacles or terrain.

Multi-Function Display (continued)**Terrain Awareness and Warning System (TAWS) – Optional****NOTE**

If the G1000 system is configured to use the optional Terrain Awareness and Warning System (TAWS), Terrain Proximity will not be available for use.

The Terrain Awareness and Warning System (TAWS) is an optional feature used to increase situational awareness and aid in reducing controlled flight into terrain (CFIT). TAWS provides visual and aural cautions and warning alerts when terrain and obstacles are within a given altitude threshold from the aircraft. The displayed alerts and warnings are advisory in nature only. TAWS satisfies TSO-C151b Class B certification requirements whereas the more limited Terrain Proximity does not.

TAWS uses terrain and obstacle information supplied by government sources. Terrain information is based on terrain elevation information in a database that may contain inaccuracies. Individual obstructions may be shown if available in the database. The data undergoes verification by Garmin to confirm accuracy of the content, per TSO-C151b standards, however, the displayed information should never be understood as being all-inclusive and data may be inaccurate.

GPS altitude, which is derived from satellite position and therefore may differ from baro-corrected altitude read from the altimeter, is converted to mean sea level (MSL)-based altitude (GPS-MSL altitude) and is used in conjunction with GPS position to calculate and predict the aircraft's flight path in relation to the surrounding terrain and obstacles, whose altitudes are also referenced to MSL.

System Status:

During G1000 power-up, TAWS conducts a self-test of its aural and visual annunciations. The system test can also be manually initiated by selecting the TAWS Page then depress the MENU key, then select the "Test TAWS" option. An aural alert "TAWS System Test OK" or "TAWS System Failure" is issued at test completion, regardless of whether the test was initiated automatically or manually. TAWS System Testing is disabled when ground speed exceeds 30 knots.

TAWS requires the following to operate properly:

- * A valid terrain/obstacle/airport terrain database
- * A valid 3-D GPS position solution

Multi-Function Display (continued)**Terrain Awareness and Warning System (TAWS) – Optional (continued)***System Status (continued)*

If a valid 3-D GPS position solution and vertical accuracy requirements are not attained or the aircraft is out of the database coverage area, a TAWS N/A annunciation will appear on the TAWS Page and the aural annunciation “TAWS Not Available” is heard. When the GPS signal is re-established and the aircraft is within the database coverage area, the aural message “TAWS Available” is heard.

Operation of TAWS:

Terrain is displayed on the following pages:

- * Navigation Map Page
- * TAWS Page
- * Trip Planning Page
- * Flight Plan Page
- * PFD Inset Map

To display terrain data on maps other than the TAWS Page, select the MAP softkey (select INSET softkey for the PFD inset map) on the Navigation Map Page and then select the TERRAIN softkey. When TAWS is selected on maps other than the TAWS Page, an icon to indicate the feature is enabled for display and a legend for TAWS terrain colors is shown.

Terrain customization options are available by depressing the MENU key while on the Navigation Map Page, and then selecting “Map Setup” then “Map” group. Options selected on the Navigation Map page will be used on other map pages (less the TAWS Page itself) that display terrain information. Additional information about obstacles can be displayed by panning over the display on the map. The panning feature is enabled by depressing the RANGE knob on the keypad then pushing the knob in the desired direction until it is over the obstacle of interest.

Multi-Function Display (continued)**Terrain Awareness and Warning System (TAWS) – Optional (continued)***Operation of TAWS (continued)*

To inhibit the aural and visual Premature Descent Alert (PDA) and Forward Looking Terrain Awareness (FLTA) alerts (RTC, ITI, ROC and IOI), press the INHIBIT softkey on the TAWS Page or depress the MENU key then select "Inhibit TAWS" or "Enable TAWS" depending on the current state. In either case, inhibiting and enabling TAWS alerts depends on the status of the INHIBIT softkey, as the INHIBIT softkey performs both functions. Use caution when inhibiting TAWS as the system should be enabled when appropriate. Once TAWS is inhibited a TAWS INHB alert annunciation is displayed on the MFD and PFD.

NOTE

If TAWS alerts are inhibited when the Final Approach Fix is the active waypoint during a GPS WAAS approach, a LOW ALT annunciation may appear on the PFD next to the altimeter if the current aircraft altitude is at least 164 feet below the prescribed altitude at the Final Approach Fix.

TAWS Page:

The TAWS Page is located in the Map Page Group on the MFD.

The TAWS Page is specialized to show terrain, obstacle, and potential impact point data in relation to the aircraft's current altitude, without clutter from the basemap. Aviation data (airports, VORs, and other NAVAIDs) can be displayed for reference. If an obstacle and the projected flight path of the aircraft intersect, the display automatically zooms in to the closest potential point of impact on the TAWS Page.

Aircraft orientation on this map is always heading up unless there is no valid heading. Two views are available relative to the position of the aircraft; the 360° default display and the radar-like ARC (120°) display. Map range is adjustable with the RANGE Knob from 1 to 200 nm, as indicated by the map range rings or arcs.

SECTION 7
DESCRIPTION
AND OPERATION



Alert Type	PFD/MFD Alert Annunciation	MFD Pop-Up Alert	Aural Message	Response Technique*
Excessive Descent Rate Warning (EDR)	PULL UP	PULL-UP	"Pull Up"	WARNING
Reduced Required Terrain Clearance Warning (RTC)	PULL UP	TERRAIN - PULL-UP	"Terrain, Terrain; Pull Up, Pull Up"	WARNING
Imminent Terrain Impact Warning (ITI)	PULL UP	TERRAIN AHEAD - PULL-UP	"Terrain Ahead, Pull Up; Terrain Ahead, Pull Up"	WARNING
Reduced Required Obstacle Clearance Warning (ROC)	PULL UP	OBSTACLE - PULL-UP	"Obstacle, Obstacle; Pull Up, Pull Up"	WARNING
Imminent Obstacle Impact Warning (IOI)	PULL UP	OBSTACLE AHEAD - PULL-UP	"Obstacle Ahead, Pull Up; Obstacle Ahead, Pull Up"	WARNING
Reduced Required Terrain Clearance Caution (RTC)	TERRAIN	CAUTION - TERRAIN	"Caution, Terrain; Caution, Terrain"	CAUTION
Imminent Terrain Impact Caution (ITI)	TERRAIN	TERRAIN AHEAD	"Terrain Ahead; Terrain Ahead"	CAUTION
Reduced Required Obstacle Clearance Caution (ROC)	TERRAIN	CAUTION - OBSTACLE	"Caution, Obstacle; Caution, Obstacle"	CAUTION
Imminent Obstacle Impact Caution (IOI)	TERRAIN	OBSTACLE AHEAD	"Obstacle Ahead; Obstacle Ahead"	CAUTION
Premature Descent Alert Caution (PDA)	TERRAIN	TOO LOW - TERRAIN	"Too Low, Terrain"	CAUTION
Altitude Callout "500"	None	None	"Five-Hundred"	N/A
Excessive Descent Rate Caution (EDR)	TERRAIN	SINK RATE	"Sink Rate"	CAUTION
Negative Climb Rate Caution (NCR)	TERRAIN	DON'T SINK	"Don't Sink"	CAUTION

* See associated Response Techniques checklists on pages 7-29 and 7-30.

TAWS Alert Types
Table 1

Multi-Function Display (continued)**Terrain Awareness and Warning System (TAWS) – Optional (continued)***TAWS Page (continued)*

On all pages that display terrain data, the obstacles and terrain are depicted with the following colors:

- * Red - above or within 100 feet below the aircraft altitude.
- * Yellow - between 100 feet and 1000 feet below the aircraft altitude.
- * Black - more than 1000 feet below the aircraft altitude.

TAWS Alerts:

Alerts are issued when flight conditions meet parameters that are set within TAWS software algorithms. TAWS alerts typically employ a CAUTION or a WARNING alert severity level, or both. When an alert is issued, visual annunciations are displayed on the PFD and MFD and aural alerts are simultaneously issued. The TAWS Alert Annunciation is shown at the upper left of the Altimeter tape on the PFD and below the Terrain Legend on the MFD. If the TAWS Page is not displayed at the time, a pop-up alert appears on the MFD. To acknowledge the pop-up alert:

- Press the CLR Key (returns to the currently viewed page), or
- Press the ENT Key (accesses the TAWS Page)

TAWS alerts types are shown in Table 1 on page 7-28.

Response Technique - WARNING:

1. Level the wings while simultaneously adding maximum power.
2. Smoothly pitch up at a rate of 2° to 3° per second towards an initial target pitch attitude of 15°.
3. Adjust pitch attitude to ensure terrain clearance, while respecting stall warning. If the flaps are extended, retract flaps to the up position.
4. Continue climb at best angle of climb speed (V_X) until terrain or obstacle clearance is assured.
 - * Only vertical maneuvers are recommended unless operating in VMC or the pilot determines, after using all available information and instruments, that a turn, in addition to the vertical escape maneuver, is the safest course of action.
 - * Pilots are authorized to deviate from their current air traffic control (ATC) clearance to the extent necessary to comply with a TAWS warning.



Multi-Function Display (continued)

Terrain Awareness and Warning System (TAWS) – Optional (continued)

TAWS Alerts (continued)

Response Technique - CAUTION:

1. Take positive corrective action until the alert ceases.
2. Based on analysis of all available instruments and information:
 - * Stop descending or,
 - * Initiate a climb and/or,
 - * Turn as necessary.

Weather Radar

The Weather Radar installation consists of a Receiver/Transmitter unit in a teardrop shaped pod mounted beneath the right wing just outboard of the wing jack point.

The Garmin GWX 68 Airborne Color Weather Radar is a four-color digital pulsed radar with 6.5 kilowatts of output power. It combines excellent range and adjustable scanning profiles with a high-definition target display. The pulse width is four microseconds (μs) on all ranges except the 2.5 nm range. At close range, the GWX 68 uses a one μs pulse width to reduce the targets from smearing together.

The Piper PA-46 Meridian uses a 10-inch phased array antenna that is fully stabilized to accommodate 30° of pitch and roll.

To focus radar scanning on specific areas, Sector Scanning offers pilot-adjustable horizontal scan angles of 20° , 40° , 60° , or 90° . A vertical scanning function helps to analyze storm tops, gradients, and cell buildup activity at various altitudes.

Radar features include:

- * Extended Sensitivity Time Constant (STC) logic that automatically correlates distance of the return echo with intensity, so cells do not suddenly appear to get larger as they get closer.
- * WATCH® (Weather Attenuated Color Highlight) helps identify possible shadowing effects of short-range cell activity, identifying areas where radar return signals are weakened or attenuated by intense precipitation (or large areas of lesser precipitation) and may not fully reflect the weather behind a storm.
- * Weather Alert that looks ahead for intense cell activity in the 80-320 nm range, even if these ranges are not being monitored.

Multi-Function Display (continued)**Weather Radar (continued)***Operation of Radar:***NOTE**

Pulling the XM circuit breaker will render the radar inoperative.

NOTE

Radar images beyond approximately 130 nm should not be relied upon.

Weather Mode:

To activate the radar's Weather mode while on the ground, proceed to the Map Page Group on the MFD, rotate the small FMS knob to the Weather Radar Page, select the MODE softkey, and then select the STANDBY mode softkey. After the system goes through a 60-second warm-up period (countdown is displayed on the screen) the radar will enter STANDBY mode. To begin radar transmitting, select the WEATHER mode softkey. A pop-up menu will appear alerting the pilot that the radar is being activated on the ground and safety precautions should be exercised.

To activate the radar while in flight, proceed to the Map Page Group on the MFD, rotate the small FMS knob to the Weather Radar Page, select the MODE softkey, and then select the WEATHER mode softkey. After the system goes through a 60-second warm-up period (countdown is displayed on the screen) the radar will begin transmitting.

When the weather radar system is in either the Weather or Ground Map mode, the system automatically switches to Standby mode upon landing.

Ground Map Mode:

To activate the radar's Ground Map mode, proceed to the Map Page Group on the MFD, rotate the small FMS knob to the Weather Radar Page, select the MODE softkey, and then select the GROUND softkey. Select the BACK softkey, then activate the cursor by pressing the small FMS knob, rotate the large FMS knob to place the cursor in the TILT field, then turn the small FMS knob to adjust the antenna tilt angle to display ground returns at the desired distance.

When the weather radar system is in either the Weather or Ground Map mode, the system automatically switches to Standby mode upon landing.

**SECTION 7
DESCRIPTION
AND OPERATION**

PA-46-500TP

! ~~_____~~ MERIDIAN

THIS PAGE INTENTIONALLY LEFT BLANK

Multi-Function Display (continued)**Weather Radar (continued)***Weather Radar Page:*Weather Display:

When evaluating various target returns on the weather radar display, the colors denote precipitation intensity and rates shown in the following table.

Weather Mode Color	Intensity	Approximate Precipitation Rate (inches/hour)
Black	< 23 dBZ	< .01
Green	23 dBZ to < 32 dBZ	.01 to 0.1
Yellow	32 dBZ to < 41 dBZ	0.1 to 0.5
Red	41 dBZ to < 50 dBZ	0.5 to 2
Magenta	50 dBZ and greater	> 2

Precipitation Intensity and Rates

Table 2

Updrafts and downdrafts in thunderstorms carry water through the cloud, therefore the more severe the drafts, the greater the number and size of the precipitation droplets. With this in mind, the following interpretations can be made from what is displayed on the weather radar.

Avoid these areas by an extra wide margin.

- * In areas where the displayed target intensity is red or magenta (indicating large amounts of precipitation), the turbulence is considered severe.
- * Areas that show steep color gradients (intense color changes) over thin bands or short distances suggest irregular rainfall rate and strong turbulence.
- * Areas that show red or magenta are associated with hail or turbulence, as well as heavy precipitation. Vertical scanning and antenna tilt management may be necessary to identify areas of maximum intensity.

Multi-Function Display (continued)

Weather Radar (continued)

Weather Radar Page (continued)

Proper use of the weather radar is critical for detecting various types of weather phenomena (thunderstorms, squall lines, tornadoes, hail, etc.). Additional details on the weather radar are contained in the latest revisions of the Garmin Cockpit Reference Guide for the Piper PA-46 Meridian P/N: 190-00764-XX and/or the Garmin G1000 Pilot's Guide for the Piper PA-46 Meridian P/N: 190-00763-XX.

Ground Map Display:

When evaluating various intensities of ground target returns, the colors shown in the table below should be used.

Ground Map Mode Color	Intensity
Black	0 dB
Light Blue	> 0 dB to < 9 dB
Yellow	9 dB to < 18 dB
Magenta	18 dB to < 27 dB
Blue	27 dB and greater

Ground Target Return Intensities

Table 3

A secondary use of the weather radar system is for the presentation of terrain. This can be a useful tool for verifying aircraft position. A picture of the ground is represented much like a topographical map that can be used as a supplement to the Navigation Map on the MFD.

Ground Map mode uses a different gain range than Weather mode. Different colors are also used to represent the intensity levels. The displayed intensity of ground target returns is defined in the table shown above. The type and orientation of the target in relation to the aircraft affects the intensity displayed. Use of the GAIN and TILT controls helps improve contrast so that specific ground targets can be recognized more easily.

Proper use of the weather radar is critical for detecting various

Multi-Function Display (continued)**Weather Radar (continued)***Weather Radar Page (continued)*

types/features of terrain. Additional details on the weather radar are contained in the latest revisions of the Garmin Cockpit Reference Guide for the Piper PA-46 Meridian P/N: 190-00764-XX and/or the Garmin G1000 Pilot's Guide for the Piper PA-46 Meridian P/N: 190-00763-XX.

Garmin Datalink (GDL) – Optional

XM Satellite Weather and XM Satellite Radio® entertainment services is provided through the optional GDL 69A, a remote-mounted data-link satellite receiver. XM Satellite Radio and XM Satellite Weather services, available by subscription, each have coded IDs unique to the installed GDL 69A. These coded ID's must be provided to XM Satellite Radio to activate service. These IDs are located on the label on the back of the Data Link Receiver and on the XM Information Page on the MFD and in the XM Satellite Radio Activation Instructions included with the unit (available at www.garmin.com, P/N 190-00355-04). Once activated, XM Satellite Radio uses the coded IDs to send an activation signal that allows the G1000 to display weather data and/or entertainment programming provided through the GDL 69A.

NOTE


Pulling the XM circuit breaker will disable the radar as well as the expected GDL69A functions (XM weather and XM radio).

XM Satellite Weather:

Received graphical weather information and associated text is displayed on the Multi Function Display (MFD) and the Primary Flight Display (PFD) Inset Map. XM satellite weather operates in the S-band frequency range and provides continuous reception capabilities at any altitude throughout North America.

The primary map for viewing XM Weather data is the Weather Data Link Page in the Map Page Group. This is the only G1000 map display capable of showing information for all available XM weather products.

Selecting the products for display on the Weather Data Link Page is made by pressing the softkey associated with that product. The label for the



Multi-Function Display (continued)

Garmin Datalink (GDL) – Optional (continued)

XM Satellite Weather (continued)

product is shown in capital letters in the Weather Products column in the table below. When a weather product is selected for display, the corresponding softkey label changes to gray to indicate the product is enabled. Unavailable weather products have subdued softkey labels (softkeys are disabled from selection).

NOTE

Echo Tops and Cloud Tops are not selectable at the same time due to their color similarities.

The following pages can display various portions of XM Weather data:

- * Navigation Map
- * Weather Datalink Page (able to display all XM Weather data)
- * Weather Information Page
- * AUX - Trip Planning Page
- * Nearest Pages
- * Flight Plan Pages
- * PFD Inset Map

When a weather product is active on the Weather Data Link Page or the Navigation Map Page, the age of the data is displayed on the screen. The age of the product is based on the time difference between when the data was assembled on the ground and the current GPS time. Weather products are refreshed at specific intervals.

If for any reason, a weather product is not refreshed within the 30, 60, or 90-minute Expiration Time intervals, the data is considered expired and is removed from the display. This ensures that the displayed data is consistent with what is currently being broadcast by XM Satellite Radio services. If more than half of the expiration time has elapsed, the color of the product age displayed changes to yellow.

Multi-Function Display (continued)

Garmin Datalink (GDL) – Optional (continued)

XM Satellite Weather (continued)

Weather Product	Symbol	Expiration Time (minutes)	Refresh Rate (minutes)
NEXRAD		30	5
Cloud Top (CLD TOP)		60	15
Echo Top (ECHO TOP)		30	7.5
XM Lightning (LTNG)		30	5
Cell Movement (CELL MOV)		30	1.25
SIGMETs/AIRMETs (SIG/AIR)		60	12
METARs		90	12
City Forecast (CITY)		90	12
Surface Analysis (SFC)		60	12
Freezing Levels (FRZ LVL)		60	12
Winds Aloft (WIND)		60	12
County Warnings (COUNTY)		60	5
Cyclone Warnings (CYCLONE)		60	12
Radar Coverage	No product image	30	5
TFRs	No product image	60	12
TAFs	No product image	60	12

Weather Product Symbols, Expiration Times and Refresh Rates
Table 4

Multi-Function Display (continued)

Garmin Datalink (GDL) – Optional (continued)

XM Satellite Weather (continued)

The table on page 7-37 shows the weather product symbols, the expiration time and the refresh rate. The refresh rate represents the interval at which XM Satellite Radio broadcasts new signals that may or may not contain new weather data. It does not represent the rate at which weather data is updated or new content is received by the Data Link Receiver. Weather data are refreshed at intervals defined and controlled by XM Satellite Radio and their data vendors.

Additional details on the weather products are contained in the latest revisions of the Garmin Cockpit Reference Guide for the Piper PA-46 Meridian P/N: 190-00764-XX and/or the Garmin G1000 Pilot's Guide for the Piper PA-46 Meridian P/N: 190-00763-XX.

Customizing the Weather Data Link Page is possible by selecting Weather Data Link Page from the Map Group, press the MENU key, select Weather Setup option from the Page Menu and press the ENT key. Turn the large FMS knob to scroll to a weather product of interest then rotate the small FMS knob to scroll through the options for each product (ON/OFF, range settings, etc.). Press the ENT key to select the option then press the FMS knob or the CLR key to return to the Weather Data Link Page with the changed settings.

Customizing Weather Data Link options is also available on the Navigation Map page. Proceed to the Navigation Map page, depress the MENU key, highlight the Map Setup option and press the ENT key, turn the small FMS knob to highlight the Weather group, turn the large FMS knob to highlight and move between the product selections. When an item is highlighted, turn the small FMS knob to select the option and press the ENT key. Press the FMS knob or the CLR key to return to the Navigation Map Page with the changed settings.

Multi-Function Display (continued)**Garmin Datalink (GDL) – Optional (continued)***XM Radio Entertainment:*

The optional XM Radio entertainment feature of the GDL 69A Data Link Receiver is available for the pilot's and passengers' enjoyment. XM Satellite Radio offers a variety of radio programming over long distances without having to constantly search for new stations. The GDL 69A can receive the S-band, XM Satellite Radio® entertainment services at any altitude throughout the Continental U.S. Based on signals from satellites, coverage far exceeds land-based transmissions.

Entertainment audio is not available on the GDL 69 Data Link Receiver as it is on the GDL 69A Data Link Receiver.

XM Radio is never muted for the cabin passengers unless a stereo input to the stereo input jack is installed. XM Radio is automatically muted for the front seat crewmembers during the following conditions:

- Aircraft radio reception
- Push-to-talk switch activation
- Stall warning activation
- Gear warning activation
- Marker beacon audio activity
- Master caution and master warning chimes
- Audible system messages

The XM Radio Page provides information and control of the audio entertainment features of the XM Satellite Radio. To get to the XM Radio Page, proceed to the AUX Page Group on the MFD, turn the small FMS knob to the AUX-XM Information Page and select the RADIO softkey.

Additional details on the XM Radio features are contained in the latest appropriate p/n XX and revisions of the Garmin Cockpit Reference Guide for the Piper PA-46 Meridian P/N: 190-00764-XX and/or the Garmin G1000 Pilot's Guide for the Piper PA-46 Meridian P/N: 190-00763-XX.

Keypad

Control for the MFD, and if desired, the PFD, is performed by the MFD/PFD control unit (keypad) located aft of the throttle quadrant. Alpha-numeric keys are provided for easy entry of flight plan information, waypoint information, and frequency information. A range knob is provided to select ranges on the MFD or PFD, if desired. For a description of all the keys and features of the keypad, refer to the Garmin G1000 Cockpit Reference Guide for Piper PA-46 Meridian, Garmin p/n 190-00764-XX, latest p/n XX and revision or the Garmin G1000 Pilot's Guide for the Piper PA-46 Meridian, Garmin p/n 190-00763-XX, latest p/n XX and revision.

Audio Panels

Each audio panel operates independently and contains traditional transmitter and receiver selectors, as well as an integral intercom and marker beacon system. The marker beacon lights appear on the PFD and the marker beacon audio can be heard on the cockpit speaker via the pilot's audio panel. In addition, a clearance recorder records the last 2½ minutes of received audio. Lights above the audio panel selections indicate which selections are active. Pressing the red DISPLAY BACKUP button on either audio panel causes both that side PFD and the MFD to display the Reversionary mode.

GTX 33 Mode S Transponder

The G1000 Avionics Suite includes a GTX 33 Mode S Elementary Surveillance Operations transponder which connects to the PFD for control and display.

The transponder provides Mode A (normal), Mode C (Altitude Encoding) and Mode S (Data Communications) functions.

The transponder is an automated transceiver operating on radar frequencies, receiving ground radar and traffic alert and collision avoidance system (TCAS) interrogations at 1030 MHz, then transmitting a coded response to ground based radar at 1090 MHz.

The unit includes an altitude monitor and traffic information service (TIS). Altitude and traffic alerts are announced by a voice audio output. The PFD displays the code, reply indication, and operating mode. The MFD displays TIS graphical information, which may also appear in the PFD inset map. A traffic alert causes the PFD inset maps to automatically appear.

GTX 33 Mode S Transponder (Continued)

Ground stations can interrogate mode S transponders individually using a 24-bit International Civil Aviation Organization (ICAO) mode S address, which is unique to the particular aircraft. In addition, ground stations may interrogate a GTX 33 for its transponder data capability and the aircraft flight identification, which is the registration number or other call sign. The GTX 33 makes the maximum airspeed capability (set during configuration setup) available to TCAS systems on board nearby aircraft to aid in the determination of TCAS advisories.

7.9 STANDBY INSTRUMENTS

The standby instrument group includes an electric attitude indicator, an airspeed indicator, and a barometric altimeter mounted to the left of the pilot's PFD. The standby airspeed and altimeter are plumbed to the left side pitot static system and the alternate static system, and are of the traditional mechanical design. The standby electric attitude indicator is powered by an emergency battery mounted in the underwing radar pod, and is controlled by a push-button switch that is placarded STBY GYRO, ON/OFF. Prior to activating the standby gyro, the emergency battery should be tested by pressing the STBY GYRO TEST button and noting the STBY BAT TEST OK CAS message on the PFD or MFD as appropriate. If a fault occurs which causes one of the ADC and/or AHRS to output misleading information to the PFD, the standby instruments act as a useful comparison to indicate which of the three displays are correct.

Standby Attitude Indicator

The Standby Attitude Indicator provides backup display of aircraft attitude. It is located at the top of the standby instrument group where it can be viewed easily by the pilot. It is powered from an emergency battery so that it will remain powered for at least 30 minutes after the loss of the aircraft electrical system. The attitude indicator is a DC powered electromechanical unit. A power warning flag is rotated out of sight by a flag motor which allows the flag to reappear if power is interrupted. The standby attitude indicator switch must be selected ON for the standby gyro system to operate.

Depressing the test switch applies a ground for the ON/OFF control circuit. If the self test does not complete within 5 seconds, one or more of the following may be true:

- Batteries are less than 50% charged.
- The attitude indicator power supply itself is defective.

7.10 HYDRAULIC SYSTEM

The hydraulic system provides the power to retract and extend the landing gear. (See Figure 7-2.)

The electric motor driven hydraulic pump assembly is located aft of the rear baggage compartment and is accessible through the baggage compartment aft close-out panel. The pump assembly has an integral reservoir with filler plug, sight gauge and vent. The pump assembly incorporates pressure switches, bypass relief valves, and thermal relief valves in both the UP and DOWN sides. A shuttle valve is also incorporated to allow for unequal volumes of hydraulic fluid displaced during UP and DOWN gear actuation. Normal system operating pressure is controlled by the pressure switches. Maximum system operating pressure is limited by the bypass relief valves, and maximum system holding or trapped pressure is limited by the thermal relief valves.

NOTE

Occasional cycling of the hydraulic pump during climb and initial cruise can occur due to variations in the system pressure caused by ambient temperature changes.

The motor which drives the hydraulic pump is reversible and runs in one direction to supply gear UP pressure and in the opposite direction to supply gear DOWN pressure. The direction in which the pump runs is controlled electrically by the position of the gear selector switch on the instrument panel.

Other major components of the hydraulic system are the three gear actuators and the emergency gear extension valve. Operation of these components is covered in the landing gear section.


SECTION 7
DESCRIPTION
AND OPERATION

PA-46-500TP



7.10 HYDRAULIC SYSTEM (continued)

102550 B



Hydraulic System
Figure 7-2

7.11 LANDING GEAR

The aircraft is equipped with hydraulically operated, fully retractable, tricycle landing gear.

Locking-type actuators are used for main and nose gears. The actuator assembly provides mechanical gear-down locking at the fully extended position and is hydraulically unlocked. The actuator also acts as the gear brace in the extended position.

The main gear retracts inboard into the wing root area. A mechanically linked door covers the strut assembly.

Hydraulic pressure for gear operation is furnished by an electrically driven hydraulic pump. Landing gear operation is controlled by a two position landing gear selector switch with a wheel shaped knob located to the left of the engine power control quadrant. Three green lights, which are individually activated as each gear mechanically locks into the DOWN position, are located above the landing gear selector. A DAY/NIGHT rocker switch, located in the center overhead switch panel, can be used for adjusting the intensity of the landing gear indicator lights.

NOTE

The DAY/NIGHT switch must be in the DAY position to obtain full intensity of the landing gear position indicator lights. When the aircraft is operated at night, the switch should be in the NIGHT position to dim the gear lights.

The landing gear selector switch must be pulled outward to release it from a detent in the DOWN position prior to moving it to the UP position. In addition, there is a squat switch on the left main gear which prevents operation of the gear UP electrical circuit when the aircraft weight is on the gear. If the landing gear selector is placed in the UP position with the aircraft weight on the gear, the gear warning horn will sound, and the red GEAR WARN annunciator will illuminate.

The landing gear is held in the UP position by hydraulic pressure which is trapped in the system UP lines by a check valve in the pump assembly. When normal pump operation is stopped by the pressure switch, a check valve in the pump assembly closes to trap fluid pressure in the UP side of the system. Emergency gear extension is accomplished by a manually actuated valve which relieves the pressure in the UP side and bypasses fluid to the DOWN side of the system. The additional fluid required for DOWN operation comes directly from the reservoir.

7.11 LANDING GEAR (continued)

The landing gear is held in the DOWN position by spring loaded mechanical locking mechanisms built into each of the three actuating cylinders. The individual gear safe light switches are also mechanically operated when each mechanism is in the LOCKED position. With the hydraulic pump and system operating normally, hydraulic pressure is also trapped in the DOWN side of the system. This DOWN pressure is not required to mechanically lock the cylinders and is not available if the hydraulic pump is inoperative.

The EMERGENCY GEAR EXTENSION system allows the landing gear to free fall, with spring assist on the nose gear, into the extended position where the mechanical locks engage. If a gear system malfunction has been indicated and the EMERGENCY GEAR EXTENSION system used, it is recommended that the EMERGENCY GEAR EXTENSION control and the HYDRAULIC PUMP circuit breaker be left in the pulled position until the aircraft is safely on jacks. See the Maintenance Manual for proper landing gear system check-out procedures. If the aircraft is being used for training purposes or a pilot check-out flight the EMERGENCY GEAR EXTENSION control and HYDRAULIC PUMP POWER circuit breaker must be reset in order for hydraulic pressure to be generated in the UP side of the system and the gear retracted.

CAUTION

When flying in extreme cold where the aircraft has been cold-soaked for an extended period of time, the gear may not indicate down and locked for 10 to 15 seconds after normal gear extension.

CAUTION

When flying in extreme cold where the aircraft has been cold soaked, it may take several minutes for all three gear to indicate down and locked following an EMERGENCY EXTENSION "FREE FALL".

7.11 LANDING GEAR (continued)

A red GEAR WARN annunciator, located just above the landing gear position lights, is activated whenever all three gears are not fully down and locked, or not fully up with the gear doors closed. This annunciator will illuminate during normal gear operation to indicate that the gear is in transit. If it does not go out within approximately 10 seconds during normal gear operation or illuminates steadily during flight with the landing gear selector in the UP position, a system malfunction is indicated. An amber HYDR PUMP ON message will display on the MFD with a single aural chime any time the hydraulic pump has been operating for 15 seconds or more while airborne. A red HYDR PUMP ON message will display on the MFD with a repeating aural chime during any activation of the hydraulic pump while on the ground.

The red GEAR WARN annunciator and gear warning horn will operate simultaneously under the following conditions:

(a) In flight when the throttle is reduced to low power settings and the landing gear is not in the DOWN position.

(b) In flight when the flaps are extended beyond 10° and the landing gear is not in the DOWN position.

(c) On the ground when the landing gear selector is in the UP position. The landing gear squat switch activates to prevent operation of the retract side of the hydraulic pump on the ground.

A landing gear warning horn mute switch is located above the pilot's PFD. Pressing the landing gear warning horn mute switch temporarily silences the landing gear warning horn only if the horn was triggered by low power settings. The landing gear warning horn mute switch will not silence the horn if it was triggered by flaps extended beyond 10°. When pressed, the landing gear warning horn mute switch will illuminate. The horn can be silenced by pressing the switch and the light within the switch can only be extinguished by extending the landing gear or advancing the power lever.

7.13 BRAKE SYSTEM

The brake system is designed to meet all normal braking needs. Two single-disc, double puck brake assemblies, one on each main gear, are actuated by toe brake pedals mounted on both the pilot's and copilot's rudder pedals. A brake system reservoir, independent of the hydraulic system reservoir, is located on the firewall. Brake fluid should be maintained at the level marked on the reservoir. For further information see BRAKE SERVICE in Section 8 of this handbook.

The parking brake knob is located below the pilot's control column. To set the parking brake, first depress and hold the toe brake pedals and then pull the parking brake knob. To release the parking brake, first depress and hold the toe brake pedals and then push in on the parking brake knob.

THIS SPACE INTENTIONALLY LEFT BLANK

7.15 FLIGHT CONTROL SYSTEM

The primary flight controls are conventional and are operated by dual control wheels and rudder pedals. The control wheel operates the ailerons and elevator. The rudder pedals actuate the rudder and nose wheel steering. The toe brakes, which are an integral part of the pedals, operate the wheel brakes. The ailerons and rudder are interconnected through a rudder/aileron spring system, which is activated only when controls are out of harmony. In normal coordinated flight, the system is inactive. All flight control systems are operated by closed circuit cable systems.

The elevator trim control is located on the pedestal and the rudder trim control is located on the instrument panel below the autopilot. Aileron trim is provided by a fixed, ground-adjustable tab on the right aileron. The elevator trim control wheel is located on the right side of the pedestal. The trim wheel is rotated forward for nose-down trim and aft for nose-up trim. Rudder trim is achieved by a trim tab driven by an electro-mechanical linear actuator. The rudder trim is activated by depressing a rocker switch, located on the instrument panel below the autopilot. The switch is marked with L and R, corresponding to nose left or nose right. Trim indications, in degrees, are located on the MFD. The green arc indicates the normal takeoff range.

The wing flaps are electrically controlled by a flap selector lever mounted on the instrument panel immediately to the right of the control pedestal. The flap position indicator is located on the MFD. The flaps may be set to one of four positions; up (0°), 10°, 20°, and full down (36°). Each position is detented on the flap selector panel. The flaps will automatically move to the selected position, which can be confirmed by referring to the position indicator. The flaps may be extended to 10° at airspeeds below 168 KIAS, 20° below 135 KIAS, and 36° flap extension is limited to airspeeds below 118 KIAS. When extending the flaps with the landing gear retracted, prior to the flaps reaching the 20° position, the landing gear warning horn will sound, and the red GEAR WARN annunciator will illuminate. If a red FLAP FAIL message displays on the MFD, it is indicative of a flap system malfunction in which case the flap protection circuit automatically removes power from the electric flap motor. Resetting the FLAP WARN circuit breaker will restore normal operating power to the flap motor. If, after resetting, and operation of the flaps, the message displays again, then a system malfunction is indicated and the flap motor circuit breaker should be pulled.

**SECTION 7
DESCRIPTION
AND OPERATION**

PA-46-500TP

**! ===== MERIDIAN
MERIDIAN**

THIS PAGE INTENTIONALLY LEFT BLANK

7.17 FUEL

The fuel system consists of two main, inboard, and header wing tanks, two header tank boost pumps, supply and vapor return fuel lines, and four sump drains. Fuel is drawn from both wings simultaneously, with float valves and switches employed to prevent air ingestion. The two header tank and two fuel return sump drains are located on the lower aft left and right sides of the cowling. The filter sump drain is located adjacent to the left header sump drain. Upon engine shutdown, the fuel remaining in the fuel manifold drains into an EPA fuel purge system. This system utilizes accumulated engine bleed air to force the residual fuel into the burner upon shutdown. A slight and momentary increase in ITT and the possible presence of smoke in the exhaust is normal as the residual fuel is consumed. The fuel shut-off valve is located on the center pedestal under a red protective cover and is pulled for the closed position. A fuel temperature indicator, shown on the MFD, displays the fuel temperature sensed by a fuel temperature probe, located in the right inboard fuel tank. During operations where the fuel temperature indicator is below -23°C (-10°F), the fuel return solenoid valve downstream of the high pressure gear driven pump opens and returns unused fuel from the fuel control unit to the outboard left and right fuel tanks. This returning of warmed fuel to the fuel tanks slows the cooling process of the fuel, which allows the aircraft to operate at temperatures as cold as -54°C (-65°F) for a longer period of time.

NOTE

Fuel pump activation is more likely to occur while warm fuel is being returned to the tanks due to the increased likelihood of fuel tank imbalance.

The return fuel solenoid valve will be energized open when the following conditions are met:

- The valve will always be open during an engine start, regardless of the other conditions.
- When the fuel temperature indicator is below -23°C (-10°F) **AND** the total fuel quantity is more than 100 lbs.

The return fuel solenoid valve will be de-energized (closed) when the following conditions are met:

- Fuel temperature indicator is above -23°C (-10°F) and the engine is not in a start cycle.
- Total fuel quantity is less than 100 lbs. and the engine is not in a start cycle.


7.17 FUEL (continued)

An inline electric boost pump is located in each wing root just forward of the header tanks. Control of these pumps is through a three-position switch located on the left overhead panel with selections: MAN, OFF, and AUTO. The pumps operate in unison to provide emergency back up for the engine driven pump, boost pressure for starting, and vapor suppression at high altitudes. In the AUTO position, a pressure switch activates both pumps automatically when the fuel pressure from the engine driven pump drops below 9 psig, and remains activated until the pressure increases to 12 psig. During this period, the red FUEL PRESS LOW message with aural warning, white L FUEL PUMP ON and white R FUEL PUMP ON messages will illuminate. As pressure increases to 12 psig the pumps are turned off and all three messages extinguish. This boost pump cycling prompts the pilot to select the MAN mode to provide continuous fuel pressure. In the AUTO mode the pumps are also controlled automatically, but separately, by the Garmin Primary Flight Display (PFD). The Garmin system provides a secondary means to control fuel balance. To provide proper fuel balance, a discrete signal from the PFD activates the boost pump on the "heavy" side once a 25-pound imbalance is reached. The system should automatically correct itself.

If the system does not correct itself and the imbalance increases to 40 pounds, a FUEL PUMP ON advisory message will illuminate corresponding to the heavy wing along with an amber FUEL IMBALANCE caution annunciation and a single aural chime indicating a possible fuel balancing system malfunction that may require pilot action.

If the imbalance continues to increase to 125 pounds, a red FUEL IMBALANCE warning annunciation will illuminate along with a repeating aural chime indicating that the maximum allowable fuel imbalance has been reached and the pilot should land as soon as possible.

7.17 FUEL (continued)



Fuel System Schematic
Figure 7-3

7.19 ELECTRICAL

Power for the 28 Vdc negative ground dual fed split bus electrical system is supplied by a direct driven 200 ampere generator and a belt driven 135 ampere alternator. The generator and the alternator are located on the aft end of the engine. Although the units do not operate in true parallel fashion, both units are kept running at the same time. The generator is considered the primary current source and the alternator is the back-up. The units that control the generator and the alternator are adjusted such that the generator furnishes all of the load and the alternator is the backup. In the event that the generator should fail or be turned off for any reason, the alternator picks up the entire load. A single 24 Vdc lead acid battery of 38 ampere hour capacity, is located in the battery compartment in the right side of the nose of the aircraft just forward of the wing leading edge. The battery provides power for engine starting and also acts as an emergency source of electrical power in the event the generator and the alternator should both fail.

Electrical switches are located as follows.

- An overhead switch panel (Figure 7-6) located above the upper edge of the wind shield.
- Avionics and systems switches located on the instrument panel. (Figure 7-9)
- Environmental control panel installed in the instrument panel. (Figure 7-9)

A battery bus, located in the engine compartment, provides a source of power for the courtesy lights. Because the battery bus is connected directly to the battery, power is available for these functions even when the Battery switch is OFF. The battery bus contains fuses to protect these circuits.

The Emergency (EMER) bus can be activated by depressing the EMER switch on the overhead switch panel.

NOTE

In the event of a total electrical failure and to operate exclusively on the emergency bus, the battery master switch must be OFF and the EMER switch ON.

NOTE

The displayed voltage "VOLTS" will be that of the emergency bus when the EMER switch is turned ON and the battery, alternator and generator switches are turned OFF, otherwise the displayed voltage will be that of the TIE BUS.

7.19 ELECTRICAL (continued)

The EMER bus is tied directly to the battery via a relay. The EMER bus provides power to #1 PFD, #1 Comm/Nav/GPS, #1 Audio Panel, #1 AHRS, #1 ADC, Emergency Bus Voltage Indication, Landing Gear Down Lights, Internal Lighting for the Standby Instruments, and Illumination in the Magnetic Compass. The following parameters on PFD 1 will display invalid while operating exclusively on the EMER bus: Fuel Quantity, Torque, Oil Pressure, Vacuum, Cabin Altitude, Cabin Rate and Cabin Differential Pressure. Rudder trim and flaps will not function but the indications will correspond to the values that were present when the power failed and BETA and REVERSE will not be available. The emergency bus is intended to provide emergency power to systems required to land the aircraft in the event of a total electrical failure.

When the Battery switch, located on the overhead switch panel, is turned ON, the battery contactor closes, enabling current to flow from the battery to both the start contactor and the tie bus located on the lower left section of the pilots instrument panel (Figures 7-4 and 7-9). Should the airplane's battery be depleted, a receptacle (located behind a small access door on the left side of the aft fuselage) permits using an external 24 Vdc power source for engine start. With the Battery switch OFF, connecting an appropriate external source completes a circuit that closes the external power contactor, permitting current to flow to the starter generator and the tie bus. Whether using the airplanes battery, or external power, tie bus overcurrent protection is provided by the 150 ampere Battery circuit breaker.

NOTE

The red VOLTS message will illuminate with repeating chime any time the main bus voltage falls below 24 Volts (if the generator is OFF, alternator is OFF and aircraft is on the ground) or 25 Volts (if the generator is ON, alternator is ON, or aircraft is in the air) or any time the EMER bus voltage drops below 24 Volts. Check the voltmeter for correct voltage.

7.19 ELECTRICAL (continued)

The generator and the alternator each have their own independent ON-OFF switch located on the overhead switch panel. Each system also has its own solid state voltage regulator which regulates field voltage to their respective device. When selected ON, the output of the generator and the alternator is fed through individual shunts to the tie bus. The alternator is tied to the bus by a 150 ampere circuit breaker. The generator is tied to the bus by a line contactor which is controlled by the generator control unit (GCU). Should an overvoltage or field ground fault condition occur in the alternator system, its voltage regulator will turn off the output to the alternator field. Once the fault has been cleared the alternator system may be turned back on by turning the alternator switch on the overhead switch panel OFF and then back ON. Should an overvoltage or ground fault condition occur in the generator system the GCU will open the line contactor and place itself in the tripped mode. Once the fault has been cleared the generator can be put back on line by resetting the GENERATOR CONTROL circuit breaker (on the lower left hand instrument panel, Figures 7-4 and 7-9) and turning the generator switch on the overhead switch panel OFF and then back ON. Any time the alternator or generator are turned OFF when the aircraft is in the air, a red ALTERNATOR OFF message or a red GENERATOR OFF message will be displayed on the MFD with repeating aural chimes. Any time the alternator or generator are turned OFF when the aircraft is on the ground, a white ALTERNATOR OFF message or a white GENERATOR OFF message will be displayed on the MFD.


The engine start system has an Auto and a Manual mode. Auto mode is considered the normal mode. In Auto mode, momentarily depressing the PUSH START switch will engage the starter. The starter will automatically disengage at 56% Ng. To disengage the starter or to abort a start in AUTO mode, place the MAN/STOP switch (green indicator light in switch illuminated) to the manual position. When in manual mode, the starter will engage only while the PUSH START switch is depressed.

A main electrical bus with associated circuit breakers is located on the pilot's forward and aft side panels (Figure 7-7). The Non-Essential Bus and #1 Avionics Bus are located on the co-pilot's forward side panel and the #2 Avionics Bus is located on the co-pilot's aft side panel (Figures 7-4 and 7-9). The two avionics busses are interconnected via a 25 ampere bus tie circuit breaker.

7.19 ELECTRICAL (continued)




Current is fed to the main bus by three conductors. Three in line diodes provide isolation in the event of a ground fault in one of the feeder lines. The three feeders are protected by two 80 amp and one 100 amp circuit breakers (Figure 7-4). The non-essential bus is also fed by the 100 amp circuit breaker.

The two avionics busses are fed through independent contactors (Figure 7-4). The feeders to the contactors are protected by 35 ampere circuit breakers. When the AVIONICS switch on the overhead switch panel is depressed, both avionics contactors close allowing current to flow to both avionics busses. Should the need arise, either avionics bus can be isolated by pulling the avionics bus BUS TIE circuit breaker and the appropriate tie bus avionics circuit breaker.



Tie Bus Circuit Breakers
Figure 7-4

7.19 ELECTRICAL (continued)



Overhead Switch Panel


Figure 7-6

SECTION 7
DESCRIPTION
AND OPERATION

PA-46-500TP





7.19 ELECTRICAL (continued)



PILOT'S AFT PANEL


PILOT'S FORWARD PANEL



Circuit Breaker Panel - Pilot's Side, Typical
Figure 7-7

SECTION 7
DESCRIPTION
AND OPERATION

PA-46-500TP




7.21 INSTRUMENT PANEL

The instrument panel has been designed to incorporate the Garmin G1000 Integrated Cockpit. All Communication and Navigation Systems, Flight Instruments, Engine Instruments, and System Annunciations have been integrated into a custom design package specifically for the PA-46-500TP.

All the high current tie bus input and feeder circuit breakers are located on the lower left section of the instrument panel.

THIS SPACE INTENTIONALLY LEFT BLANK



- | | | |
|---------------------------------------|--|-------------------------------------|
| 1. Audio Panel | 10. Mic/Mask Select Switch | 19. Landing Selector |
| 2. Standby Attitude Gyro Test Switch | 11. Hour Meter | 20. Gear Warning Light |
| 3. Standby Attitude Gyro Power Switch | 12. ELT Switch | 21. Bleed Air Shutoff Control |
| 4. Standby Instruments | 13. Environmental Control System Panel | 22. Cabin Pressure Dump Switch |
| 5. Gear Warn Mute Switch | 14. Flaps Position Selector | 23. ECS Cabin Comfort Control |
| 6. Cabin Altitude Mute Switch | 15. Autopilot Controller | 24. Cabin Pressurization Controller |
| 7. Master Warn Switch | 16. Rudder Trim Switch | 25. Tie Buss Circuit Breakers |
| 8. Master Caution Switch | 17. Emergency Landing Gear Extension | 26. ADF Receiver |
| 9. Stall Warning Test Switch | 18. Landing Gear Indicator Lights | 27. Parking Brake |

Instrument Panel, Typical
 Figure 7-9

**SECTION 7
DESCRIPTION
AND OPERATION**

PA-46-500TP

===== MERIDIAN

THIS PAGE INTENTIONALLY LEFT BLANK

7.23 PITOT STATIC SYSTEM

Pitot pressure for the airspeed indicators is sensed by heated pitot heads installed on the bottom of the left and right wings and is carried through lines within the wing and fuselage to the two air data computers mounted behind the instrument panel. Static pressure for the two air data computers and standby altimeter and airspeed indicators is sensed by static source ports on the underside of the fuselage. Static pressure for the pressurization system outflow valve is sensed by a separate static port located on the aft bottom of the aircraft in close proximity to the static ports.

An alternate static source control valve is located below the instrument panel to the left of the pilot. For normal operation, the lever remains down. To select alternate static source, place the lever in the up position. When the alternate static source is selected the airspeed and altimeter and vertical speed indicator are vented to alternate static ports on the aft sides of the fuselage. During alternate static source operation, these instruments may give slightly different readings. The pilot can determine the effects of the alternate static source on instrument readings by switching from standard to alternate sources at different airspeeds. Corrections for each operating mode are shown in Section 5, Performance.

If one or more of the pitot static instruments malfunction, the system should be checked for dirt, leaks or moisture.

The holes in the sensors for pitot and static pressure must be fully open and free from blockage. Blocked sensor holes will give erratic or zero readings on the instruments.

Both the pitot and static systems can be drained through separate drain valves located on both the right and left lower side panel next to the crew seats. Three drains exist on the pilot's side. The forward valve is the pilot's static drain, the center valve is the alternate static drain and the aft valve is the pilot's pitot drain. Two drains exist on the copilot's side. The forward valve is the copilot's static drain and the aft valve is the copilot's pitot drain.

The heated pitot heads, which alleviate problems with icing and heavy rain, are standard equipment. The switch for pitot heat is located on the right overhead switch panel. Static source ports have been demonstrated to be non-icing; however, in the event that icing does occur, selecting the alternate static source will alleviate the problem.

7.25 ENVIRONMENTAL SYSTEM

The environmental system consists of:

- (a) An engine bleed air and conditioning system.
- (b) The ventilating air system.
- (c) An air conditioning system.
- (d) The cabin air distribution system.
- (e) The pressurization and control system.

Compressor bleed air from the P3 engine port supplies air for heating the cabin during flight and ground operations and for pressurization. The bleed air is first routed through a mass flow controller that mixes ambient and bleed air, then the air flow is split between a heat exchanger and muffler. The amount of air flowing through each component is dependent on the cabin air temperature setting. The air then flows into the cabin through the lower left and right cabin side panel ducts, and through the windshield defroster, when selected by pulling the defoster knob located below the right control column. Conditioned bleed air entering the cabin will always be warmer than the outside air and typically warmer than the cabin air.

Cabin ventilating air during ground or unpressurized flight operation is provided by a blower through the lower left and right cabin side panel ducts. The blower is activated by the VENT/FAN switch.

Cabin air conditioning is provided by a vapor cycle system. The compressor is belt driven by the engine dual drive.

The condenser and its cooling air fan are located in the tailcone immediately aft of the rear pressure bulkhead. Cooling air from outside the tailcone is drawn into the cooling air duct through a flush opening in the skin, routed across the condenser coil, and discharged overboard through the tailcone exit opening.

Two recirculation blowers and evaporator assemblies are located aft of each rear seat below the rear baggage compartment floor. The recirculation blowers draw air into each evaporator coil through grills in the floor structure behind the rear seats and discharges it into the upper left and right cabin side panel ducts. Adjustable eyeball outlets are located at each seat location in the airplane.

7.25 ENVIRONMENTAL SYSTEM (continued)

The AIR COND and blower LO & HI switches, located as part of the environmental switch panel in the center of the instrument panel, are used to control the air conditioning system.

When the AIR COND switch is selected ON, the compressor belt drive is electrically clutched, the condenser blower motor relay is closed, and both recirculation blowers are activated. The recirculation blowers can be operated independently of the air conditioner by selecting the blower HI or LO on. In either situation, the blower switches are used only to select a HI or LO recirculation blower motor speed. Overcurrent protection is provided by the 15 amp CABIN FANS, 5 amp AIR CONDITIONING CONTROL, and 25 amp AIR CONDITIONING POWER circuit breakers in the copilot's forward circuit breaker panel.

The HFC-134A portion of the system incorporates a receiver dryer, a sight gauge, suction and discharge service valves, and 265 psi high pressure and 40 psi low pressure switches. Should the compressor discharge pressure increase above 265 psi, or decrease below 40 psi, the applicable pressure switch will open, disengaging the freon compressor clutch.

Refer to paragraph 7.27, BLEED AIR, CONDITIONING AND PRESSURIZATION SYSTEM, for a more complete description of the pressurization system and use of related controls and switches.

7.27 BLEED AIR, CONDITIONING AND PRESSURIZATION SYSTEM

Air for cabin pressure is obtained from the P3 engine bleed port. Bleed air is routed through the mass flow and temperature controllers. The mass flow controller meters the amount of mass flow to the cabin through an actuator controlled, ambient and bleed air, mixing ejector. The amount of mass flow is controlled by a four position rotary switch located to the right of the left control column. The available settings are OFF, NORM, HIGH, and EMER.

The temperature controller sets the percentage of bleed air that will flow through the cooling heat exchanger versus the percentage that will flow through the acoustic muffler. The amount of air through each device determines the mixed cabin supply air temperature. The temperature controls are located on the instrument panel to the lower-left of the co-pilot's control column and have two modes of operation, automatic and manual. Cabin temperature is controlled by a relative temperature knob when in automatic mode and an increase/decrease rocker switch when in manual mode. The automatic temperature mode relies on the cabin temperature sensor, located behind the pilot in a side close out panel, for temperature regulation. The manual temperature mode directly controls the amount of air flowing through the cooling heat exchanger and acoustic muffler.

The cabin pressurization control system consists of an isobaric outflow valve, a safety outflow valve, absolute pressure regulator, cabin altitude and rate selector, electrically operated vacuum solenoid valve, and surge tank.

Cabin altitude, differential pressure, and rate of cabin altitude change are displayed on the MFD. Cabin pressure is automatically regulated to a maximum of 5.5 psi pressure differential. Should the cabin outflow valve malfunction, the cabin safety valve will maintain a maximum of 5.6 cabin differential pressure. The landing gear squat switch and vacuum pressure prevents the cabin from being pressurized while the airplane is on the ground.

7.27 BLEED AIR, CONDITIONING AND PRESSURIZATION SYSTEM (continued)

Should cabin pressure altitude exceed 10000 feet, an amber CABIN ALT 10000 message and aural caution will alert the pilot. If the cabin altitude exceeds 12,000 feet, the emergency bleed air solenoid is automatically opened and a white EMER BLEED ON message and a red CABIN ALT 12000 (as sensed by the GAE43 or 12K switch) message and aural warning will replace the amber CABIN ALT 10000 message. If the cabin altitude exceeds 13,500 feet, the absolute pressure regulator will close the isobaric outflow valve. The cabin pressurization system isobaric outflow valve provides the means by which smoke and impurities are vented from the cabin.

For pressurized flight, set the cabin pressure controller at 500 feet above the airport pressure altitude, ECS CABIN COMFORT control set to NORM and the DUMP switch set to CAB PRES (DUMP extinguished). The rate of cabin ascent and descent change is controlled with the rate knob (left lower corner of the cabin pressure controller), and may be adjusted between approximately 200 and 2000 feet per minute, as desired. Setting the rate knob arrow to the 9 o'clock position provides a cabin rate of change of approximately 500 feet per minute. This position gives a comfortable rate for normal operations.


For complete instructions on the operation of the cabin pressurization system, refer to Section 4, Normal Procedures.

The CAB PRES/DUMP switch, when set to DUMP, electrically opens a solenoid valve allowing vacuum suction pressure to open the safety valve and rapidly dump cabin pressure to ambient pressure.

For unpressurized flight the ECS CABIN COMFORT control should be set to OFF and the pressurization bleed air shut off valve pulled closed. Setting the CAB PRES/DUMP switch to DUMP will provide maximum airflow through the cabin.

For complete instructions on pressurization malfunctions, refer to Section 3 - Emergency Procedures.

Emergency Oxygen System Installation
Figure 7-10



The pilot diluter demand emergency oxygen system consists of a quick donning mask, stowage box, pressure gauge, and oxygen bottle with pressure regulator and shut-off valve assembly. The complete system is contained within a cabinet located behind the copilot seat. Figure 7-10 shows the pilot emergency oxygen system as installed within the cabin.

7.28 EMERGENCY OXYGEN SYSTEM

SECTION 7
DESCRIPTION
AND OPERATION

7.28 EMERGENCY OXYGEN SYSTEM (Continued)

The oxygen system is activated by a lever located above the stowage box and slightly recessed within the cabinet. A placard on the cabinet clearly marks the ON and OFF positions. The system pressure gauge is located on top of the cabinet and is illuminated by a post light. The pressure gauge incorporates a yellow arc from 0 to 800 psi. The minimum safe charge for pressurized operation above 25,000 feet is 800 psi or above. The quick donning mask stowage box incorporates a test indicator and is located in the upper left corner of the stowage box face. A press-to-test button is also located in the lower left corner of the stowage box face. The controls on the mask itself consist of a switch to select between diluted/normal (N) flow and non-diluted flow (100%), as well as an additional emergency pressure breather switch. Integral to the mask supply line and adjacent to the mask is a secondary flow indicator.

To remove the mask from the stowage box, pull on the inflation control valve (red handles) protruding from the face of the stowage box. Once removed, depressing the inflation control valve inflates the harness and allows it to be placed over the head. After the harness is completely over the head, releasing the inflation control valve will firmly hold the mask in place. To achieve optimum fit, simply reinflate the harness by depressing the inflation control valve and adjusting the mask as needed. The MIC SELECT switch, located above the pilot's PFD, when in the mask position activates the mask microphone. Continued oxygen system operation can be verified by the pressure gauge, located on top of the cabinet, and two flow indicators, one located on the face of the stowage box and the other integral to the oxygen mask supply line.

With the system charged to 800 psi or higher and the mask set to normal (N), the pilot oxygen system will provide adequate oxygen for an emergency descent from 30,000 feet to 10,000 feet. The 15 minute descent profile used to define the minimum safe oxygen charge includes a one-minute dwell time at 30,000 feet, a 5,000 fpm descent to 10,000 feet, followed by a 10 minute hold at 10,000 feet. With the system fully charged to 1800 psi and the mask set to normal (N), the oxygen system will provide oxygen to the pilot for approximately 25 minutes at 30,000 feet.

NOTE

Pilot oxygen system pressure must be above the yellow arc, or greater than 800 psi, during pressurized flight above 25,000 feet.

7.28 EMERGENCY OXYGEN SYSTEM (Continued)

The emergency oxygen system for all occupants other than the pilot consists of three two-man oxygen generators and six masks. The system consists of two major assemblies, the copilot and cabin passenger assemblies. The oxygen generators provide sufficient oxygen flow for six people for a 15 minute period. Once an oxygen generator is activated, it will continue to produce oxygen until depleted, as no shutoff provisions are provided. Each generator has two oxygen masks connected, either of which is capable of activating the generator.

The copilot assembly is located under the copilot seat and contains two masks and one two-man oxygen generator mounted on a sliding tray. The tray slides out into the aisle between the pilot and copilot seat, exposing the two masks. Each mask is connected to the oxygen generator via a clear plastic oxygen delivery tube and lanyard. Pulling either of the masks, and thus the lanyard, activates the oxygen generator and delivers oxygen to both masks simultaneously. The additional mask can be used by the pilot in the event of a failed pilot demand oxygen system. The generator has two over-pressure relief valves to prevent excessive pressure should a malfunction in the system occur.

The cabin passenger assembly is located in a drawer beneath the right rear-facing passenger seat. Four masks and two two-man oxygen generators are accessed by sliding the drawer out in the aft direction. The two inboard masks are connected to the first oxygen generator, while the two outboard masks are connected to the second generator. Any of the four masks will reach any of the four passengers. Activation and operation of the passenger oxygen generators is identical to the copilot assembly.

Placards are provided on the side panels outboard of the copilot's seat and the right aft-facing seat; the placards state the location and operation of the copilot and passenger emergency oxygen system, and that smoking is prohibited.

An OXYGEN message is provided to inform the crew whenever either of the three oxygen generators has been activated. The message is displayed as a white advisory while on the ground but as an amber caution while in flight and is activated by a microswitch on each generator. The message will continue to illuminate until the used generator is replaced with a full one.

7.29 VACUUM SYSTEM

Vacuum for the system is provided by an ejector, driven by pressure regulated, precooled engine bleed air. Also, included is a vacuum regulator and a low vacuum switch.

Vacuum is used for pneumatic deice boot hold down and as a source of control pressure for the cabin pressure control system. Vacuum level indication, displayed on the MFD, is for general vacuum system health monitoring, and is for reference only. Transient decreases in vacuum during pneumatic boot operation can be expected. Any sustained decrease in system vacuum may indicate a sticking or maladjusted vacuum regulator, a leak in the system, or a failure of the ejector. The amber VACUUM LOW caution message indicates that vacuum level has dropped below 2.0 In. Hg., which is considered an excessively low value.

7.31 STALL WARNING SYSTEM

The stall warning system consists of a lift transducer located in the leading edge of the left wing and a lift computer to power regulators, a signal processor, control circuitry and a push-to-test switch. The lift transducer provides into the air stream and during flight is positioned by local airflow velocity and direction. A continuous stall warning tone will sound prior to the actual stall.

Activation of the stall warning push-to-test switch (STALL TEST) during ground operation will produce an aural stall warning tone, verifying proper stall warning operation. If the autopilot were to be engaged during the stall warning test, it will disengage once the stall warning test button is depressed. The amber STALL WARN FAIL caution message indicates that the lift computer and/or lift transducer has failed.

7.33 EMERGENCY LOCATOR TRANSMITTER

The Emergency Locator Transmitter (ELT) operates on self-contained batteries and is located in the aft fuselage section. It is accessible through a cover on the bottom right side of the fuselage.

A battery replacement date is marked on the transmitter. To comply with FAA regulations, the battery must be replaced on or before this date. The battery must also be replaced if the transmitter has been used in an emergency situation, if the accumulated test time exceeds one hour, or if the unit has been inadvertently activated for an undetermined time period.

NOTE

If for any reason a test transmission is necessary, the test transmission should be conducted only in the first five minutes of any hour and limited to three audio sweeps. If a test must be made at any other time, the test should be coordinated with the nearest FAA tower or flight service station.

ARTEX ELT OPERATION

On the ELT unit itself is a two position switch placarded ON and OFF. The OFF position is selected when the transmitter is installed at the factory and the switch should remain in that position whenever the unit is installed in the airplane.

A pilots remote switch, placarded ON and ARM is located on the copilots instrument panel to allow the transmitter to be armed or turned on from inside the cabin. The switch is normally in ARM position. Moving the switch to ON will activate the transmitter. A warning light located above the remote switch will alert you when ever the ELT is activated.

The ME-406 ELT (406 MHz), if installed, is equipped with a warning buzzer. This warning buzzer, which receives power from the ELT itself, is mounted in the tailcone. Whenever the ELT is activated the buzzer "beeps" periodically. The time between pulses lengthens after a predetermined transmitter "ON" time. The objective is to hear the buzzer from outside the aircraft while the engine is not running.

7.33 EMERGENCY LOCATOR TRANSMITTER (continued)

ARTEX ELT OPERATION (continued)

Should the ELT be activated inadvertently it can be reset by either positioning the remote switch to the ON then immediately relocating it to the ARM position, or by setting the switch on the ELT to ON and then back to OFF.

In the event the transmitter is activated by an impact, it can be turned off by moving the ELT switch OFF. Normal operation can then be restored by resetting the switch to ARM. It may also be turned off and reset by positioning the remote switch to the ON and then immediately to the ARM position.

The transmitter can be activated manually at any time by placing either the remote switch or the ELT switch to the ON position.

NOTE

Three sweeps of the emergency tone and an illuminated warning light indicates a normally functioning unit. The warning light must illuminate during the first 2 second test period. If it does not illuminate, a problem is indicated such as a "G" switch failure.

The ELT should be checked during postflight to make certain the unit has not been activated. Check by selecting 121.50 MHz on an operating receiver. If a downward sweeping audio tone is heard the ELT may have been activated. Set the remote switch to ON. If there is no change in the volume of the signal, your airplane's ELT is probably transmitting. Setting the remote switch back to OFF will automatically reset the ELT and should stop the signal being received on 121.50 MHz.

**SECTION 7
DESCRIPTION
AND OPERATION**

PA-46-500TP



THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS


SECTION 8

AIRPLANE HANDLING, SERVICING, AND MAINTENANCE

Paragraph No.		Page No.
8.1	General	8-1
8.3	Airplane Inspection Periods	8-4
8.5	Preventive Maintenance	8-5
8.7	Airplane Alterations	8-5
8.8	Airplane File	8-6
8.9	Ground Handling	8-6
8.13	Brake Service	8-9
8.15	Hydraulic System Service	8-11
8.17	Landing Gear Service	8-11
8.19	Propeller Service	8-12
8.21	Oil Requirements	8-13
8.23	Fuel System	8-16
8.25	Tire Inflation	8-22
8.27	Battery Service	8-22
8.29	Emergency Oxygen System	8-22
8.31	Pressurization System	8-22
8.33	Lubrication	8-24
8.35	Cleaning	8-24
8.36	Cleaning and Maintenance of Relief Tube System	8-29
8.37	Cleaning Garmin PFD and MFD Displays	8-30
8.38	Cleaning and Maintenance of the PT6A Compressor and Compressor Turbine	8-31

**SECTION 8
HANDLING, SERVICING
AND MAINTENANCE**

PA-46-500TP



THIS PAGE INTENTIONALLY LEFT BLANK

SECTION 8

AIRPLANE HANDLING, SERVICING, AND MAINTENANCE

8.1 GENERAL


This section provides guidelines relating to the handling, servicing, and maintenance of the Meridian. For complete maintenance instructions, refer to the PA-46-500TP Maintenance Manual.

WARNING

Inspection, maintenance and parts requirements for all non-PIPER approved STC installations are not included in this handbook. When a non-PIPER approved STC installation is incorporated on the airplane, those portions of the airplane affected by the installation must be inspected in accordance with the inspection program published by the owner of the STC. Since non-PIPER approved STC installations may change systems interface, operating characteristics and component loads or stresses on adjacent structures, PIPER provided inspection criteria may not be valid for airplanes with non-PIPER approved STC installations.

WARNING

Modifications must be approved in writing by PIPER prior to installation. Any and all other installations, whatsoever, of any kind will void this warranty in it's entirety.



8.1 GENERAL (Continued)

WARNING

Use only genuine PIPER parts or PIPER approved parts obtained from PIPER approved sources, in connection with the maintenance and repair of PIPER airplanes.

Genuine PIPER parts are produced and inspected under rigorous procedures to insure airworthiness and suitability for use in PIPER airplane applications. Parts purchased from sources other than PIPER, even though identical in appearance, may not have had the required tests and inspections performed, may be different in fabrication techniques and materials, and may be dangerous when installed in an airplane.

Additionally, reworked or salvaged parts or those parts obtained from non-PIPER approved sources, may have service histories which are unknown or cannot be authenticated, may have been subjected to unacceptable stresses or temperatures or may have other hidden damage not discernible through routine visual or nondestructive testing. This may render the part, component or structural assembly, even though originally manufactured by PIPER, unsuitable and unsafe for airplane use.

PIPER expressly disclaims any responsibility for malfunctions, failures, damage or injury caused by use of non-PIPER approved parts.

8.1 GENERAL (Continued)

Every owner should stay in close contact with an approved Piper Service Center or Piper's Customer Services Department to obtain the latest information pertaining to their airplane, and to avail themselves of Piper's support systems.

Piper takes a continuing interest in having owners get the most efficient use from their airplane and keeping it in the best mechanical condition. Consequently, Piper, from time to time, issues service releases including Service Bulletins, Service Letters, Service Spares Letters, and others relating to the airplane.

Piper Service Bulletins are of special importance and Piper considers compliance mandatory. These are available on the Piper.com website. Depending on the nature of the release, material and labor allowances may apply. This information is provided to all approved Piper Service Centers.

Service Letters deal with product improvements and servicing techniques pertaining to the airplane. They are available on the Piper.com website.. Owners should give careful attention to Service Letter information.

Service Spares Letters offer improved parts, kits, and optional equipment which were not available originally, and which may be of interest to the owner.

Maintenance manuals, parts catalogs, and revisions to both, are available from Piper Service Centers.

Any correspondence regarding the airplane should include the airplane model and serial number to ensure proper response.

8.3 AIRPLANE INSPECTION PERIODS

WARNING

All inspection intervals, replacement time limits, overhaul time limits, the method of inspection, life limits, cycle limits, etc., recommended by PIPER are solely based on the use of new, remanufactured or overhauled PIPER approved parts. If parts are designed, manufactured, remanufactured, overhauled and/or approved by entities other than PIPER, then the data in PIPER'S maintenance/service manuals and parts catalogs are no longer applicable and the purchaser is warned not to rely on such data for non-PIPER parts. All inspection intervals, replacement time limits, overhaul time limits, the method of inspection, life limits, cycle limits, etc., for such non-PIPER parts must be obtained from the manufacturer and/or seller of such non-PIPER parts.

Piper has developed inspection items and required inspection intervals for the PA-46-500TP. The PA-46-500TP Progressive Inspection Manual contains appropriate forms, and all inspection procedures should be complied with by a properly trained, knowledgeable, and qualified mechanic at an authorized Piper Service Center or a reputable repair shop. Piper cannot accept responsibility for the continued airworthiness of any aircraft not maintained to these standards, and/or not brought into compliance with applicable Service Bulletins issued by Piper, instructions issued by the engine, propeller, or accessory manufacturers, or Airworthiness Directives issued by the FAA.

In addition, but in conjunction with the above, the FAA requires periodic inspections on all aircraft to keep the Airworthiness Certificate in effect. The owner is responsible for assuring compliance with these inspection requirements and for maintaining proper documentation in logbooks and/or maintenance records.

8.5 PREVENTIVE MAINTENANCE

The holder of a pilot certificate issued under Federal Aviation Regulations (FAR) Part 61 may perform certain preventive maintenance as defined in the FARs. This maintenance may be performed only on an aircraft which the pilot owns and operates, and which is not used in air carrier or air taxi/commercial operations service.


All other aircraft maintenance must be accomplished by a person or facility appropriately certificated by the Federal Aviation Administration (FAA) to perform that work.

Anytime maintenance is accomplished, an entry must be made in the appropriate aircraft maintenance records. The entry shall include:

- (a) The date the work was accomplished.
- (b) Description of the work.
- (c) Number of hours on the aircraft.
- (d) The certificate number of pilot performing the work.
- (e) Signature of the individual doing the work.

8.7 AIRPLANE ALTERATIONS

If the owner desires to have his aircraft modified, he must obtain FAA approval for the alteration. Major alterations accomplished in accordance with Advisory Circular 43.13-2, when performed by an A & P mechanic, may be approved by the local FAA office. Major alterations to the basic airframe or systems not covered by AC 43.13-2 may require a Supplemental Type Certificate.



8.8 AIRPLANE FILE

The owner or pilot is required to ascertain that the following aircraft papers are in order and in the aircraft.

- (a) To be displayed in the aircraft at all times:
 - (1) Aircraft Airworthiness Certificate Form FAA-8100-2.
 - (2) Aircraft Registration Certificate Form FAA-8050-3.

- (b) To be carried in the aircraft at all times:
 - (1) Pilot's Operating Handbook and FAA approved Airplane Flight Manual.
 - (2) Weight and Balance data plus a copy of the latest Repair and Alteration FAA Form -337, if applicable.
 - (3) Aircraft equipment list.

Although the aircraft and engine logbooks are not required to be in the aircraft, they should be made available upon request. Logbooks should be complete and up to date. Good records will reduce maintenance cost by giving the mechanic information about what has or has not been accomplished.

8.9 GROUND HANDLING

(a) Towing

The airplane may be moved on the ground by power equipment that will not damage or excessively strain the nose gear steering assembly.

CAUTION

When towing with power equipment, do not turn the nose gear beyond its steering limit in either direction, as this will result in damage to the nose gear and steering mechanism.

CAUTION

Do not tow the airplane when the controls are secured.

In the event towing lines are necessary, ropes should be attached to both main gear struts as high up on the tubes as possible. Lines should be long enough to clear the nose and/or tail by not less than fifteen feet, and a qualified person should ride in the pilot's seat to maintain control by use of the brakes.

8.9 GROUND HANDLING (Continued)**(b) Taxiing****CAUTION**

Do not operate engine above ground idle with cabin doors open.

Before attempting to taxi the airplane, ground personnel should be instructed and approved by a qualified person authorized by the owner. Engine starting and shut-down procedures as well as taxi techniques should be covered. When it is ascertained that the propeller blast and taxi areas are clear, power should be applied to start the taxi roll, and the following checks should be performed:

- (1) Taxi a few feet forward and apply the brakes to determine their effectiveness.
- (2) Propeller thrust may be modulated from full forward to full reverse by selection of the reversing range. A lock-out feature allows reverse pitch to function only during ground operations.
- (3) While taxiing, make slight turns to ascertain the effectiveness of the steering.
- (4) Observe wing clearance when taxiing near buildings or other stationary objects. If possible, station an observer outside the airplane.
- (5) When taxiing over uneven ground, avoid holes and ruts.
- (6) Do not operate the engine at high rpm when running up or taxiing over ground containing loose stones, gravel, or any loose material that may cause damage to the propeller blades.
- (7) When the airplane is stopped on the taxiway or runway and brake freeze-up occurs, actuate the brakes several times using maximum pressure. To reduce the possibility of brake freeze-up during taxi operation in severe weather conditions, one or two taxi slow downs (from 25 to 5 knots) may be made using light brake pressure, which will assist moisture evaporation within the brake.
- (8) Minimize ground operation in Beta/Reverse and monitor engine oil temperature.

8.9 GROUND HANDLING (Continued)

(c) Parking

When parking the airplane, be sure that it is sufficiently protected from adverse weather conditions and that it presents no danger to other aircraft. When parking the airplane for any length of time or overnight, it is suggested that it be moored securely.

- (1) To park the airplane, head it into the wind if possible.**
- (2) The parking brake knob is located just below the left control column. To set the parking brake, first depress and hold the toe brakes and then pull out on the parking brake knob. To release the parking brake, first depress the brake pedals and then push in on the parking brake knob.**

CAUTION

Care should be taken when setting brakes that are overheated or during cold weather when accumulated moisture may freeze a brake.

- (3) Aileron and elevator controls should be secured with the front seat belt and chocks should be used to properly block the wheels.**

(d) Mooring

The airplane should be moored for immovability, security and protection. The following procedures should be used for the proper mooring of the airplane:

- (1) Head the airplane into the wind if possible.**
- (2) Retract the flaps.**
- (3) Immobilize the ailerons and elevator by looping the seat belt through the control wheel and pulling it snug.**
- (4) Place chocks both fore and aft of the main wheels.**

8.9 GROUND HANDLING (Continued)**(d) Mooring (continued)**

- (5) Secure tiedown ropes to main landing gear and tail tiedown at approximately 45 degree angles to the ground. When using rope of non-synthetic material, leave sufficient slack to avoid damage to the airplane should the ropes contract.

CAUTION

Use bowline knots, square knots or locked slip knots. Do not use plain slip knots.

NOTE

Additional preparations for high winds include using tiedown ropes from the nose landing gear and securing the rudder.


- (6) Install pitot head covers if available. Be sure to remove the pitot head covers before flight.
- (7) The cabin door should be locked when the airplane is unattended.
- (8) For overnight or in blowing snow or dust, install engine inlet covers and dust covers on the air inlet cooling duct on top of the cowling and on the exhaust stacks. Attach propeller restrainers to prevent windmilling.

8.13 BRAKE SERVICE

The brake system is filled with MIL-H-5606 (petroleum base) hydraulic fluid. The fluid level should be checked periodically (at least every 90 days) or at every 100 hour inspection, and replenished when necessary. The brake fluid reservoir is located on the left side of the firewall. If the entire system must be refilled, fill with fluid under pressure from the brake end of the system. This will eliminate air from the system.

No adjustment of the brake clearances is necessary. If, after extended service, brake blocks become excessively worn they should be replaced with new segments.

1. DISC BRAKE ASSEMBLY
2. BRAKE FLUID RESERVOIR
3. PARKING BRAKE CONTROL
4. PARKING BRAKE VALVE
5. BRAKE LINES
6. BRAKE CYLINDER



BRAKE SYSTEM

Figure 8-1

8.15 HYDRAULIC SYSTEM SERVICE

The hydraulic system reservoir is an integral part of the electric hydraulic pump assembly. It is located aft of the aft cabin baggage compartment and is accessible through the baggage compartment aft closeout panel. Fill the reservoir with MIL-H-5606 hydraulic fluid. The fluid level should be checked periodically (at least every 90 days) or at every 100 hour inspection, and replenished when necessary. With the landing gear down and the system up to pressure, fill to the FULL line on the sight gauge.

8.17 LANDING GEAR SERVICE

The main landing gear uses 6.00 x 6 wheels with 6.00 x 6, eight-ply rating tires and tubes. (Refer to paragraph 8.25.)

The nose wheel uses a 5.00 x 5 wheel with a 5.00 x 5 eight-ply rating, type III tire and tube. (Refer to paragraph 8.25.)

Wheels are removed by taking off the hub cap, cotter pin, axle nut, and bolts holding the brake segment in place. Mark tire and wheel for reinstallation; then dismount by deflating the tire, removing the through-bolts from the wheel and separating the wheel halves.

Landing gear oleos should be serviced according to the instructions on the units. The main oleos should be extended under normal static load until 3.14 +/- 0.25 inches of oleo piston tube is exposed, and the nose gear should show 2.7 +/- 0.25 inches. To add air to the oleo struts, attach a strut pump to the valve assembly near the top of the oleo strut housing and pump the oleo to the desired position. To add oil, jack the aircraft, release the air pressure in the strut, remove the valve core and add oil through this opening with the strut extended. After the strut is full, compress it slowly and fully to allow excess air and oil to escape. With the strut still compressed reinsert the valve core and pump up the strut as above.

8.17 LANDING GEAR SERVICE (Continued)

In jacking the aircraft for landing gear or other service, two hydraulic jacks and a tail stand should be used. At least 400 pounds of ballast should be placed on the base of the tail stand before the airplane is jacked up. The hydraulic jacks should be placed under the jack points on the bottom of the wing and the airplane jacked up until the tail skid is at the right height to attach the tail stand. After the tail stand is attached and the ballast added, jacking may be continued until the airplane is at the height desired.

The steering rods from the rudder pedals to the transverse bellcrank in the nose wheel tunnel are factory adjusted and should be readjusted only in accordance with the applicable rigging specification. Nose wheel alignment is accomplished by adjusting the rod end(s) on the steering bungee assembly in such a way that the nose wheel is in line with the fore and aft axis of the plane when the rudder pedals are centered. Alignment of the nose wheel can be checked by pushing the airplane back and forth with the rudder two degrees to the right to determine that the plane follows a straight line. The turning arc of the nose wheel is $30^{\circ} \pm 1^{\circ}$ in either direction and is limited by stops at the trunnion forging or the forward steering contact arm mounted on the engine mount.

NOTE

The rudder is set to neutral with the rudder pedals neutralized and the nose wheel centered.

8.19 PROPELLER SERVICE

The spinner and backing plate should be cleaned and inspected for cracks frequently. Before each flight the propeller should be inspected for nicks, scratches, and corrosion. Significant damage must be repaired by a qualified mechanic prior to flight. Nicks or scratches cause an area of increased stress which can lead to serious cracks or the loss of a propeller tip. The back face of the blades should be painted when necessary with flat black paint to retard glare. To prevent corrosion, the surface should be cleaned and waxed periodically.

8.21 OIL REQUIREMENTS

Oil conforming to Pratt & Whitney Canada Service Bulletin 3001 and all revisions or supplements thereto, must be used. The oils listed below comply with the engine manufacturers specification PWA521 and have a viscosity Type II rating. These oils are fully approved for use in Pratt & Whitney Canada, Inc. commercially operated engines. When adding oil, service the engine with the type and brand which is currently being used in the engine. Refer to the airplane and engine maintenance records for this information. Should oils of different viscosities or brands be inadvertently mixed, the oil system servicing instructions in the Pratt & Whitney Maintenance Manual, p/n 3013242, shall be carried out.

Exxon Turbo Oil 2380

Aero Shell Turbine Oil 500

Aero Shell Turbine Oil 560 (Third generation lubricant)

Royco Turbine Oil 500

Royco Turbine Oil 560 (Third generation lubricant)

Mobil Jet Oil II

Mobil Jet Oil 254 (Third generation lubricant)

Castrol 5000

Turbonycoil 525-2A

CAUTION

Do not mix brands or types of oils.

When changing from an existing lubricant formulation to a "third generation" lubricant formulation (see list above), the engine manufacturer strongly recommends that such a change should only be made when an engine is new or freshly overhauled. For additional information on the use of third generation oils, refer to the engine manufacturer's pertinent oil service bulletins.

8.21 OIL REQUIREMENTS (Continued)

TOTAL OIL CAPACITY

12 U.S. quarts (11.4 L) (including oil in filter, cooler and hoses)

DRAIN AND REFILL QUANTITY

Approximately 9.2 U.S. quarts (8.7L).

OIL QUANTITY OPERATING RANGE

NOTE

Oil quantity operating range may be verified either by the dipstick method or by the visual sight glass method. Either method is acceptable for oil quantity preflight operations.

Dipstick Method

Fill to within 1½ quarts of MAX HOT or MAX COLD (as appropriate) on dipstick. Quart markings indicate U.S. quarts low if oil is hot. For example, a dipstick reading of 3 indicates the system is within 2 quarts of MAX, if the oil is cold, and within 3 quarts of MAX if the oil hot. It is recommended the oil level be checked either within 10 minutes after engine shutdown while the oil is hot (MAX HOT marking) or prior to the first flight of the day while the oil is cold (MAX COLD marking). If more than 10 minutes has elapsed since engine shutdown, and engine oil is still warm, perform an engine dry motoring run (Section 4.15) before checking oil level.

WARNING

Ensure oil dipstick cap is securely latched down. Operating the engine with less than the recommended oil level and with the dipstick cap unlatched will result in excessive oil loss and eventual engine stoppage.

8.21 OIL REQUIREMENTS (Continued)

OIL QUANTITY OPERATING RANGE (continued)

Sight Glass Method

Engine oil quantity may be determined by using the visual sight glass located on the aft, left corner of the engine. Oil quantity (whether hot or cold) indicated in the green area of the sight glass is adequate for flight operations.

OIL DRAIN PERIOD

Pratt & Whitney Canada experience, over an extended period of time, has indicated that regular oil changes are no longer necessary for the PT6A-42 engine. However, operators should be aware of the danger of oil contamination from extraneous matter such as hydraulic fluid, sand, etc. which would require the oil system to be drained, flushed and replenished with new oil of an approved brand.

8.23 FUEL SYSTEM

(a) Servicing Fuel System

At every 100 hour inspection or after an extended downtime, the fuel filter strainer must be cleaned. The fuel filter strainer is located under the aft nose section on the left side.

(b) Fuel Requirements (Jet A, Jet A-1)

NOTE

For approved additives, refer to Pratt & Whitney Service Bulletin 3044.

The operation of the aircraft is approved only with an anti-icing additive in the fuel. If pre-blended fuel is not used, then an anti-icing additive must be added to the fuel when refueling. The anti-icing additive must meet the specification MIL-I-27686, must be uniformly blended with the fuel while refueling, and must not exceed 0.15% by volume. *One and one half liquid* ounces per ten gallons of fuel would fall within this range. A blender supplied by the additive manufacturer should be used. Except for the information contained in this section, the manufacturer's mixing or blending instructions should be carefully followed.

CAUTION

Assure that the additive is directed into the flowing fuel stream. The additive flow should start after and stop before the fuel flow. Do not permit the concentrated additive to come in contact with the aircraft painted surfaces or the interior surfaces of the fuel tanks.

Some fuels have anti-icing additives pre-blended in the fuel at the refinery, so no further blending should be performed.

Fuel additive can not be used as a substitute for preflight draining of the fuel system drains.

8.23 FUEL SYSTEM (Continued)**(c) Filling Fuel Tanks****WARNING**

Do not operate any avionics or aircraft electrical equipment during refueling. Do not allow open flame or smoking in the vicinity of the airplane while refueling.

During all refueling operations, fire fighting equipment must be available. Two ground wires from different points on the airplane to separate approved grounding stakes shall be used.

Observe all safety precautions required when handling fuel. Fill the fuel tanks through the filler located on the forward slope of the wing. Each wing holds 570 pounds (85 U.S gallons) of usable fuel. When using less than the standard 570 pounds capacity, fuel should be distributed equally between each side.

CAUTION

Fuel imbalance must not exceed 125 pounds prior to takeoff.

NOTE

Aircraft should be refueled in a wing level condition. At times this will require alternate filling of left and right tanks until the full condition is reached.


8.23 FUEL SYSTEM (Continued)

(d) Draining Fuel Strainer, Sumps and Lines

The fuel tank sumps, fuel return sumps, and fuel filter should be drained before the first flight of the day and after refueling. The fuel tank sumps and fuel return sumps, which represent the lowest points in the system, are located in the left/right header tanks and behind the firewall at the left/right wing roots respectively. Each fuel system sump drains via flush mounted valves located on the left and right aft bottom portion of the engine cowling. (Refer to Figure 8-4.) The fuel filter drain is located on the lower left side of the cowling a few inches forward of the left sump drain. Sumps and filter should be drained until sufficient fuel has flowed to ensure the removal of any contaminants. (The first fuel sample cup full will only drain fuel from the lines; more than one cup sampling must be taken to assure fuel sample is from the fuel tanks). When draining filter and sumps, use the end of the rod to push in the valve, catching fuel in the cup. (Refer to Figure 8-3.) Always inspect fuel for contaminants, water and fuel grade (color). Assure that valves have sealed after draining.

NOTE

Sump drains will lock open if valve is pushed in and turned. Continue turning to release lock.



FUEL TANK DRAIN

Figure 8-3

8.23 FUEL SYSTEM (Continued)**(e) Emptying Fuel System (See Figure 8-4.)****CAUTION**

When draining any amount of fuel, care should be taken to ensure that no fire hazard exists before starting the engine.

CAUTION

Whenever the fuel system is completely drained and fuel is replenished, it will be necessary to purge the fuel system and the fuel control, per the Pratt & Whitney Engine Maintenance Manual, to insure that no air exists in the fuel supply lines.

For draining a large volume of fuel, a quick evacuation outlet is incorporated into the fuel system and is located adjacent to the fuel filter. Fuel can be drained from this outlet by gravity or by using the airplane's boost pumps. Using the airplane's boost pumps provides a means of draining the left and right sides separately.

Draining fuel using gravity is accomplished as follows:

- (1) Remove the filter access door.
- (2) Close the firewall shutoff valve.
- (3) Remove the cap and connect a 1/2 inch hose to the quick evacuation outlet.
- (4) Place the other end of the hose in a suitable container. (Be sure the container is large enough to hold the amount of fuel to be drained.)
- (5) Open the firewall shutoff valve and allow the fuel to flow into the container.
- (6) To stop the fuel flow, close the firewall shutoff valve.
- (7) Install the cap on the quick evacuation outlet, and safety wire.

8.23 FUEL SYSTEM (Continued)


(e) Emptying Fuel System (continued)

Draining fuel using the airplane's boost pumps is accomplished as follows:

- (1) Remove the filter access door.
- (2) Close the firewall shutoff valve.
- (3) Remove the cap and connect a 1/2 inch hose to the quick evacuation outlet.
- (4) Place the other end of the hose in a suitable container. (Be sure the container is large enough to hold the amount of fuel to be drained.)
- (5) Open the firewall shutoff valve.
- (6) Turn the boost pump switch to MAN. (To stop fuel flow, move the switch to OFF and close the firewall shutoff valve.)
- (7) If fuel is to be drained from only one side, follow the procedure above except pull the circuit breaker for the pump that is not required.
- (8) Install the cap on the quick evacuation outlet, and safety wire.

NOTE

The boost pumps are disabled at approximately 2.5 gallons per side. Most of the remaining fuel can be drained by gravity from the quick evacuation outlet, but the final small amount must be drained from the sump drains.



1. RIGHT RETURN LINE SUMP DRAIN
2. RIGHT FUEL TANK SUMP DRAIN
3. FIREWALL SHUTOFF VALVE
4. LEFT FUEL TANK SUMP DRAIN
5. FUEL FILTER DRAIN
6. LEFT RETURN LINE SUMP DRAIN
7. FUEL FILTER ACCESS DOOR
8. QUICK EVACUATION OUTLET

FUEL QUICK EVACUATION SYSTEM

Figure 8-4

8.25 TIRE INFLATION

For maximum service, keep tires inflated to the proper pressure: nose tire should be 70 psi or 50 psi, depending on type of tire installed (see placard on nose wheel strut to verify correct psi) and main tires should be 55 psi. All wheels and tires are balanced before original installation, and the relationship of tire, tube, and wheel should be maintained upon reinstallation. Unbalanced wheels can cause extreme vibration in the landing gear; therefore, in the installation of new components, it may be necessary to rebalance the wheels with the tires mounted. When checking tire pressure, examine the tires for wear, cuts, bruises, and slippage.

8.27 BATTERY SERVICE

Access to the 24-volt battery is through the battery access panel located on the aft right side of the engine compartment. Remove the access panel by removing the screws securing the panel to the fuselage. Release the retainers (one on each side near the bottom of the battery) by loosening the top screw on each retainer enough to pivot the retainer out of the way and allow the battery to be pulled out.

The battery is maintenance free and requires no maintenance of the liquid level and recombines the gases formed on charge within the battery to reform water. The battery may be used in any attitude without danger of leakage or spilling of electrolyte.

Inspect the battery for general condition (at least every 30 days). If evidence of leakage is present, the battery must be replaced.

8.29 EMERGENCY OXYGEN SYSTEM

The emergency oxygen system must be serviced if used. The canister generators must be replaced with new units to restore the emergency system to a useable condition. The pilot's quick-donning oxygen mask system also must be serviced if used or if it shows indications of low pressure. Refer to the PA-46-500TP Maintenance Manual for oxygen system maintenance and inspection requirements.

8.31 PRESSURIZATION SYSTEM

The system should be given an operational check before each flight. Should the operational check show any malfunction of the pressurization system, refer to the PA-46-500TP Maintenance Manual.

THIS PAGE INTENTIONALLY LEFT BLANK



8.33 LUBRICATION

For lubricating instructions, a chart showing lubrication points and types of lubricants to be used, and lubrication methods, refer to the PA-46-500TP Maintenance Manual.

8.35 CLEANING

(a) Cleaning Engine Compartment

- (1) Place a large pan under the engine to catch waste.
- (2) See engine maintenance manual for engine external cleaning requirements.
- (3) Lubricate the controls, bearing surfaces, etc., in accordance with the Lubrication Chart in the PA-46-500TP Maintenance Manual.
- (4) Assure that all engine exhaust deposits and stains are removed frequently from bottom of aircraft around exhaust outlets. *Accumulation of exhaust deposits left even over short periods of time will cause corrosion.*

8.35 CLEANING (Continued)**(b) Cleaning Landing Gear**

Before cleaning the landing gear, place a plastic cover or similar material over the wheel and brake assembly.

CAUTION

Do not brush the micro switches.

- (1) Place a pan under the gear to catch waste.
- (2) Spray or brush the gear area with solvent or a mixture of solvent and degreaser, as desired. Where heavy grease and dirt deposits have collected, it may be necessary to brush areas that were sprayed, in order to clean them.
- (3) Allow the solvent to remain on the gear from five to ten minutes. Then rinse the gear with additional solvent and allow to dry.
- (4) Remove the cover from the wheel and remove the catch pan.
- (5) Lubricate the gear in accordance with the Lubrication Chart.

(c) Cleaning Exterior Surfaces

The airplane should be washed with a mild soap and water. Harsh abrasives or alkaline soaps or detergents could make scratches on painted or plastic surfaces or could cause corrosion of metal. Cover areas where cleaning solutions could cause damage. To wash the airplane, use the following procedure:

CAUTION

Do not direct any stream of water or cleaning solutions at the openings in the pitot head, static ports, alternate static ports or fuselage belly drains.

- (1) Flush away loose dirt with water.
- (2) Apply cleaning solution with a soft cloth, a sponge or a soft bristle brush.
- (3) To remove exhaust stains, allow the solution to remain on the surface longer.
- (4) To remove stubborn oil and grease, use a cloth dampened with naphtha.
- (5) Rinse all surfaces thoroughly.
- (6) Any good automotive wax may be used to preserve painted surfaces. Soft cleaning cloths or a chamois should be used to prevent scratches when cleaning or polishing. A heavier coating of wax on the leading surfaces will reduce the abrasion problems in these areas.

8.35 CLEANING (Continued)

(d) Cleaning Windshield and Windows

CAUTION

Use only mild soap and water when cleaning the heated windshield. Use of ANY other cleaning agent or material may cause distortion or damage to windshield coatings.

- (1) Remove dirt, mud and other loose particles from exterior surfaces with clean water.
- (2) Wash with mild soap and warm water or with aircraft plastic cleaner. Use a soft cloth or sponge in a straight back and forth motion. Do not rub harshly.
- (3) Remove oil and grease with a cloth moistened with kerosene.

CAUTION

Do not use gasoline, alcohol, benzene, carbon tetrachloride, thinner, acetone, or window cleaning sprays.

- (4) After cleaning plastic surfaces, apply a thin coat of hard polishing wax. Rub lightly with a soft cloth. Do not use a circular motion.
- (5) A minor scratch or mar in plastic can be removed by rubbing out the scratch with jeweler's rouge. Smooth both sides and apply wax. Deep scratches may lead to failure when pressurized.
- (6) If a deep scratch or crack is found in any of the windshields or windows, do not pressurize cabin until serviced at authorized repair station.

(e) Cleaning Headliner, Side Panels and Seats

- (1) For normal soiling and smudges, simply use the dry cleaning pad provided. This pad contains an exclusive grit-free powder with unusual power to absorb dirt.

Squeeze and twist the pad so the powder sifts through the meshes and adheres to the cloth. Then rub the soiled part in any direction, as hard as necessary to clean.

Even though the pad eventually becomes soiled, this soil will not transfer back to the headliner.

8.35 CLEANING (Continued)

- (2) For simple stains (e.g. coffee, cola) clean headliner with a sponge and a common household suds detergent (e.g. Tide). Dirty grease stains should be first spot cleaned with a lighter fluid containing Naphtha to remove the solvent soluble matter. Any stain residue should then be shampooed with a household upholstery cleaner (e.g. Carbona upholstery and rug shampoo).

With proper care, your Meridian headliner will provide years of excellent appearance and durability.

CAUTION

Solvent cleaners require adequate ventilation.

- (3) Leather should be cleaned with saddle soap or a mild hand soap and water.

(f) Cleaning Carpets

To clean carpets, first remove loose dirt with a whisk broom or vacuum. For soiled spots and stubborn stains use a nonflammable dry cleaning fluid. Floor carpets may be cleaned like any household carpet.

(g) Cleaning Oxygen Equipment

- (1) Clean the mask assemblies with a suitable oil-free disinfectant.
- (2) Wipe dirt and foreign particles from the unit with a clean, dry, lint-free cloth.

(h) Cleaning Surface Deicing Equipment

The deicers should be cleaned when the aircraft is washed using a mild soap and water solution.

In cold weather, wash the boots with the airplane inside a warm hangar if possible. If the cleaning is to be done outdoors, heat the soap and water solution before taking it out to the

8.35 CLEANING (Continued)

airplane. If difficulty is encountered with the water freezing on boots, direct a blast of warm air along the region being cleaned using a portable ground heater.

Petroleum products are injurious to rubber and their use as cleaning agents should be avoided. Limited use of Mineral Spirits or non-leaded (NOT LOW LEAD) gasoline is not harmful in cleaning the deicers, if the cloth is dampened (not dripping) with solvent, and a dry cloth is used to wipe the deicer before the solvent has time to soak into the rubber.

With the deicer boots properly cleaned, a coating of Agemaster No. 1 should be applied to the boots, as described in the PA-46-500TP Maintenance Manual. This treatment helps protect the neoprene deice boots from ozone attack, aging and weathering.

IceX may be applied to all of the boots if icing conditions are anticipated. Any boots treated with Agemaster should be allowed to dry before application of IceX. For specific instructions refer to the PA-46-500TP Maintenance Manual.

8.36 CLEANING AND MAINTENANCE OF RELIEF TUBE SYSTEM

When the aircraft is equipped with a relief tube system, the corrosive effects of urine or other liquids poured through the system are extreme and require much attention to the cleanliness of this system both inside and outside of the aircraft. From the interior standpoint, the funnel tube assembly, rubber hose and surrounding sheet metal should be cleaned at termination of flight when the system has been used. Likewise, attention to the exterior of the aircraft is equally as important and must be cleaned as described below.

NOTE

The corrosive affects of urine on painted and unpainted surfaces cannot be understated. Corrosion may appear in surrounding areas if allowed to go uncleaned for one day.

(a) Interior

After each use of the relief tube, the area surrounding the relief tube should be examined for spillage and cleaned according to the cleaning procedures listed in paragraphs 8.35(e) and (f) above. Clean area inside the box and access door, funnel and tube using mild soap and water. After cleaning, assure that no soapy residue remains by flushing with clean water. Dry system thoroughly.

CAUTION

Should spillage extending into the fuselage be evident, maintenance actions must occur which include removing panels to access the floor structure to neutralize urine spillage in the aircraft structure.

Prepare to flush the relief tube assembly by placing a container underneath the relief tube outlet. Flush tube by pouring a solution of baking soda (10%) and water through the tube, flushing out the entire system. Flush again with at least 1/2 gallon of clear water. (Shop air, at low pressure, may be blown through the relief tube system to dry the system.)

8.36 CLEANING AND MAINTENANCE OF RELIEF TUBE SYSTEM (Continued)

(b) Exterior

Exterior bottom painted surfaces of the aircraft must be cleaned from the firewall to the tip of the tail including the bottom of the tail surfaces, at termination of each flight when the relief tube system has been used. Cleaning should occur in accordance with paragraph 8.35(c) with the following exception: After completion of washing, a solution of baking soda (10%) and water should be applied to the entire area and allowed to remain for a few minutes. The area then must be thoroughly rinsed with clean water. The area should be thoroughly dried and observed for paint chips and corrosion, with touch up as necessary.

8.37 CLEANING GARMIN PFD AND MFD DISPLAYS

The Garmin Primary Flight Display (PFD) and Multi-Function Display (MFD) use a lens coated with a special anti-reflective coating that is very sensitive to skin oils, waxes and abrasive cleaners.

CAUTION

Cleaners containing ammonia will harm the anti-reflective coating. It is very important to clean the display lenses using a clean, lint-free cloth and an eyeglass lens cleaner that is specified as safe for anti-reflective coatings.

8.38 CLEANING AND MAINTENANCE OF THE PT6A COMPRESSOR AND COMPRESSOR TURBINE

Cleaning of the compressor and turbine sections is required to enhance the durability of the engine by reducing the onset of sulphidation attacks on the turbine blades and preventing salt deposits from damaging the compressor section. Reference Piper Service Letter No. 1110 dated March 28, 2008 for additional maintenance information pertaining to the importance of conducting compressor and turbine blade washes.

Sulphidation occurs at engine operating temperatures with sodium and sulphur present. Most aviation turbine fuels contain sulphur in sufficient amounts for sulphidation to occur. Common sources of sodium are seawater, atmospheric pollutants and volcanic discharges. Initially, sulphidation attacks the oxide protective coating of the turbine blade and, as the oxidation accelerates, blister scale begins to form. The important point to remember is that sulphidation is a hot-corrosion phenomenon and therefore turbine blades are most susceptible to it.

Compressor blades are also affected by salt deposits; however, the corrosion mode does not require high temperatures. Extended exposure to wet deposits of salt can lead to rust and pitting which affect aerodynamic efficiency and fatigue life. If not addressed, corrosion will progress to the point where compressor components will need to be replaced.

Magnesium components such as the compressor inlet case and the reduction gearbox housing are also susceptible to corrosion should the protective epoxy paint become chipped, scratched or eroded.

CAUTION

If a turbine wash is to be performed in conjunction with a compressor wash, ensure that the compressor is washed first.

- (a) Perform compressor and turbine wash in accordance with Engine Maintenance Manual (EMM) section 71-00-00.
- (b) Recommended wash schedule is found in the EMM Table "Wash Schedule Recommendation".




THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS

SECTION 9

SUPPLEMENTS

Paragraph/Supplement No.		Page No.
9.1	General	9-1
1	Meridian Aircraft Flight Into Known Icing (FIKI)	9-3
2	Bendix/King KR-87 Digital ADF with Garmin PFD Indicator	9-37
3	Bendix/King KN-63 DME	9-47
4	WX-500 Stormscope - Optional	9-51
5	Garmin G1000 Avionics System - Synthetic Vision and Pathways	9-57




THIS PAGE INTENTIONALLY LEFT BLANK

SECTION 9
SUPPLEMENTS

9.1 GENERAL

This section provides information in the form of supplements which are necessary for efficient operation of the airplane when it is equipped with one or more of the various optional systems and equipment not approved with the standard airplane.

All of the supplements provided in this section are FAA Approved and consecutively numbered as a permanent part of this handbook. The information contained in each supplement applies only when the related equipment is installed in the airplane.



THIS PAGE INTENTIONALLY LEFT BLANK

**PILOT'S OPERATING HANDBOOK
AND
FAA APPROVED AIRPLANE FLIGHT MANUAL**

**SUPPLEMENT NO. 1
FOR
MERIDIAN AIRCRAFT
FLIGHT INTO KNOWN ICING (FIKI)**

This supplement must be attached to the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual when operating the Piper PA-46-500TP Meridian airplane into known icing conditions. The information contained in this document supplements or supersedes the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual only in those areas listed herein. For limitations, procedures, performance and loading information not contained in this supplement, consult the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual.

FAA APPROVED:



**ALBERT J. MILL
DOA-510620-CE
PIPER AIRCRAFT, INC.
VERO BEACH, FLORIDA**

DATE OF APPROVAL: November 12, 2008

SECTION 1 - GENERAL

This supplement provides information necessary for the operation of the Piper Meridian aircraft for flight into known icing conditions.

Icing conditions can exist when:

- The outside air temperature (OAT) is 5°C or colder, and visible moisture in any form such as clouds, fog or mist, rain, snow, sleet and ice crystals are present.
- During ground operations when operating on contaminated ramps, taxiways or runways where surface snow, ice, standing water or slush are present.
- There are visible signs of ice accretion on the aircraft.

The Meridian ice protection system was designed and tested for operation in light to moderate meteorological conditions defined in FAR 25, Appendix C, for continuous maximum and intermittent maximum icing conditions. The ice protection system was not designed or tested for flight in freezing rain, freezing drizzle or supercooled liquid water and ice crystals, or conditions defined as severe. Flight in these conditions is prohibited and must be avoided.

The ice protection system was not designed to remove ice, snow or frost accumulations from a parked airplane. Ice, snow or frost must be completely removed during preflight to ensure a safe takeoff and subsequent flight. Procedures for ice, snow or frost removal, such as a heated hangar and/or approved deicing fluids, must be used to ensure that **ALL** ice, snow, or frost is **COMPLETELY** removed from the wings, tail, control surfaces, windshield, propeller, engine intakes, fuel vents and pitot-static ports, prior to flight.

Some icing conditions not defined in FAR Part 25, Appendix C have the potential of producing hazardous ice accumulations, which may exceed the capabilities of the airplane's ice protection equipment. See section titled Visual Cues for Supercooled Large Droplet (SLD) Conditions in this supplement.

Flight into icing conditions which are outside the FAR defined conditions is prohibited, and pilots are advised to be prepared to divert the flight promptly, by changing course or altitude, if hazardous ice accumulations occur.

SECTION 1 - GENERAL (continued)**VISUAL CUES FOR SUPERCOOLED LARGE DROPLETS (SLD) CONDITIONS**

Should supercooled large droplets (SLD) be present, most aircraft with unpowered controls and pneumatic boots should request a route or altitude change to exit the conditions.

The cues listed as follows are indicative of SLD conditions:

- Ice may become visible on the upper or lower surface of the wing, aft of the active part of the deicing boots. Pilots should look for irregular or jagged lines of ice or for pieces of ice shedding off the airplane. During night operations, adequate illumination should be used to observe all areas.
- The aft limit of ice accumulation on a propeller spinner that is not heated will reveal ice extending beyond normal limits.
- Unheated portions of side windows may begin to accumulate granular dispersed ice crystals or a translucent or opaque coating over the entire window. This icing may be accompanied by other ice patterns on the windows, such as ridges. These patterns may occur from within a few seconds to half a minute after exposure to SLD conditions.
- Ice coverage may become unusually extensive, with visible ice fingers or feathers on parts of the airframe that normally would not be covered by ice.
- The aircraft's performance may degrade. Pilots should remain vigilant when icing conditions are present, and any alteration of the aircraft's performance should be monitored closely as a sign of icing on the airplane.

SECTION 1 - GENERAL (continued)**ICING DEFINITIONS**

Residual Ice - Ice that remains attached to the de-ice boot at the conclusion of that boot inflation cycle.

Intercycle Ice - The quantity of ice that accumulates on the wing horizontal stabilizer and vertical tail de-ice boots between de-ice boot cycles.

Failure Ice - The quantity of ice accumulated on the wing horizontal stabilizer and vertical tail de-ice boots if the pneumatic surface de-ice system fails.

Light Icing - The rate of accumulation may create a problem if flight is prolonged in this environment. Occasional use of de-icing/anti-icing equipment removes/prevents accumulation.

Moderate Icing - The rate of accumulation is such that even short encounters become potentially hazardous and use of de-icing/anti-icing equipment or flight diversion is necessary.

Severe Icing - The rate of accumulation is such that de-icing/anti-icing equipment fails to reduce or control the hazard. Immediate flight diversion is necessary.

Rime Ice - A rough, milky, opaque ice formed by the instantaneous freezing of small, supercooled water droplets.

Mixed Ice - Simultaneous appearance of rime and clear ice or an ice formation that has the characteristics of both rime and clear ice.

Clear Ice - A glossy, clear, or translucent ice formed by the relatively slow freezing of large supercooled water droplets. The terms "clear" and "glaze" have been used for essentially the same type of ice accretion, although some reserve "clear" for thinner accretions which lack horns and conform to the airfoil.

SECTION 2 - LIMITATIONS**REQUIRED EQUIPMENT**

The Piper Meridian airplane is approved for flight into light to moderate icing conditions as defined by FAR Part 25, Appendix C, only if the following required ice protection systems and equipment are installed and functioning properly.

1. Surface De-ice System
2. Propeller Anti-ice System
3. Windshield Heat Anti-ice System
4. Pitot Heat Anti-ice System
5. Stall Heat Anti-ice System
6. Wing Inspection Light (Ice Light)

NOTE

The Generator and Alternator must be installed and functioning properly for flight into known icing conditions.

ENVIRONMENTAL CONDITIONS

Inadvertent operation in freezing rain, freezing drizzle, or conditions defined as severe may be detected by heavy ice accumulation on the airframe and windshield, ice accumulation in areas not normally observed to collect ice, or when ice forms on the upper surface of the wing, aft of the surface de-ice boot. If these conditions are encountered, the pilot should take immediate action to exit these conditions by changing altitude or course.

Takeoff is prohibited with the following forms of contamination:

With frost adhering to the following areas:

1. Wing leading edge
2. Wing upper surface
3. Windshield

With ice, snow or slush adhering to the following areas:

1. Wing leading edge and upper wing surface
2. Flight control surfaces
3. Top of fuselage
4. Windshield
5. All static ports
6. Upper surface of engine cowling forward of windshield

**SECTION 2 - LIMITATIONS (continued)****ENVIRONMENTAL CONDITIONS (continued)**

A visual and tactile (hand on surface) check of the wing leading edge and wing upper surface must be performed to ensure the wing is free from frost, ice, snow, or slush when the outside air temperature is less than 10°C (50°F) or if it cannot be determined, wing fuel temperature is above 0°C (32°F) and

1. there is visible moisture present (rain, drizzle, sleet, snow, fog, etc.); or
2. water is present on the wing upper surface; or
3. the difference between the dew point and the outside temperature is 3°C (5°F) or less; or
4. the atmospheric conditions have been conducive to frost formation.

MINIMUM SPEED IN ICING CONDITIONS

Minimum speed during flight in icing conditions with the flaps up is 130 KIAS.

FLAP SETTINGS FOR OPERATION IN ICING CONDITIONS

Flaps must be up when holding in icing conditions. Maximum flap extension with ANY ice accumulation on the airframe is limited to 20°.

MINIMUM TORQUE REQUIRED FOR PROPER SURFACE DE-ICE SYSTEM OPERATION

During flight, engine torque must be maintained at the following settings to assure proper surface de-ice system operation.

- Above 25,000 feet - engine torque must be 350 ft. lb. or greater
- At or below 25,000 feet - engine torque must be 250 ft. lb. or greater

WINDSHIELD HEAT

Ground operation with windshield heat selected to ANTI ICE or DEFOG is limited to 20 seconds duration.

MAGNETIC COMPASS

Accuracy of the magnetic compass may be unreliable with the combination of air conditioner, windshield heat, prop heat and stall heat on.

SECTION 2 - LIMITATIONS (continued)**AUTOPILOT**

Autopilot operation during icing conditions may mask cues that indicate adverse changes in aircraft handling characteristics. Autopilot operation is prohibited if any of the following conditions in icing flight are experienced:

- Severe icing conditions (reference SECTION 1 - GENERAL).
- Elevator bridging is encountered.
- Frequent autopilot trim wheel movement during straight and level flight.
- Conditions developed which cause pitch, roll or yaw servo to provide a sustained force as indicated by ELE, AIL or RUD alert annunciations in the AFCS system status field on the PFD and/or pilot qualitative evaluations.

NOTE

The autopilot must be disconnected periodically to evaluate the above mentioned conditions.

CAUTION

During flight in icing conditions, ice will form on the unprotected leading edge of the elevator, and possibly form a bridge of ice, or ice cap, between the stabilizer and the elevator. This condition may be detected and verified by visual observation, by increased elevator pitch control forces, or frequent autopilot trim annunciations during straight and level flight. If ice bridging is detected or suspected, disconnect the autopilot and pulse the aircraft elevator pitch control to dislodge the ice bridge. Elapsed time between conducting elevator checks will vary, depending upon the amount and type of ice accretion. Usually 8 to 10 minutes between elevator pulsing cycles is considered sufficient.

SECTION 2 - LIMITATIONS (continued)**SURFACE DE-ICE SYSTEM**

Operation of the surface de-ice system is prohibited in temperatures below -40°C. Such operation may result in damage to the surface de-ice boots.

OAT PROBES

At the highest Mach number shown in the performance charts of this POH and with a fully iced over OAT probe, which assumes the measured total temperature equals static temperature, the maximum indicated temperature error calculated is 7°C less than actual.

PLACARDS

On the pilot's left side panel:

THIS AIRCRAFT MUST BE OPERATED AS A NORMAL
CATEGORY AIRPLANE IN COMPLIANCE WITH THE
OPERATING LIMITATIONS STATED IN THE FORM OF
PLACARDS, MARKINGS AND MANUALS. NO ACROBATIC
MANEUVERS (INCLUDING SPINS) APPROVED. THIS
AIRCRAFT APPROVED FOR V.F.R., I.F.R., DAY
AND NIGHT ICING FLIGHT WHEN EQUIPPED IN
ACCORDANCE WITH THE AIRPLANE FLIGHT MANUAL.

WARNING

TURN OFF STROBE LIGHTS WHEN IN CLOSE
PROXIMITY TO GROUND OR DURING FLIGHT
THROUGH CLOUD, FOG OR HAZE.

PRESSURIZED LANDING NOT APPROVED.

SECTION 3 - EMERGENCY PROCEDURES**ICE PROTECTION SYSTEM ANNUNCIATORS****NOTE**

During high ambient temperature conditions when switching windshield heat from ANTI ICE to DEFOG, the red WNDSHLD OVRTEMP annunciator may illuminate and remain illuminated until the windshield surface temperature cools to the DEFOG heat temperature range.

NOTE

For a complete list of items that are required to be operational for flight in icing conditions, see Kinds of Operation Equipment List in Section 2.

Warning Messages - Red - Repeating Aural Chime

L PITOT HT FAIL	Both left and right pitot heat have failed.
R PITOT HT FAIL	Both left and right pitot heat have failed.
PROP HEAT FAIL	A fault has developed in the propeller heat system in flight.
SURF DE-ICE FAIL	Surface de-ice system has failed in flight.
WNDSHLD OVRTEMP	Windshield temperature exceeds 170°F or the windshield temperature sensor has failed.

Caution Messages - Amber - Single Aural Chime

L PITOT HT FAIL	Left pitot heat has failed.
R PITOT HT FAIL	Right pitot heat has failed.
PITOT HEAT OFF	Pitot heat has not been selected ON (no chime accompanies this CAS message).
PROP HEAT FAIL	A fault has developed in the propeller heat system while the aircraft is on the ground.
STALL WARN FAIL	The lift computer and/or lift transducer has failed.
SURF DE-ICE FAIL	Surface de-ice system has failed while the aircraft is on the ground.
VACUUM LOW	Vacuum is below approximately 2.0 inches of mercury.

SECTION 3 - EMERGENCY PROCEDURES (continued)**ICE PROTECTION SYSTEM ANNUNCIATORS (continued)****Left Pitot Heat Failure**

Indication: Master Caution Indication; Amber L PITOT HT FAIL message; Single aural chime.

NOTE

Failure of the L Pitot Heat could cause erroneous indications of pilot's airspeed and standby airspeed. Airspeeds on each PFD should be compared for accuracy.

L PITOT HEAT Circuit BreakerRESET
(Located on the pilot's aft circuit breaker panel, row A, position 2.)

If IAS MISCOMPARE
annunciation illuminatedSELECT GOOD ADC

Right Pitot Heat Failure

Indication: Master Caution Indication; Amber R PITOT HT FAIL message; Single aural chime.

NOTE

Failure of the R Pitot Heat could cause erroneous indications of copilot's airspeed. Airspeeds on each PFD should be compared for accuracy.

R PITOT HEAT Circuit BreakerRESET
(Located on the pilot's aft circuit breaker panel, row A, position 3.)

If IAS MISCOMPARE
annunciation illuminatedSELECT GOOD ADC

SECTION 3 - EMERGENCY PROCEDURES (continued)**ICE PROTECTION SYSTEM ANNUNCIATORS (continued)****Both Left and Right Pitot Heat Failure**

Indication: Master Warning Indication; Red L PITOT HT FAIL and red R PITOT HT FAIL messages; Repeating aural chime.

NOTE

Failure of both left and right pitot heaters could cause erroneous pilot, copilot and/or standby airspeed indications. Exit and avoid icing conditions and monitor pilot and copilot airspeeds. In the event of complete loss of airspeed, maintain safe airspeed by use of throttle, engine settings and airframe sensory cues.

L PITOT HEAT Circuit BreakerRESET
(Located on the pilot's aft circuit breaker panel, row A, position 2.)

R PITOT HEAT Circuit BreakerRESET
(Located on the pilot's aft circuit breaker panel, row A, position 3.)

If either circuit breaker opens again, do not reset.

Pitot Heat Off

Indication: Master Caution Indication; Amber PITOT HEAT OFF message; Single aural chime.

PITOT HEAT Switch.....Select ON

Prop Heat Failure**In Flight:**

Indication: Master Warning Indication; Red PROP HEAT FAIL message; Repeating aural chime.

PROP HEAT Circuit BreakerCHECK IN
(Located on the pilot's aft circuit breaker panel, row A, position 4.)

If PROP HEAT Circuit Breaker was closed (not out):

PROP HEAT SwitchCycle OFF then ON

If Annunciator remains illuminated, Exit and Avoid icing conditions.

On Ground:

Indication: Amber Caution Indication; Amber PROP HEAT FAIL message; Single aural chime.

Flight in icing conditions is prohibited.

SECTION 3 - EMERGENCY PROCEDURES (continued)**ICE PROTECTION SYSTEM ANNUNCIATORS (continued)****Windshield Over Temp**

Indication: Master Warning Indication; Red WNDSHLD OVRTEMP message; Repeating aural chime.

WINDSHLD HT Switch.....OFF

If Windshield Over Temp Annunciator extinguishes:

WINDSHLD HT Switch.....DEFOG

If Windshield Over Temp Annunciator remains illuminated:

WINDSHLD HT Switch.....OFF

WINDSHIELD HEAT Circuit Breakers (2)PULL
(Located on the pilot's aft circuit breaker panel, row A, positions 7, 8.)

NOTE

During high ambient temperature conditions when switching windshield heat from ANTI ICE to DEFOG, the red WNDSHLD OVRTEMP message may illuminate and remain illuminated until the windshield surface temperature cools to the DEFOG heat temperature range.

Surface De-ice Failure**In Flight:**

Indication: Master Warning Indication; Red SURF DE-ICE FAIL message; Repeating aural chime.

SURFACE DE-ICE Circuit BreakerRESET
(Located on the pilot's aft circuit breaker panel, row A, position 6.)

If message remains illuminated, Exit and Avoid icing conditions.

On Ground:

Indication: Master Caution Indication; Amber SURF DE-ICE FAIL message; Single aural chime.

Flight in icing conditions is prohibited.

SECTION 3 - EMERGENCY PROCEDURES (continued)

ICE PROTECTION SYSTEM ANNUNCIATORS (continued)

Stall Warning Fail

Indication: Master Caution Indication; Amber STALL WARN FAIL message; Single aural chime.

STALL WARN Circuit BreakerRESET
 (Located on the pilot's forward circuit breaker panel, row C, position 5.)

Avoid low airspeeds and monitor approach speeds closely.

Vacuum System Failure

Indication: Master Caution Indication; Amber VACUUM LOW message; Single aural chime; Amber vacuum indication.

Vacuum gaugeCHECK - WITHIN NORMAL OPERATING RANGE

Monitor vacuum gauge. Low vacuum may lead to improper operation of the wing and empennage deice boots and malfunction of the cabin pressurization. Monitor cabin altitude.

Before landing, verify cabin is depressurized. If not depressurized:

ECS CABIN COMFORT SwitchOFF
 BLEED AIR LeverPULL OUT (closed)
 PressurizationVERIFY ZERO DIFFERENTIAL PRESSURE

CAUTION

If de-ice boots are not fully deflated, stall speeds will be increased by approximately 5 KIAS.

Landing Without Flaps

Proceed as for normal approach. Landing distance may be calculated by increasing the flap 20° landing distance by 16%. Landing ground roll may be calculated by increasing the flap 20° landing ground roll by 13%.

Landing GearDOWN, 3 GREEN
 Final Approach Speed110 KIAS
 LandingNORMAL
 BrakingAS REQUIRED
 ReverseAS REQUIRED

SECTION 4 - NORMAL PROCEDURES

The Piper PA-46-500TP is approved for flight into known icing conditions as defined in Section 1, GENERAL. Operating in icing conditions of Continuous Maximum and Intermittent Maximum as defined in FAR 25, Appendix C has been substantiated; however, there is no correlation between these conditions and forecasts of reported "Light, Moderate and Severe" conditions. **Flight into severe icing is not approved.**

Icing conditions can exist in any clouds when the temperature is below freezing; therefore it is necessary to closely monitor outside air temperature when flying in clouds or precipitation. Clouds which are dark and have sharply defined edges usually have high water content and should be avoided whenever possible. **Freezing rain and freezing drizzle must always be avoided.**

Pneumatic boots must be cleaned regularly for proper operation in icing. The exterior surfaces of the aircraft should be checked prior to flight. **Do not attempt flight with frost, ice or snow adhering to the exterior surfaces of the aircraft or landing gear.**

Prior to dispatch into forecast icing conditions all ice protection equipment must be functionally checked for proper operation.


SECTION 4 - NORMAL PROCEDURES (continued)**ENGINE RUNUP**

1. WINDSHLD HT SwitchSelect ANTI ICE position,
Verify increased amps/
Select DEFOG position,
Verify increased amps
2. WINDSHLD HT Switch.....OFF

CAUTION

To avoid possible windshield distortion or overheat during ground operations or during testing, DO NOT position the WINDSHLD HT switch to ANTI ICE or DEFOG for more than 20 seconds

3. PITOT HEAT.....Select ON -
Verify increased amps and
amber PITOT HEAT OFF
annunciator extinguished
4. PITOT HEATOFF
5. PROP HEATSelect ON -
Verify increased amps for
approximately 1-minute and
no PROP HEAT FAIL caution
message
6. PROP HEATOFF
7. STALL HEATActivate switch and verify
increased amps.
8. STALL HEATOFF



SECTION 4 - NORMAL PROCEDURES (continued)

ENGINE RUNUP (continued)

9. SURFACE DE-ICE.....CHECK
- a) POWER LEVER - Increase to 250 ft. lb. torque
 - b) SURF DE-ICE Switch - Select ON (Verify green light in SURF DE-ICE switch illuminated and no SURF DE-ICE FAIL or VACUUM LOW caution messages during each de-ice boot inflation cycle. Visually verify wings and horizontal stabilizer de-ice boot inflation and deflation.)
 - c) POWER LEVER - IDLE
 - d) SURF DE-ICE Switch - OFF

SECTION 4 - NORMAL PROCEDURES (continued)**FLIGHT INTO KNOWN ICING CONDITIONS**

The Piper Meridian is approved for flight into known icing conditions as defined in SECTION 1, GENERAL.

WARNING

Flight in icing conditions is prohibited if there is known failure of any of the ice protection systems or if the generator or alternator are failed or are inoperative.

WARNING

Maximum flap extension with ANY ice accumulation on the airframe is limited to 20°.

NOTE

Flight in known icing conditions is approved only if the required ice protection systems and equipment are installed and functioning properly. They are:

SURFACE DE-ICE SYSTEM
PROPELLER HEAT ANTI-ICE SYSTEM
WINDSHIELD HEAT ANTI-ICE SYSTEM
PITOT HEAT ANTI-ICE SYSTEM
STALL HEAT ANTI-ICE SYSTEM
WING INSPECTION LIGHT (ICE LIGHT)

NOTE

Prolonged operation of the stall warning vane heater in temperatures greater than 5°C will reduce the operational life of the stall warning vane.



SECTION 4 - NORMAL PROCEDURES (continued)

FLIGHT INTO KNOWN ICING CONDITIONS (continued)

PRIOR to entering icing conditions, the following ice protection systems **MUST** be activated.

1. SURF DE-ICESELECT ON
2. STALL HEATSELECT ON
3. PITOT HEATVERIFY ON
4. PROP HEATSELECT ON
5. WINDSHLD HTSELECT ANTI ICE
6. Wing Inspection Light (ICE LIGHT)AS REQUIRED
7. IGNITIONMAN
8. Windshield Defog (DEFROST)PULL ON
9. ECS CABIN COMFORTHIGH

During Icing Conditions:

10. Wing Leading Edge.....MONITOR for continual shedding of ice
11. Annunciator Panel.....MONITOR for correct function of ice protection systems (no system failures)

WARNING

If any of the aircraft ice protection systems fail during flight in icing conditions, exit and avoid icing conditions.

SECTION 4 - NORMAL PROCEDURES (continued)

FLIGHT INTO KNOWN ICING CONDITIONS (continued)

After departure from icing conditions with remaining residual and intercycle airframe ice:

- 1. SURF DE-ICEMAINTAIN ON
- 2. STALL HEATMAINTAIN ON
- 3. PROP HEATMAINTAIN ON
- 4. PITOT HEATMAINTAIN ON
- 5. WINDSHLD HTDE-FOG or ANTI ICE as required
- 6. IGNITIONAUTO
- 7. FlapsDO NOT EXTEND BEYOND 20°

After removal of residual and intercycle airframe ice:

- 1. SURF DE-ICEOFF
- 2. STALL HEATOFF
- 3. PROP HEAT.....OFF
- 4. PITOT HEATMAINTAIN ON
- 5. WINDSHLD HTDE-FOG or ANTI ICE as required



SECTION 4 - NORMAL PROCEDURES (continued)

BEFORE LANDING

APPROACH CHECK

Altimeter and Standby AltimeterSET
 PressurizationSET
 Fuel PumpMAN
 IgnitionMAN
 Fuel QuantityCHECK
 SeatsADJUSTED & LOCKED IN POSITION
 ArmrestsSTOWED
 Belts/HarnessFASTENED & ADJUSTED
 Landing GearDOWN (below 168 KIAS)
 FlapsSET (10° @ 168 KIAS max.)

LANDING CHECK

Landing Gear3 GREEN LIGHTS
 BrakesCHECK
 FlapsSET (20° @ 135 KIAS max.)
 Airspeed100 KIAS

NOTE

Landing distance performance was established by maintaining a power on (370 ft. lb. torque), stabilized 3° approach at 100 KIAS, and reducing power to idle during the flare.

AutopilotDISENGAGE
 Yaw Damper (prior to landing)DISENGAGE

BALKED LANDING (Go-Around)

Power LeverSET TAKEOFF TORQUE
 Climb Airspeed100 KIAS
 After climb established:
 Climb AirspeedACCELERATE TO 110 KIAS
 FlapsRETRACT TO 0°
 Landing GearRETRACT
 AirspeedACCELERATE TO 125 KIAS (Vy)

AFTER LANDING

FUEL PUMPS Switch.....	AUTO
IGNITION Switch	OFF
PITOT HEAT Switch	OFF
Additional Ice Protection Equipment	OFF
Landing /Taxi Lights	AS REQUIRED
Strobe Light	AS REQUIRED
WX Radar	STBY
Flaps	RETRACT
Transponder	AS REQUIRED

SECTION 5 - PERFORMANCE

The performance charts in this supplement are based on an airplane with ice on the unprotected surfaces that would have accumulated during a 45 minute hold in icing conditions, in addition to, intercycle ice on the de-ice boots while they are operating in the 60 second cycle mode. It is assumed that the flaps and landing gear are retracted while executing the 45 minute hold. Intercycle ice is the ice on the de-ice boots just prior to de-ice boot inflation.


Be sure to review flap extension and airspeed limitations in SECTION 2, LIMITATIONS and de-ice equipment operation in SECTION 4, NORMAL PROCEDURES of this supplement when ice is on the airframe.



SECTION 5 - PERFORMANCE (continued)

EXAMPLE	
OAT:	-5°C
Press. Altitude:	3,500 FT.
Weight:	4,500 LB.
Rate of Climb:	1,204 FPM

ASSOCIATED CONDITIONS	
Power:	MAXIMUM CONTINUOUS
ECS:	NORMAL
Airframe Ice:	45 MIN HOLD
Gear:	EXTENDED
Flaps:	20°
Climb speed:	100 KIAS



Balked Landing Climb Performance
Figure 1


SECTION 5 - PERFORMANCE (continued)

EXAMPLE

OAT: -5°C
 Press. Altitude: 3,500 FT.
 Weight: 2,041 KG
 Rate of Climb: 1,204 FPM

ASSOCIATED CONDITIONS

Power: MAXIMUM CONTINUOUS
 ECS: NORMAL
 Airframe ice: 45 MIN HOLD
 Gear: EXTENDED
 Flaps: 20°
 Climb speed: 100 KIAS



Balked Landing Climb Performance (Metric)

Figure 2




SECTION 5 - PERFORMANCE (continued)

EXAMPLE

OAT: -5 C°
 Pressure Altitude: 3,500 FT.
 Rwy Gradient: 1% UP
 Headwind Component: 5 KT.
 Ground Roll Distance: 1,356 FT.

ASSOCIATED CONDITIONS


Runway: PAVED, LEVEL, DRY SURFACE
 Weight: 4,850 LB.
 Airframe Ice: 45 MIN HOLD
 Flaps: 20°
 Touch Down Speed: 92 KIAS
 Braking: MODERATE WITH BETA




Landing Ground Roll, Flaps 20°, without Reverse

Figure 3

SECTION 5 - PERFORMANCE (continued)




Landing Ground Roll, Flaps 20°, without Reverse (Metric)
Figure 4



SECTION 5 - PERFORMANCE (continued)

EXAMPLE	
OAT:	-5 °C
Runway Gradient:	1% UP
Pressure Altitude:	3,500 FT.
Headwind Component:	5 KT.
Landing Distance:	2,964 FT.

ASSOCIATED CONDITIONS	
Runway:	PAVED, LEVEL, DRY SURFACE
Weight:	4,850 LB.
Airframe Ice:	45 MIN HOLD
Approach:	3 DEGREES
Flaps:	20°
Approach Speed:	100 KIAS
Touch Down Speed:	92 KIAS
Braking:	MODERATE WITH BETA



Landing Distance, Flaps 20°, without Reverse

Figure 5


SECTION 5 - PERFORMANCE (continued)

EXAMPLE

OAT: -5°C
 Runway Gradient: 1% UP
 Pressure Altitude: 3,500 FT.
 Headwind Component: 5 KT.
 Landing Distance: 903 MTR

ASSOCIATED CONDITIONS

Runway: PAVED, LEVEL, DRY SURFACE
 Weight: 2,200 KG.
 Airframe Ice: 45 MIN HOLD
 Approach: 3 DEGREES
 Flaps: 20°
 Approach Speed: 100 KIAS
 Touch Down Speed: 92 KIAS
 Braking: MODERATE WITH BETA



Landing Distance, Flaps 20°, without Reverse (Metric)

Figure 6



SECTION 6 - WEIGHT AND BALANCE

No change.

THIS SPACE INTENTIONALLY LEFT BLANK

SECTION 7 - DESCRIPTION AND OPERATION OF THE AIRPLANE AND ITS SYSTEMS

PNEUMATIC DE-ICE SYSTEM

The Piper Meridian utilizes BF Goodrich pneumatic de-ice boots to displace ice from the leading edges of the wing, vertical and horizontal stabilizer. The de-ice boots are fabricated from neoprene containing built in span wise inflation tubes. The system consists of the wing, vertical and horizontal stabilizer de-ice boots, pressure regulator, ejector, pressure switches, de-icer flow valves, vacuum regulator, timer, check valve and a water separator. The timer allows continuous operation of the pneumatic de-ice system without additional input from the pilot once the system is selected on. The de-ice boots are inflated by engine bleed air and held down during flight by vacuum supplied by a single fixed orifice ejector.

Operation of the pneumatic de-ice system is controlled by an alternate action push-button switch, labeled SURF DE-ICE, on the overhead switch panel. When the switch is engaged, power is supplied to the de-ice timer which then shuttles the empennage de-icer flow valve to supply precooled bleed air pressure to the empennage boots for six seconds. At the end of six seconds the empennage de-icer flow valve returns to the vacuum (normal) position and the bottom wing de-icer flow valve is shuttled to the pressure side. After a second 6 seconds the bottom wing deicer flow valve is shuttled back to the vacuum side and the process is repeated for the upper wing boots. This complete cycle is repeated every 60 seconds or until the surface deice switch is disengaged. The timer monitors system voltage, increasing and decreasing boot pressure, and cycle advance. Should any failure in operation be detected, the red SURF DE-ICE FAIL annunciator will illuminate.

Circuit protection for the surface de-ice system is provided by a SURFACE DE-ICE circuit breaker (located on the pilot's aft circuit breaker panel, Row A, Position 6).

SECTION 7 - DESCRIPTION AND OPERATION OF THE AIRPLANE AND ITS SYSTEMS (continued)

HEATED PROPELLER

The propeller de-ice system consists of dual element heater boots bonded to the inner 1/3 portion of each propeller blade, slip ring assemblies connected to the propeller hub to distribute power to the propeller blade heating elements, a modular brush assembly which transfers electrical power to the rotating slip rings, and an electronic control module (timer) to cycle power to the heaters. In flight, when the PROP HEAT switch is selected ON, the electronic control module directs power through the modular brush assembly and slip ring to the outer 4 propeller blade heating elements for approximately 90 seconds. The electronic control module then switches power to the inner 4 propeller blade heating elements for approximately 90 seconds. This cycle will continue as long as the PROP HEAT switch is in the ON position and the airplane is airborne.

During Ground operations with the PROP HEAT switch engaged, power is sent to the outer 4 propeller blade heating elements for 30 seconds and then power is directed to the inner 4 propeller blade heating elements for the next 30 seconds. After one minute, the electronic control module will remove power to the boots and the system will remain OFF as long as the airplane remains on the ground, unless the operator manually selects the PROP HEAT switch ON, again, or until the airplane leaves the ground.

A red Prop Heat Fail (PROP HEAT FAIL) annunciator will illuminate if:

1. An over current (greater than 30 amps).
2. An under current (less than 18.0 amps).
3. A loss of power when the PROP HEAT is selected ON.
4. 28 Vdc applied when the PROP HEAT switch is not engaged.

In the over current scenario, the timer will de-energize the propeller heat, and illuminate the red PROP HEAT FAIL annunciation. In the under current scenario, the timer will maintain the propeller heat on and illuminate the red PROP HEAT FAIL annunciation.

**SECTION 7 - DESCRIPTION AND OPERATION OF THE AIRPLANE
AND ITS SYSTEMS (continued)****HEATED WINDSHIELD**

The left-side windshield in the cockpit is heated by current from the aircraft electrical system. Windshield heat is controlled by a 3 position rocker switch located in the overhead switch panel and labeled WINDSHLD HT DEFOG - ANTI ICE. Circuit protection for the heated windshield is provided by the WINDSHIELD HEAT CONTROL and POWER circuit breakers in the pilot's aft circuit breaker panel (Row A, Position 7 and 8).

NOTE

The right cockpit windshield is not heated, therefore during icing conditions visibility through the right windshield may be impaired or completely eliminated.

CAUTION

To avoid possible windshield distortion or overheat during ground operations, or during testing, do not position the WINDSHLD HT switch to ANTI ICE or DEFOG for more than 20 seconds.

WINDSHLD HT should be selected to the ANTI ICE position prior to entering suspected icing conditions. Sudden penetration into icing conditions, with the windshield heat OFF, will greatly reduce its effectiveness to prevent or eliminate windshield ice.

An over-temperature sensor is included as an integral part of the heated windshield. A system failure causing an over-temperature condition (above 170°F / 77°C) will illuminate the red Windshield Overtemperature CAS message (WINDSHLD OVRTEMP) located on the MFD.

NOTE

During high ambient temperature conditions when switching windshield heat from ANTI ICE to DEFOG the red Windshield Overtemperature annunciator (WINDSHLD OVRTEMP) may illuminate and remain illuminated until the windshield surface temperature cools to the DEFOG heat temperature range.

SECTION 7 - DESCRIPTION AND OPERATION OF THE AIRPLANE AND ITS SYSTEMS (continued)

HEATED PITOT

A pitot heat anti-ice system is installed to assure proper airspeed indications in the event icing conditions are encountered. The system is designed to prevent ice formation rather than remove it, once formed. During normal operations pitot heat should be selected ON and the amber Pitot Heat Off annunciator (PITOT HEAT OFF) extinguished before take-off.

One heated pitot head is installed on the underside of each wing. Pitot heat is controlled by a single PITOT HEAT switch located in the overhead switch panel and protected by L PITOT HEAT and R PITOT HEAT circuit breakers located in the pilot's aft circuit breaker panel (Row A Position 2 and 3).

CAUTION

Care should be taken when an operational check of the heated pitot head is being performed on the ground. The unit becomes very hot. Ground operation should be limited to three minutes to avoid damaging the heating elements.

HEATED STALL WARNING

A heated stall warning vane is installed in the leading edge of the left wing. It is controlled by a STALL HEAT switch located in the overhead switch panel and is protected by a STALL HEAT circuit breaker located in the pilot's aft circuit breaker panel (Row A Position 5). To prevent damage during ground operation, the stall warning has an in-line resistor activated by the main gear squat switch which limits the ground electrical load to approximately 33 percent of the in-flight load.

NOTE

Prolonged operation of the stall warning vane heater in temperatures greater than 5°C will reduce the operational life of the stall warning vane.

**SECTION 7 - DESCRIPTION AND OPERATION OF THE AIRPLANE
AND ITS SYSTEMS (continued)****ICE LIGHT (Wing Inspection Light)**

An ice detection light is installed on the left side of the forward fuselage, and when selected ON, will illuminate the left wing leading edge. The ice detection light is controlled by the ICE LIGHT switch located in the overhead switch panel. Circuit protection is provided by an ICE circuit breaker located in the EXTERIOR LIGHTS section of the pilot's forward circuit breaker panel (Row A Position 7).

ALTERNATE STATIC SOURCE

An alternate static source control valve is located on the sidewall below the lower left corner of the instrument panel. For normal operation, the control valve lever should be in the down position. To select the alternate static source, the control valve lever should be placed in the up position. When alternate static source and ADC 1 are selected, the pilot's airspeed, altimeter and vertical speed indicators, and the standby airspeed and altimeter, are vented to the alternate static buttons located on the right and left side of the AFT fuselage. During operation with the alternate static source selected, the airspeed, altimeter, and vertical speed indicator will give slightly different readings than normal. Charts depicting airspeed and altitude position error calibrations using alternate static source are provided in the Pilots Operating Handbook and FAA Approved Airplane Flight Manual, Section 5, Performance.




THIS PAGE INTENTIONALLY LEFT BLANK

**PILOT'S OPERATING HANDBOOK
AND
FAA APPROVED AIRPLANE FLIGHT MANUAL**

**SUPPLEMENT NO. 2
FOR
BENDIX/KING KR-87 DIGITAL ADF
WITH GARMIN PFD INDICATOR**

This supplement must be attached to the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual when the Bendix/King KR-87 Digital ADF with the Garmin Primary Flight Display (PFD) Indicator is installed per the Equipment List. The information contained herein supplements or supersedes the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual only in those areas listed herein. For limitations, procedures and performance information not contained in this supplement, consult the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual.

FAA APPROVED:



ALBERT J. MILL
DOA-510620-CE
PIPER AIRCRAFT, INC.
VERO BEACH, FLORIDA

DATE OF APPROVAL: November 12, 2008



SECTION 1 - GENERAL

The Bendix/King Digital ADF is a panel mounted, digitally tuned, automatic direction finder. It is designed to provide continuous 1 kHz digital tuning in the frequency range of 200 kHz to 1799 kHz and eliminates the need for mechanical band switching. The system comprises a receiver, a built-in electronic timer, a bearing indicator on the Garmin PFD and a KA-44B combined loop and sense antenna.

The Bendix/King Digital ADF can be used for position plotting and homing procedures, and for aural reception of amplitude modulated (AM) signals.

The "flip-flop" frequency display allows switching between pre-selected "STANDBY" and "ACTIVE" frequencies by pressing the frequency transfer button. Both preselected frequencies are stored in a non-volatile memory circuit (no battery power required) and displayed in self-dimming gas discharge numerics. The active frequency is continuously displayed in the left window, while the right window will display either the standby frequency or the selected readout from the built-in timer.

The built-in electronic timer has two separate and independent timing functions: (1) An automatic flight timer that starts whenever the unit is turned on. This timer functions up to 59 hours and 59 minutes. (2) An elapsed timer which will count up or down for up to 59 minutes and 59 seconds. When a preset time interval has been programmed and the countdown reaches :00, the display will flash for 15 seconds. Since both the flight timer and elapsed timer operate independently, it is possible to monitor either one without disrupting the other. The pushbutton controls are internally lighted.

SECTION 2 - LIMITATIONS

No change.

SECTION 3 - EMERGENCY PROCEDURES

No change.

SECTION 4 - NORMAL PROCEDURES**To Operate as an Automatic Direction Finder:**

1. OFF/VOL Control - ON.
2. Frequency Selector Knobs - SELECT desired frequency in the standby frequency display.
3. FRQ Button - PRESS to move the desired frequency from the standby to the active position.
4. ADF SPEAKER/PHONE - Selector Switch (on audio control panel) - SELECT as desired.
5. OFF/VOL Control - SET to desired volume level.
6. ADF Bearing - Display ADF bearing on either PFD by selecting the PFD softkey, then pressing the BRG1 or BRG2 softkey until "ADF" is displayed in the appropriate Bearing 1 or Bearing 2 Information Window and the bearing pointer is displayed on the HSI.

ADF Test (Pre-flight or In-flight):

1. ADF Button - SELECT ANT mode and note pointer moves towards the 90° position and then disappears.
2. ADF Button - SELECT ADF mode and note the pointer moves without hesitation to the station bearing. Excessive pointer sluggishness, wavering or reversals indicate a signal that is too weak or a system malfunction.



SECTION 4 - NORMAL PROCEDURES (continued)

NOTE

The Standby Frequency which is in memory while Flight Time or Elapsed Time modes are being displayed may be called back by pressing the FRQ button, then transferred to active use by pressing the FRQ button again.

To Operate Elapsed Time Timer-Count Down Mode:

1. OFF/VOL Control - ON.
2. FLT/ET Mode Button - PRESS (once or twice) until ET is annunciated.
3. SET/RST Button - PRESS until the ET annunciation begins to flash.
4. FREQUENCY SELECTOR KNOBS - SET desired time in the elapsed time display. The small knob is pulled out to tune the 1's. The small knob is pushed in to tune the 10's. The outer knob tunes minutes up to 59 minutes.

NOTE

Selector knobs remain in the time set mode for 15 seconds after the last entry or until the SET/RST, FLT/ET, or FRQ button is pressed.

5. SET/RST Button - PRESS to start countdown. When the timer reaches 0, it will start to count up as display flashes for 15 seconds.

NOTE

While FLT or ET are displayed, the active frequency on the left side of the window may be changed, by using the frequency selector knobs, without any effect on the stored standby frequency or the other modes.

SECTION 4 - NORMAL PROCEDURES (continued)**ADF Operation NOTES:***Erroneous ADF Bearing Due to Radio Frequency Phenomena:*

In the U.S., the FCC, which assigns AM radio frequencies, occasionally will assign the same frequency to more than one station in an area. Certain conditions, such as Night Effect, may cause signals from such stations to overlap. This should be taken into consideration when using AM broadcast station for navigation.

Sunspots and atmospheric phenomena may occasionally distort reception so that signals from two stations on the same frequency will overlap. For this reason, it is always wise to make positive identification of the station being tuned, by switching the function selector to ANT and listening for station call letters.

Electrical Storms:

In the vicinity of electrical storms, an ADF indicator pointer tends to swing from the station tuned toward the center of the storm.

Night Effect:

This is a disturbance particularly strong just after sunset and just after dawn. An ADF indicator pointer may swing erratically at these times. If possible, tune to the most powerful station at the lowest frequency. If this is not possible, take the average of pointer oscillations to determine relative station bearing.

Mountain Effect:

Radio waves reflecting from the surface of mountains may cause the pointer to fluctuate or show an erroneous bearing. This should be taken into account when taking bearings over mountainous terrain.

Coastal Refraction:

Radio waves may be refracted when passing from land to sea or when moving parallel to the coastline. This also should be taken into account.




SECTION 5 - PERFORMANCE

No change.


SECTION 6 - WEIGHT AND BALANCE

Factory installed optional equipment is included in the licensed weight and balance data in Section 6 of the Pilot's Operating Handbook and Airplane Flight Manual.

SECTION 7 - DESCRIPTION AND OPERATION



KR-87 Digital ADF



14

ADF Displays on Garmin PFD

King Digital ADF Operating Controls and PFD Indicator
Figure 1



SECTION 7 - DESCRIPTION AND OPERATION (continued)

Legend - Figure 1

1. Mode Annunciation - Antenna (ANT) is selected by the "out" position of the ADF button. This mode improves the aural reception and is usually used for station identification. The bearing pointer is deactivated and will move towards the 90° relative position and then disappear. Automatic Direction Finder (ADF) mode is selected by the depressed position of the ADF button. This mode activates the bearing pointer. The bearing pointer will point in the direction of the station relative to the aircraft heading.
2. Active Frequency Display - The frequency to which the ADF is tuned is displayed here. The active ADF frequency can be changed directly when either of the timer functions are selected.
3. Beat Frequency Oscillator (BFO) - The BFO mode, activated and annunciated when the "BFO" button is depressed, permits the carrier wave and associated morse code identifier broadcast on the carrier wave to be heard.


NOTE

CW signals (Morse Code) are unmodulated and no audio will be heard without use of BFO. This type of signal is not used in the United States air navigation. It is used in some foreign countries and marine beacons.

4. Standby Frequency Annunciation (FRQ) - When FRQ is displayed, the STANDBY frequency is displayed in the right hand display. The STANDBY frequency is selected using the frequency select knobs. The selected STANDBY frequency is put into the ACTIVE frequency window by pressing the frequency transfer button.
5. Standby Frequency Display - Either the standby frequency, the flight timer, or the elapsed time is displayed in this position. The flight timer and elapsed timer are displayed replacing the standby frequency which goes into "blind" memory to be called back at any time by depressing the FRQ button. Flight time or elapsed time are displayed and annunciated alternatively by depressing the FLT/ET button.

SECTION 7 - DESCRIPTION AND OPERATION (continued)**Legend - Figure 1 (continued)**

6. Timer Mode Annunciation - Either the elapsed time (ET) or flight time (FLT) mode is annunciated here.
7. Frequency Selector Knobs - Selects the standby frequency when FRQ is displayed and directly selects the active frequency whenever either of the timer functions is selected. The frequency selector knobs may be rotated either clockwise or counterclockwise. The small knob is pulled out to tune the 1's. The small knob is pushed in to tune the 10's. The outer knob tunes the 100's with rollover into the 1000's. These knobs are also used to set the desired time when the elapsed timer is used in the countdown mode.
8. Off/Volume Control (OFF/VOL) - Controls primary power and audio output level. Clockwise rotation from OFF position applies primary power to receiver; further clockwise rotation increases audio level. Audio muting causes the audio output to be muted unless the receiver is locked on a valid station.
9. Set/Reset Button (SET/RST) - The set/reset button, when pressed, resets the elapsed timer whether it is being displayed or not.
10. Flight Time/Elapsed Time Mode Selector Button (FLT/ET) - The Flight Timer/Elapsed Time mode selector button, when pressed, alternatively selects either Flight Timer mode or Elapsed Timer mode.
11. Frequency Transfer Button (FRQ) - The FRQ transfer button, when pressed, exchanges the active and standby frequencies. The new frequency becomes active and the former active frequency goes into standby.
12. BFO Button - The BFO button selects the BFO mode when in the depressed position (see Note under item 3).
13. ADF Button - The ADF button selects either the ANT mode or the ADF mode. The ANT mode is selected with the ADF button in the out position. The ADF mode is selected with the ADF button in the depressed position.
14. Bearing Pointer (on PFD) - The cyan arrow indicates magnetic bearing to the station in degrees.




THIS PAGE INTENTIONALLY LEFT BLANK

**PILOT'S OPERATING HANDBOOK
AND
FAA APPROVED AIRPLANE FLIGHT MANUAL**

**SUPPLEMENT NO. 3
FOR
BENDIX/KING KN-63 DME**

This supplement must be attached to the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual when the Bendix/King KN-63 DME is installed per the Equipment List. The information contained herein supplements or supersedes the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual only in those areas listed herein. For limitations, procedures and performance information not contained in this supplement, consult the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual.

FAA APPROVED:



ALBERT J. MILL
DOA-510620-CE
PIPER AIRCRAFT, INC.
VERO BEACH, FLORIDA

DATE OF APPROVAL: November 12, 2008

SECTION 1 - GENERAL

The Bendix/King KN-63 DME supplies continuous slant range distance information from a fixed ground station to an aircraft in flight.

The equipment consists of a Garmin Primary Flight Display (PFD) which contains all the operating controls and displays, and a remotely mounted KN-63 Receiver-Transmitter. The Garmin PFD displays the Nav radio (1 and 2) which is receiving the DME signal, the Nav frequency and the distance to the DME station in nautical miles.

SECTION 2 - LIMITATIONS

No change.

SECTION 3 - EMERGENCY PROCEDURES

No change.

SECTION 4 - NORMAL PROCEDURES**DME Operation**

1. NAV 1 and NAV 2 VHF Navigation Receivers - ON; TUNE FREQUENCY to VOR/DME or VORTAC station frequencies, as required.

NOTE

When the VORTAC or VOR/DME frequency is selected, the appropriate DME frequency is automatically channeled.

2. DME IDENTIFICATION - select DME button on audio panel (audio ID will always come through the headset and will come through the cockpit speaker if SPKR is selected on the audio panel).
3. Select PFD softkey, then DME softkey to display DME Information window.
4. Select DME softkey on PFD to display DME TUNING Window.
5. Select NAV1, NAV2 or HOLD mode from DME TUNING window.


SECTION 5 - PERFORMANCE

No change.

SECTION 6 - WEIGHT AND BALANCE

Factory installed optional equipment is included in the licensed weight and balance data in Section 6 of the Pilot's Operating Handbook and Airplane Flight Manual.

SECTION 7 - DESCRIPTION AND OPERATION




DME Display on Garmin PFD

Figure 1

Legend - Figure 1

1. DME Information Window
2. DME MODE ANNUNCIATOR
Displays the DME operating mode; NAV 1; NAV 2; or HOLD as selected in the DME TUNING window.
3. FREQUENCY
Displays the frequency of the VOR/DME or VORTAC selected on the associated navigation radio.
4. DISTANCE DISPLAY (NM)
DME distance to VOR/DME or VORTAC displayed in .1 nautical mile increments up to 99.9 NM, then in increments of one nautical mile to up to 389 NM.



SECTION 7 - DESCRIPTION AND OPERATION (continued)


Legend - Figure 1 (continued)

5. DME TUNING Window (NAV1, NAV2, HOLD)

Allows access to the DME operating mode as follows:

NAV 1 Selects DME operation with No. 1 VHF navigation set; enables channel selection by NAV 1 frequency selector controls.

5 ———



NAV 2 Selects DME operation with No. 2 VHF navigation set; enables channel selection by NAV 2 frequency selector switches. Brightness of the labels for this switch is controlled by the RADIO light dimming rheostat.

HOLD Selects DME memory circuit; DME remains channeled to station which was last channeled when HOLD was selected and will continue to display information relative to this channel. Allows both the NAV 1 and NAV 2 navigation receivers to be set to new operational frequencies without affecting the previously selected DME operation.

NOTE


In the HOLD mode there is no annunciation of the NAV 1 / Nav 2 radio which is being used, but the frequency tuned via that radio remains on the display. Additionally, an annunciator labeled HOLD illuminates on the DME display to flag the pilot that the DME is in the HOLD mode.

**PILOT'S OPERATING HANDBOOK
AND
FAA APPROVED AIRPLANE FLIGHT MANUAL

SUPPLEMENT NO. 4
FOR
WX-500 STORMSCOPE - OPTIONAL**


This supplement must be attached to the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual when the WX-500 Stormscope is installed per the Equipment List. The information contained herein supplements or supersedes the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual only in those areas listed herein. For limitations, procedures and performance information not contained in this supplement, consult the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual.

FAA APPROVED:



ALBERT J. MILL
DOA-510620-CE
PIPER AIRCRAFT, INC.
VERO BEACH, FLORIDA

DATE OF APPROVAL: November 12, 2008

**SECTION 1 - GENERAL**

This supplement provides information necessary for the operation of the aircraft with the L3 WX-500 Stormscope.

WARNING

Never use your Stormscope system to attempt to penetrate a thunderstorm. The FAA Advisory Circular, Subject: Thunderstorms, and the Aeronautical Information Manual (AIM) recommend that a pilot "avoid by at least 20 miles any thunderstorm identified as severe or giving an intense radar echo.

NOTE

There are several atmospheric phenomena other than nearby thunderstorms that can cause isolated discharge points in the strike display mode. However, clusters of two or more discharge points in the strike display mode do indicate thunderstorm activity if these points reappear after the screen has been cleared. Avoid the clusters and you will avoid the thunderstorms. In the cell display mode, even a single discharge point may represent thunderstorm activity and should be avoided.

NOTE

L-3 STORMSCOPE® WX-500 Lightning and GDL-69/69A XM® Satellite Weather Lightning are mutually exclusive products.

SECTION 2 - LIMITATIONS

The L-3 WX-500 Stormscope Weather Mapping Sensor Users Guide, p/n 002-11503-002, Rev. K, dated 10-Jan-2008 or later appropriate revision, must be immediately available to the flight crew whenever weather avoidance is predicated on the use of this system.

SECTION 3 - EMERGENCY PROCEDURES

No change.

SECTION 4 - NORMAL PROCEDURES

To display Stormscope data on the Stormscope Page, proceed to the Map Page Group on the MFD and turn the small FMS knob to the Stormscope page.

To display Stormscope data on any map besides the Stormscope Page, select the MAP softkey (or the INSET softkey for the PFD Inset Map), then select the STRMSCP softkey. These pages can also display cell or strike data using the yellow lightning strike symbology shown in the table contained in Section 7 below.

To change the range on the Stormscope Page display, rotate the RANGE knob clockwise to zoom out and counterclockwise to zoom in.

To change the viewing mode on the Stormscope Page, select the Stormscope Page, select the VIEW softkey, select the 360 softkey to display a 360° viewing area or select the ARC softkey to display a 120° viewing area. Select the BACK softkey to return to the Stormscope Page. This same feature is also selectable through the MENU key on the Stormscope Page.

Customizing Stormscope options is also available on the Navigation Map page. Proceed to the Navigation Map page, depress the MENU key, highlight the Map Setup option and press the ENT key, turn the small FMS knob to highlight the Weather group, turn the large FMS knob to highlight and move between the product selections. When an item is highlighted, turn the small FMS knob to select the option and press the ENT key. Press the FMS knob or the CLR key to return to the Navigation Map Page with the changed settings.

The following options will be available:

- * STRMSCP LTNG – Turns the display of Stormscope data on or off.
- * STRMSCP MODE – Selects the CELL or STRIKE mode of lightning activity. Cell mode identifies clusters or cells of electrical activity. Strike mode indicates the approximate location of lightning strikes.
- * STRMSCP SMBL – Selects the range at which Stormscope data displays. Stormscope data is removed when a map range greater than the STRMSCP SMBL value is selected.

SECTION 4 - NORMAL PROCEDURES (continued)

To clear Stormscope data from the Navigation Map page, proceed to the Navigation Map page, depress the MENU key, select "Clear Stormscope Lightning" and press the ENT key.

SECTION 5 - PERFORMANCE

No change.

SECTION 6 - WEIGHT AND BALANCE

Factory installed optional equipment is included in the licensed empty weight and balance data in Section 6 of the Pilot's Operating Handbook.

SECTION 7 - DESCRIPTION AND OPERATION

Stormscope data will appear automatically on the Stormscope Page. If it is desired to overlay Stormscope data on additional pages, the procedure stated in Section 4 of this supplement should be followed.

The following pages can display Stormscope data:

- * Navigation Map
- * Stormscope Page
- * AUX - Trip Planning Page
- * Nearest Pages
- * PFD Inset Map

Regardless of the page that is displaying Stormscope data, the symbology will be as follows:

Lightning Age	Symbol
Strike is less than 6 seconds old	
Strike is between 6 and 60 seconds old	
Strike is between 1 and 2 minutes old	
Strike is between 2 and 3 minutes old	


SECTION 7 – DESCRIPTION AND OPERATION (continued)

If Stormscope data has been selected ON, a small Stormscope icon will appear in the lower right corner of the Navigation Map page. Additional information concerning the map orientation, Stormscope mode selected and strike rate per minute is displayed in the upper right corner of the Navigation Map page.

If heading input is lost, strikes and/or cells must be cleared manually after the execution of each turn. This is to ensure that the strike and/or cell positions are depicted accurately in relation to the nose of the aircraft.

Stormscope lightning data can be displayed up to 800 nm zoom range (in North Up orientation) on the Navigation Map Page. However, in Track Up orientation at the 500 nm range, a portion of Stormscope lightning data can be behind the aircraft and therefore not visible on the Navigation Map. Since the range for Stormscope data is 400 nm diameter total (200 nm in front and 200 nm behind), the 500 nm range in North Up orientation shows all the data.

At a map range of less than 25 nm, Stormscope lightning data is not displayed, but can still be present. The presence of Stormscope lightning data is indicated by the annunciation 'LTNG < 25 nm' in the upper right corner of the Navigation Map Page.




THIS PAGE INTENTIONALLY LEFT BLANK

**PILOT'S OPERATING HANDBOOK
AND
FAA APPROVED AIRPLANE FLIGHT MANUAL
SUPPLEMENT NO. 5
FOR
ADDITION OF SYNTHETIC VISION AND
PATHWAY TO THE GARMIN G1000 SOFTWARE SUITE**

This supplement must be attached to the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual when the Synthetic Vision Sub System (SVS) for the Garmin G1000 is installed per the Equipment List. The information contained herein supplements or supersedes the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual only in those areas listed herein. For limitations, procedures and performance information not contained in this supplement, consult the Pilot's Operating Handbook and FAA Approved Airplane Flight Manual.

FAA APPROVED:




ALBERT J. MILL
ODA-510620-CE
PIPER AIRCRAFT, INC.
VERO BEACH, FLORIDA

DATE OF APPROVAL: November 6, 2009

SECTION 1 - GENERAL

This supplement describes the Synthetic Vision Sub System (SVS) that is an optional part of the Garmin G1000 Integrated Avionics System. This information supplements the information presented in the Pilot Operating Handbook. For additional information, consult the "G1000 Integrated Flight Deck Cockpit Reference Guide for the Piper PA-46 Meridian", P/N 190-00764-XX.

The purpose of the SVS is to assist the pilot in maintaining situational awareness with regard to the terrain and traffic surrounding the aircraft and the navigational situation relative to the programmed flight plan. A typical SVS display is shown in Figure 1.



Typical SVS Display

Figure 1

SVS provides additional features on the G1000 primary flight displays with the following information:

- **Synthetic Terrain;** an artificial, database derived, three dimensional view of the terrain ahead of the aircraft within a field of view of approximately 30 degrees left and 35 degrees right of the aircraft heading.
- **Obstacles;** obstacles such as towers, including buildings over 200 AGL that are within the depicted synthetic terrain field of view.
- **Flight Path Marker (FPM);** A green circular barbed symbol showing the current lateral and vertical path of the aircraft. The FPM is always displayed when synthetic terrain is selected for display.

SECTION 1 - GENERAL (Continued)

- **Pathway;** a pilot selectable three dimensional representation of the programmed flight plan path that can be selected for display alone or with the flight director anytime synthetic terrain is selected for display.
- **Traffic;** a display on the PFD indicating the position of other aircraft detected by the Traffic Alerting System (TAS).
- **Horizon Line;** a white line indicating the true horizon is always displayed on the SVS display.
- **Horizon Heading;** a pilot selectable display of heading marks displayed just above the horizon line on the PFD.
- **Airport Signs;** pilot selectable "signposts" displayed on the synthetic terrain display indicating the position of nearby airports that are in the G1000 database.
- **Runway Highlight;** a highlighted presentation of the location and orientation of the runway(s) at the destination airport.

The synthetic terrain depiction displays an area approximating the view from the pilot's eye position when looking directly ahead out the windshield in front of the pilot. Terrain features outside this field of view are not shown on the display.

The synthetic terrain display is intended to aid the pilot's awareness of the terrain and obstacles in front of the airplane. It may not provide either the accuracy or fidelity, or both, on which to solely base decisions and plan maneuvers to avoid terrain or obstacles. The synthetic vision elements are not intended to be used for primary aircraft control in place of the primary flight instruments

The Pathway presentation is intended only to aid the pilot's awareness of the programmed flight path location relative to the airplane's current position. No vertical Pathway information is presented along the climb path but Pathway boxes may be displayed along the course at the selected target altitude.

SECTION 2 - LIMITATIONS

1. Use of the SVS display elements alone for aircraft control without reference to the G1000 primary flight instruments or the aircraft standby instruments is prohibited.
2. Use of the SVS alone for navigation, or obstacle or terrain avoidance is prohibited.



SECTION 2 - LIMITATIONS (Continued)

- 3. Use of the SVS traffic display alone to avoid other aircraft is prohibited.

SECTION 3 - EMERGENCY PROCEDURES

SVS Displays information inconsistent with G1000 primary flight instrumentation.

On the PFD:

- PFD SoftkeyPRESS
- SYN VIS SoftkeyPRESS
- SYN TERR SoftkeyPRESS
- SVS is removed from both PFD displaysVERIFY
- Use G1000 primary displays for navigation and aircraft control.

If G1000 operation in display backup mode is required

Select display backup mode on the G1000 system.

NOTE:

When display backup mode is selected, the MFD will initially present a non SVS (blue sky over solid brown ground) display. SVS will be presented on the backup display within 20 seconds if it was enabled on the PFD when display backup was selected.


SECTION 4 - NORMAL PROCEDURES

Turn Synthetic Vision on/off:

On either PFD:

- PFD SoftkeyPRESS
- SYN VIS SoftkeyPRESS
- SYN TERR Softkey.....PRESS as desired

The SVS will cycle on or off with each press of the SYN TERR Softkey. The Flight Path Marker, Traffic, Horizon Line and Runaway Highlight are displayed anytime SYN TERR is selected for display.



SECTION 4 - NORMAL PROCEDURES (Continued)

The SVS display may be turned on or off from either the pilot or copilot PFD displays. Turning SVS on or off from either display will simultaneously make the same change on the other PFD. The system will not permit display of SVS on one PFD and non-SVS on the other PFD.

Turn Pathways on/off:

On either PFD:

- PFD SofkeyPRESS
- SYN VIS SofkeyPRESS
- PATHWAY SofkeyPRESS as desired

The Pathway display will cycle on or off with each press of the PATHWAY Sofkey. The Pathway can be displayed separately or in conjunction with the flight director and may be independently selected on each PFD.

NOTE:

If displayed, the Pathway may be quickly turned off by pressing the PFD sofkey at the bottom of the PFD followed by two presses of the far left PFD sofkey (SYN VIS and PATHWAY).

Turn Horizon Heading on/off:

On the PFD:

- PFD SofkeyPRESS
- SYN VIS SofkeyPRESS
- HRZN HDG SofkeyPRESS as desired

The horizon heading display will cycle on or off with each press of the HRZN HDG Sofkey and may be independently selected on each PFD.

Turn Airport Signs on/off:

On the PFD:

- PFD SofkeyPRESS
- SYN VIS SofkeyPRESS
- APTSIGNS SofkeyPRESS as desired

The airport signposts display will cycle on or off with each press of the APTSIGNS sofkey and may be independently selected on each PFD.



SECTION 4 - NORMAL PROCEDURES (Continued)

USE OF PATHWAY

If Synthetic Terrain is displayed on the PFD, the Pathway may be used to assist the pilot's awareness of the programmed lateral and vertical (descending) navigation path. The following sections describe the basic use of the Pathway in various flight segments. For more detailed information, consult the G1000 Pilot's Guide.

Departure

Prior to departure, load and activate the desired flight plan into the G1000 FMS, set the initial altitude on the G1000 altitude selector and select GPS on the HSI display just as you would without the SVS.

The programmed flight path will be displayed as a series of magenta boxes along the path at the flight plan altitude subject to the following conditions:

- If the first segment of the flight plan is a heading to altitude leg, the Pathway will not be displayed along the climb path for that segment. The first Pathway segment displayed will be the first GPS course leg.
- The Pathway must be within the SVS field of view of 30 degrees left and 35 degrees right. If the programmed path is outside that field of view, the Pathway will not be visible on the display until the aircraft has turned toward the course.
- The Pathway will be displayed at either the altitude selected on the G1000 selector OR the altitude published for the procedure (e.g. SID) **WHICHEVER IS HIGHER.**

After departure, the primary aircraft control must be by reference to the primary aircraft instruments. The SVS and Pathway displays should be used to aid in awareness of the terrain and programmed flight path.

Prior to intercepting the programmed course, the Pathway will be displayed as a series of magenta "boxes" with pointers at each corner that point in the direction of the programmed course. The Pathway boxes will not be displayed on portions of the course line that would lead the pilot to intercept the course in the wrong direction.

As the aircraft approaches the center of the programmed course and altitude, the number of Pathway boxes will decrease to a minimum of four.


SECTION 4 - NORMAL PROCEDURES (Continued)**Enroute**

When enroute, the Pathway will be displayed along the lateral path defined by the programmed flight plan, at the altitude selected on the G1000 altitude selector.


Flight plan changes in altitude that require a climb will be indicated by the Pathway being displayed as a level path at the altitude entered for the current flight plan leg. Because the G1000 system does not have information available concerning aircraft performance, climb profiles are not displayed by the Pathway.

If the programmed flight plan includes one or more defined VNAV descent segments, the descent path(s) will be displayed by the Pathway as prompted by the G1000 FMS.

If the flight plan includes a significant change in course at a waypoint, the Pathway boxes toward the currently active waypoint will be magenta in color. The boxes defining the next flight plan segment may be visible, but will be displayed in a white color.



Enroute Pathway Altitude Display
Figure 2



SECTION 4 - NORMAL PROCEDURES (Continued)

Approach

During approach, the SVS and Pathway displays should only be used to maintain awareness with regard to the surrounding terrain and the programmed flight path. Primary aircraft control must be accomplished by reference to the primary flight instruments and, if desired, the flight director.

GPS Approach

During a GPS approach, the lateral path and altitude will be displayed by the Pathway in magenta along each segment including the path required to track course reversals that are part of the approach procedure (such as a holding pattern). Approach descent segments will be displayed by the Pathway as published in the approach procedure.

If Vectors-To-Final is selected as the approach transition, the Pathway will display the final approach course inbound to the Missed Approach Point (MAP). The Pathway will be shown level at the altitude set in the G1000 altitude selector, or the Final Approach Fix (FAF) crossing altitude (whichever is higher), up to the point along the final approach course where that altitude intercepts the extended VPTH or GP. If the altitude selector indicates an altitude below the airplane's current altitude, the Pathway will appear below the airplane altitude and the pilot must use normal descent techniques to intercept the VPTH or GP. If the altitude selector is left at an altitude above the current airplane altitude, the airplane will intercept the final approach course below the extended VPTH or GP, such that the Pathway will be displayed above the airplane until the aircraft intercepts the VPTH or GP. From the VPTH or GP intercept point, the Pathway will be shown inbound to the MAP along the published lateral and vertical descent path.

ILS Approach

During an ILS approach, the initial approach segments will be displayed by the Pathway in magenta at the procedure segment altitudes if they are being flown by reference to a GPS path. When the G1000 system switches to the localizer inbound to the final approach fix, the Pathway will be displayed along the localizer inbound path and glideslope in green.

SECTION 4 - NORMAL PROCEDURES (Continued)**ILS Approach (Continued)**

If Vectors-To-Final is selected as the approach transition, the Pathway will display the final approach course inbound to the Missed Approach Point (MAP). The Pathway will be shown level at the altitude set in the G1000 altitude selector, or the Final Approach Fix (FAF) crossing altitude (whichever is higher), up to the point along the final approach course where that altitude intercepts the extended GS. If the altitude selector indicates an altitude below the airplane's current altitude, the Pathway will appear below the airplane altitude and the pilot must use normal descent techniques to intercept the GS. If the altitude selector is left at an altitude above the current airplane altitude, the airplane will intercept the final approach course below the extended GS, such that the Pathway will be displayed above the airplane until the aircraft intercepts the GS. From the GS intercept point, the Pathway will be shown inbound to the MAP along the published localizer and glideslope.

VOR, LOC BC, or other Approach

Approach segments for a VOR, LOC BC, ADF or other approach that are approved to be flown by reference to GPS will be displayed by the Pathway in a magenta color. Approach segments that are defined by other than a GPS or ILS, such as heading legs or VOR defined final approach course, will not be displayed by the Pathway.


Missed Approach

When the missed approach is selected on the G1000 FMS, the Pathway to the Missed Approach Holding Point will be displayed just as described for the departure segment.

The pilot must assure that the aircraft path will, at all times, comply with the requirements of the published missed approach procedure.

If the initial missed approach leg is a heading to altitude leg or a leg defined by other than a GPS course, the Pathway will not be displayed for that segment.


If the course to the Missed Approach Holding Point is out of the SVS field of view during the initial missed approach climb, the Pathway will not be visible on the PFD until the aircraft is turned toward the course.



SECTION 4 - NORMAL PROCEDURES (Continued)

Missed approach

The Pathway will be displayed at the published missed approach altitude OR the altitude set on the G1000 altitude selector WHICHEVER IS HIGHER. If the G1000 altitude selector is set to MDA on the final approach segment and not reset during the initial missed approach, the Pathway will still be displayed at the published missed approach altitude.



Missed Approach Pathway Display
Figure 3


SECTION 5 - PERFORMANCE

No change.

SECTION 6 - WEIGHT AND BALANCE

No change.

SECTION 7 - DESCRIPTION AND OPERATION



Synthetic Terrain Display
Figure 4

General

The SVS is dependent upon terrain data provided by the underlying G1000 system. If, for some reason, the terrain data is not available from the G1000, all of the components of the SVS will be unavailable. The flight path marker, horizon heading, and airport signs are all sub components of the Synthetic Terrain display and are only available when Synthetic Terrain is enabled. Those features are selected or deselected using the PFD softkeys on the SYN VIS menu and are independently selectable on each PFD.

SECTION 7 - DESCRIPTION AND OPERATION (Continued)**Synthetic Terrain**

The synthetic (3D) terrain display on the PFD provides a perspective view of the terrain ahead of the aircraft showing ground features up to 30 degrees left and 35 degrees right of the airplane heading. The terrain display is derived from the same terrain data contained in the G1000 system that is optionally used to display terrain on the MFD map display. The terrain data has a resolution of approximately 0.15 degrees of latitude and longitude at the current position; this means that the terrain elevation contours in the database are stored broken down into squares of 0.15 degrees of latitude and longitude on each side. That data is processed and smoothed by the G1000 system to provide the synthetic terrain display. In some instances, terrain features such as lakes in mountainous areas may be presented by the SVS as if the lake water extends somewhat up the mountainside. This is due to the limitations of the terrain database resolution but is not significant for the approved uses of SVS.

The SVS terrain display will show land contours, large water features, and towers/obstacles over 200 ft AGL (including buildings), that are included in the G1000 obstacle database. In order to provide a clean, uncluttered PFD display, cultural features on the ground such as roads, highways, railroad tracks, cities, and political boundaries (state / county lines) are not displayed on the PFD even if those features are selected for display on the MFD. The colors used to display the terrain elevation contours are similar to those used on the MFD map. The terrain display also includes a north-south, east west grid to assist in orientation relative to the terrain.

The terrain display is intended to serve as an awareness tool only. It may not provide either the accuracy or fidelity, or both, on which to solely base decisions and plan maneuvers to avoid terrain or obstacles. Navigation must not be predicated solely upon the use of the TAWS, Terrain or Obstacle data displayed by the SVS.

The Terrain/Obstacle/Airport databases have an area of coverage as detailed below:

- The Terrain Database has an area of coverage from North 75° Latitude to South 60° Latitude in all longitudes.
- The Airport Terrain Database has an area of coverage that includes the United States, Canada, Mexico, Latin America, and South America.
- The Obstacle Database has an area of coverage that includes the United States.

SECTION 7 - DESCRIPTION AND OPERATION (Continued)**NOTE**


The area of coverage may be modified, as additional terrain data sources become available.

Obstacle and Terrain Alerts and Warnings

Obstacles and terrain displayed on the SVS may be highlighted if an alert or warning is generated by the G1000 Terrain or TAWS. If an obstacle alert is presented for an obstacle that is in the SVS field of view, the obstacle symbol on the PFD will turn yellow in color. If an obstacle warning is generated by the G1000 system, the obstacle symbol on the PFD will turn red.

If the G1000 Terrain or TAWS generates a terrain alert or warning, the terrain feature displayed on the PFD will be colored yellow for an alert or red for a warning for as long as the alert remains valid.

Because the area monitored by the Terrain or TAWS can be wider than the field of view that can be displayed by the SVS, it is possible to receive an obstacle or terrain audible alert for an obstacle or terrain that is not shown on the SVS display. In those cases, the object generating the alert will be left or right of the aircraft. Refer to the other displays in the aircraft to determine the cause of the message.

Flight Path Marker

Flight Path Marker (FPM)
Figure 5



SECTION 7 - DESCRIPTION AND OPERATION (Continued)


Flight Path Marker (continued)

The SVS display includes a green circular barbed symbol called the Flight Path Marker (FPM) that represents the current path of the airplane relative to the terrain display. The FPM is always displayed when synthetic terrain is displayed and the aircraft ground speed exceeds 30 kt. The FPM indicates the current lateral and vertical path of the airplane as determined by the GPS sensor. If the FPM is above the horizon line, the airplane is climbing, and similarly if the FPM is below the horizon line, the airplane is descending. If the airplane is flying in a crosswind, the FPM will be offset from the center of the display. In that case, the center of the PFD airplane reference symbol indicates the airplane heading and the FPM indicates the direction that the airplane is actually moving, taking into account the crosswind.

The FPM indicates the current path of the airplane but does not predict the future path. If aircraft attitude, power setting, airspeed, crosswind, etc. are changed, the FPM will move to indicate the new path resulting from those changes.

If the FPM is below the terrain or obstacle displayed behind it on the PFD, the current aircraft path will not clear that terrain or obstacle. If the FPM is above the terrain or obstacle, the aircraft will clear the terrain or obstacle IF THE CURRENT AIRCRAFT CONFIGURATION IS MAINTAINED AND THE AIRCRAFT PERFORMANCE WILL PERMIT YOU TO MAINTAIN THE CURRENT VERTICAL (CLIMB) GRADIENT UNTIL PAST THE TERRAIN OR OBSTACLE.

Pathway




Pathway Display on PFD
Figure 6

SECTION 7 - DESCRIPTION AND OPERATION (Continued)**Pathway (continued)**

If PATHWAY is enabled on the SYN VIS menu of the PFD and a defined GPS navigation path has been entered on the G1000, the SVS system will display a Pathway, sometimes called a “highway in the sky” or HITS. The Pathway is a perspective representation of the programmed flight path. When the aircraft is well off course, the Pathway will be displayed as a number of boxes floating in the sky along the programmed lateral and vertical path. As the aircraft intercepts the programmed flight path, the number of boxes displayed will be reduced to a minimum of four to avoid cluttering the PFD display. The Pathway is only displayed for navigation paths that are fully defined by the sensor in use. Because a fully defined lateral and vertical path through space is not defined by them, a Pathway is not displayed for heading legs, VOR, LOC only, BC or ADF segments. When the Pathway is displayed, the color of the boxes indicates the sensor generating the path. If the GPS sensor is in use, the boxes will be magenta colored. If the LOC sensor is defining the path in use, the boxes will be green.

The Pathway boxes are ± 100 ft in vertical dimension and approximately ± 380 ft horizontally from the center of the box. The Pathway presentation is intended only to aid the pilot in awareness of the programmed flight path location relative to the airplane’s current position. The Pathway is not intended for use as a primary reference in tracking the navigation path.

If a GPS based descent profile has been programmed either on the G1000 flight plan page or as part of an approach or STAR, the descent will be displayed by the Pathway. Climb paths are never displayed by the Pathway. If a profile requires a climb, the Pathway will be displayed as a level segment at the higher of the altitude defined by the programmed path or the G1000 altitude selector.

Traffic

Traffic Displays on PFD


Figure 7

SECTION 7 - DESCRIPTION AND OPERATION (Continued)

Traffic (continued)

If traffic that is within the SVS field of view is detected by the G1000 system, a symbol will be displayed on the PFD indicating the direction and relative altitude of the traffic. Additionally, the traffic symbol enlarges as the traffic moves closer to the host aircraft. The traffic will be displayed as a white diamond unless it generates a traffic alert. Traffic that causes an alert will be displayed as a solid yellow circle accompanied by a yellow TRAFFIC annunciator to the top right of the airspeed display tape. The traffic symbol enlarges as the traffic moves closer to the host aircraft.


Horizon line



SVS Display on PFD showing True Horizon
Figure 8

The SVS display includes an always-visible white horizon line that represents the true horizon. Terrain will be presented behind the horizon line, and terrain shown above the horizon line is above the current aircraft altitude. Terrain that is shown below the horizon line is below the aircraft altitude.


Horizon Heading



Heading Scale Display on PFD
Horizon Line
Figure 9

SECTION 7 - DESCRIPTION AND OPERATION (Continued)**Horizon Heading (continued)**

A heading scale may be displayed on the PFD horizon line, if selected by the pilot. The heading marks are spaced in even 30 degree increments and are presented just above the horizon line with tic marks that intersect the horizon line. The horizon heading will correspond to that presented by the HSI. Because the horizon heading is only displayed in 30 degree increments, it should only be used for general heading awareness and not be used to establish the aircraft heading.

Airport Signs and runway highlight

“Sign Post” on SVS Display on PFD

Figure 10

If APTSIGNS is selected, a “signpost” along with a representation of the runways will be plotted on the SVS display for nearby airports that are contained in the G1000 airport database. The signpost will become visible when you are within approximately 15 nm of the airport. The text identifier for the airport will be displayed inside the airport sign when the aircraft reaches approximately 8 nm from the airport. Once the aircraft reaches approximately 4.5 nm from the airport, the airport sign will be removed but the runways presentation will remain. If an approach to a specific runway has been loaded and activated, that runway will be highlighted on the SVS display.

When on an approach, the highlight for the approach runway will be considerably larger than “normal” to assist in visually acquiring the runway. The oversized highlight will automatically shrink around the runway depiction so that the runway is proportionally displayed when the aircraft is within approximately ½ nm of the threshold. Runway highlighting is displayed even if APTSIGNS are turned off.

THIS PAGE INTENTIONALLY LEFT BLANK

TABLE OF CONTENTS
SECTION 10
OPERATING TIPS

Paragraph No.		Page No.
10.1	General	10-1
10.3	Operating Tips	10-1



THIS PAGE INTENTIONALLY LEFT BLANK

SECTION 10
OPERATING TIPS

10.1 GENERAL

This section provides operating tips of particular value in the operation of the Meridian.

10.3 OPERATING TIPS

- (a) Learn to trim for takeoff so that only a very light back pressure on the control wheel is required to lift the airplane off the ground.
- (b) On takeoff, do not retract the gear prematurely. The airplane may settle and make contact with the ground because of lack of flying speed, atmospheric conditions, or rolling terrain.
- (c) To slow the airplane while taxiing and to save the brakes, it is permissible to move the prop into beta and reverse.
- (d) To reduce flap operating loads, it is desirable to have the airplane at a speed slower than the maximum allowable before extending the flaps.
- (e) Before attempting to reset any circuit breaker, allow a two to five minute cooling off period.
- (f) Before starting the engine, check that all radio switches, light switches and the pitot heat switch are in the off position so as not to create an overloaded condition when the starter is engaged.
- (g) Anti-collision lights should not be operating when flying through cloud, fog or haze, since reflected light can produce spatial disorientation. Strobe lights should not be used in close proximity to the ground, such as during taxiing, takeoff or landing.

10.3 OPERATING TIPS (continued)

- (h) In extreme turbulence, reduce power setting to obtain design operating speed. (See Section 2 Limitations for correct speeds).
- (i) In an effort to avoid accidents, pilots should obtain and study the safety related information made available in FAA publications, such as regulations, advisory circulars, Aviation News, AIM and safety aids.
- (j) Prolonged slips or skids which result in excess of 2000 feet of altitude loss or other radical or extreme maneuvers which could cause uncovering of the fuel outlet must be avoided as fuel flow interruption may occur when the tank being used is not full.
- (k) In order to prevent propeller strikes while taxiing on rough terrain or crossing over rises, the airplane should be taxied slowly with minimum power and rises should be crossed at an acute angle. Tires and struts should be properly inflated.
- (l) Pilots who fly above 10,000 feet should be aware of the need for special physiological training. Appropriate training is available for a small fee at approximately twenty-three Air Force Bases throughout the United States. The training is free at the NASA Center in Houston and at the FAA Aeronautical Center in Oklahoma.

Forms to be completed (Physiological Training Application and Agreement) for application for the training course may be obtained by writing to the following address:

Chief of Physiological Training, AAC-143
FAA Aeronautical Center
P.O. Box 25082
Oklahoma City, Oklahoma 73125

It is recommended that all pilots who plan to fly above 10,000 feet receive physiological training and then take refresher training every two or three years.